

# **DETROIT DIESEL**

---

**DDEC III/IV Single ECM**

***Troubleshooting Guide***

---

# Troubleshooting Manual

## Detroit Diesel® DDEC® Single ECM

**DETROIT DIESEL**  
**CORPORATION**



Detroit Diesel Corporation  
13400 Outer Drive, West / Detroit, Michigan 48239-4001  
Telephone: 313-592-5000  
Fax: 313-592-7888  
<http://www.detroitdiesel.com>

**NOTE:**

Additional copies of this troubleshooting manual may be purchased from Detroit Diesel Corporation Distributors. See your yellow pages - under Engines, Diesel.

Detroit Diesel®, DDC® and the spinning arrows design are registered trademarks of Detroit Diesel Corporation.  
DDEC® is a registered trademark of Detroit Diesel Corporation.  
All information subject to change without notice.  
6SE497 0006 Copyright © 2000 DETROIT DIESEL CORPORATION. All rights reserved.

Printed in U.S.A.

---

**CALIFORNIA**  
**Proposition 65 Warning**

**Diesel engine exhaust and some of its  
constituents are known to the State of  
California to cause cancer, birth  
defects, and other reproductive harm.**

## ENGINE EXHAUST

Consider the following before servicing engines:



### CAUTION:

**To avoid injury from inhaling engine exhaust, always operate the engine in a well-ventilated area. Engine exhaust is toxic.**

Please note this caution and remember:

- ☐ Always start and operate the engine in a well-ventilated area.
- ☐ If in an enclosed area, vent the exhaust to the outside.
- ☐ Do not modify or tamper with the exhaust system.





# TABLE OF CONTENTS

<b>1</b>	<b>INTRODUCTION</b>	
1.1	INTRODUCTION .....	1- 3
1.2	TROUBLESHOOTING INFORMATION .....	1- 4
<b>2</b>	<b>OPERATION</b>	
2.1	DDEC BENEFITS .....	2- 3
2.2	FEATURES .....	2- 4
2.3	DDEC SYSTEM--HOW IT WORKS .....	2- 5
2.4	DDEC RELATED PUBLICATIONS .....	2-18
<b>3</b>	<b>ECM AND SENSOR LOCATIONS</b>	
3.1	ECM AND SENSOR LOCATIONS .....	3- 3
<b>4</b>	<b>BASIC KNOWLEDGE REQUIRED</b>	
4.1	DDEC DIAGNOSTIC CODE .....	4- 3
4.2	GENERAL DIAGNOSTIC INFORMATION .....	4- 4
4.3	READING CODES WITH DIAGNOSTIC DATA READER .....	4- 5
4.4	ELECTRICAL CIRCUITS .....	4- 8
4.5	USE OF DIGITAL VOLT-OHM METER .....	4- 9
4.6	IMPORTANT INFORMATION .....	4-11
4.7	EXPLANATION OF ABBREVIATIONS AND TERMS .....	4-12
<b>5</b>	<b>FLASH CODES VS SAE CODES</b>	
5.1	READING THE DIAGNOSTIC CODES - FLASH METHOD .....	5- 3
5.2	READING CODES .....	5- 5
5.3	DDEC DESCRIPTIONS .....	5- 6
<b>6</b>	<b>TESTING / SERVICE TOOLS / TIPS</b>	
6.1	BASICS .....	6- 3
6.2	OPERATOR INFORMATION .....	6- 5
6.3	SERVICE TOOLS .....	6- 7
<b>7</b>	<b>DDEC ECM SOFTWARE FEATURES</b>	
7.1	DDEC ECM SOFTWARE FEATURES .....	7- 3
7.2	DDEC FEATURE SUMMARY .....	7-15
<b>8</b>	<b>CONNECTORS, TERMINALS, AND SPLICING</b>	
8.1	CRIMP AND REMOVAL TOOLS .....	8- 3
8.2	METRI-PACK 150 CONNECTORS .....	8- 4
8.3	WEATHER PACK AND METRI-PACK 280 CONNECTORS .....	8-11
8.4	DEUTSCH CONNECTORS .....	8-18
8.5	SPLICING GUIDELINES .....	8-23
8.6	STRAIGHT LEADS .....	8-24
8.7	SOLDER .....	8-25
8.8	SHRINK WRAP .....	8-25
8.9	MULTIPLE BROKEN WIRES .....	8-26

8.10	THREE-WIRE SPLICE .....	8-27
<b>9</b>	<b>DIAGNOSING A DDEC SYSTEM FAULT</b>	
9.1	FIRST STEP FOR DIAGNOSING A FAULT WITHIN THE DDEC SYSTEM .....	9- 3
<b>10</b>	<b>INTERMITTENT FAULT</b>	
10.1	INTERMITTENT CODE OR A SYMPTOM AND NO CODES .....	10- 3
10.2	ENGINE CRANKS BUT WILL NOT START .....	10- 4
10.3	ERRATIC PERFORMANCE AND NO CODES .....	10-20
10.4	CHECK ENGINE LIGHT AND STOP ENGINE LIGHT FAULT .....	10-21
10.5	NO DATA TO DIAGNOSTIC DATA READER .....	10-24
10.6	DIAGNOSTIC REQUEST SWITCH INOPERATIVE .....	10-29
10.7	CRUISE CONTROL INOPERATIVE .....	10-31
10.8	FAN OPERATIONAL CONCERN (ON/OFF TYPE) .....	10-40
10.9	FAN OPERATIONAL CONCERN (VARIABLE SPEED TYPE) .....	10-46
10.10	ENGINE BRAKE INOPERATIVE .....	10-50
10.11	MISCELLANEOUS DIGITAL INPUT FAULT .....	10-55
10.12	MISCELLANEOUS DIGITAL OUTPUT FAULT .....	10-58
10.13	FIRE TRUCK PRESSURE GOVERNOR FAULT .....	10-61
10.14	OPTIMIZED IDLE FEATURE DOES NOT FUNCTION .....	10-72
10.15	TRANSMISSION INTERFACE FAULT .....	10-78
<b>11</b>	<b>FLASH CODE 11 - VSG LOW</b>	
11.1	DESCRIPTION OF FLASH CODE 11 .....	11- 3
11.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 11 .....	11- 3
11.3	TROUBLESHOOTING FLASH CODE 11 .....	11- 4
<b>12</b>	<b>FLASH CODE 12 - VSG HIGH</b>	
12.1	DESCRIPTION OF FLASH CODE 12 .....	12- 3
12.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 12 .....	12- 3
12.3	TROUBLESHOOTING FLASH CODE 12 .....	12- 4
<b>13</b>	<b>FLASH CODE 13 - CLS LOW</b>	
13.1	DESCRIPTION OF FLASH CODE 13 .....	13- 3
13.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 13 .....	13- 3
13.3	TROUBLESHOOTING FLASH CODE 13 .....	13- 4
<b>14</b>	<b>FLASH CODE 14 - TEMP SENSOR HIGH</b>	
14.1	DESCRIPTION OF FLASH CODE 14 .....	14- 3
14.2	SAE J1587 EQUIVALENT CODES FOR FLASH CODE 14 .....	14- 3
14.3	TROUBLESHOOTING FLASH CODE 14 .....	14- 4
<b>15</b>	<b>FLASH CODE 15 - TEMP SENSOR LOW</b>	
15.1	DESCRIPTION OF FLASH CODE 15 .....	15- 3
15.2	SAE J1587 EQUIVALENT CODES FOR FLASH CODE 15 .....	15- 3
15.3	TROUBLESHOOTING FLASH CODE 15 .....	15- 4
<b>16</b>	<b>FLASH CODE 16 - CLS HIGH</b>	
16.1	DESCRIPTION OF FLASH CODE 16 .....	16- 3
16.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 16 .....	16- 3

16.3	TROUBLESHOOTING FLASH CODE 16 .....	16- 4
<b>17</b>	<b>FLASH CODE 17 - THROTTLE VALVE HIGH</b>	
17.1	DESCRIPTION OF FLASH CODE 17 .....	17- 3
17.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 17 .....	17- 3
17.3	TROUBLESHOOTING FLASH CODE 17 .....	17- 4
<b>18</b>	<b>FLASH CODE 18 - THROTTLE VALVE LOW</b>	
18.1	DESCRIPTION OF FLASH CODE 18 .....	18- 3
18.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 18 .....	18- 3
18.3	TROUBLESHOOTING FLASH CODE 18 .....	18- 4
<b>19</b>	<b>FLASH CODE 19</b>	
19.1	DESCRIPTION OF FLASH CODE 19 .....	19- 3
<b>20</b>	<b>FLASH CODE 20</b>	
20.1	DESCRIPTION OF FLASH CODE 20 .....	20- 3
<b>21</b>	<b>FLASH CODE 21 - TPS HIGH</b>	
21.1	DESCRIPTION OF FLASH CODE 21 .....	21- 3
21.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 21 .....	21- 3
21.3	TROUBLESHOOTING FLASH CODE 21 .....	21- 4
<b>22</b>	<b>FLASH CODE 22 - TPS LOW</b>	
22.1	DESCRIPTION OF FLASH CODE 22 .....	22- 3
22.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 22 .....	22- 3
22.3	TROUBLESHOOTING FLASH CODE 22 .....	22- 4
<b>23</b>	<b>FLASH CODE 23 - FUEL TEMP SENSOR HIGH</b>	
23.1	DESCRIPTION OF FLASH CODE 23 .....	23- 3
23.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 23 .....	23- 3
23.3	TROUBLESHOOTING FLASH CODE 23 .....	23- 4
<b>24</b>	<b>FLASH CODE 24 - FUEL TEMP SENSOR LOW</b>	
24.1	DESCRIPTION OF FLASH CODE 24 .....	24- 3
24.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 24 .....	24- 3
24.3	TROUBLESHOOTING FLASH CODE 24 .....	24- 4
<b>25</b>	<b>FLASH CODE 25</b>	
25.1	DESCRIPTION OF FLASH CODE 25 .....	25- 3
<b>26</b>	<b>FLASH CODE 26 - AUXILIARY INPUT ACTIVE</b>	
26.1	DESCRIPTION OF FLASH CODE 26 .....	26- 3
26.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 26 .....	26- 3
26.3	TROUBLESHOOTING FLASH CODE 26 .....	26- 4
<b>27</b>	<b>FLASH CODE 27 - AIR TEMP SENSOR HIGH</b>	
27.1	DESCRIPTION OF FLASH CODE 27 .....	27- 3
27.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 27 .....	27- 3
27.3	TROUBLESHOOTING FLASH CODE 27 .....	27- 4
<b>28</b>	<b>FLASH CODE 28 - AIR TEMP SENSOR LOW</b>	
28.1	DESCRIPTION OF FLASH CODE 28 .....	28- 3
28.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 28 .....	28- 3

28.3	TRUBLESHOOTING FLASH CODE 28 .....	28- 4
<b>29</b>	<b>FLASH CODE 29</b>	
29.1	DESCRIPTION OF FLASH CODE 29 .....	29- 3
<b>30</b>	<b>FLASH CODE 30</b>	
30.1	DESCRIPTION OF FLASH CODE 30 .....	30- 3
<b>31</b>	<b>FLASH CODE 31 - ENGINE BRAKE FAULT CODE</b>	
31.1	DESCRIPTION OF FLASH CODE 31 .....	31- 3
31.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 31 .....	31- 3
31.3	TRUBLESHOOTING FLASH CODE 31 .....	31- 4
<b>32</b>	<b>FLASH CODE 32 - CEL / SEL FAULT</b>	
32.1	DESCRIPTION OF FLASH CODE 32 .....	32- 3
32.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 32 .....	32- 3
32.3	TRUBLESHOOTING FLASH CODE 32 .....	32- 4
<b>33</b>	<b>FLASH CODE 33 - TBS HIGH</b>	
33.1	DESCRIPTION OF FLASH CODE 33 .....	33- 3
33.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 33 .....	33- 3
33.3	TRUBLESHOOTING FLASH CODE 33 .....	33- 4
<b>34</b>	<b>FLASH CODE 34 - TBS LOW</b>	
34.1	DESCRIPTION OF FLASH CODE 34 .....	34- 3
34.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 34 .....	34- 3
34.3	TRUBLESHOOTING FLASH CODE 34 .....	34- 4
<b>35</b>	<b>FLASH CODE 35 - OPS HIGH</b>	
35.1	DESCRIPTION OF FLASH CODE 35 .....	35- 3
35.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 35 .....	35- 3
35.3	TRUBLESHOOTING FLASH CODE 35 .....	35- 4
<b>36</b>	<b>FLASH CODE 36 - OPS LOW</b>	
36.1	DESCRIPTION OF FLASH CODE 36 .....	36- 3
36.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 36 .....	36- 3
36.3	TRUBLESHOOTING FLASH CODE 36 .....	36- 4
<b>37</b>	<b>FLASH CODE 37 - FPS HIGH</b>	
37.1	DESCRIPTION OF FLASH CODE 37 .....	37- 3
37.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 37 .....	37- 3
37.3	TRUBLESHOOTING FLASH CODE 37 .....	37- 4
<b>38</b>	<b>FLASH CODE 38 - FPS LOW</b>	
38.1	DESCRIPTION OF FLASH CODE 38 .....	38- 3
38.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 38 .....	38- 3
38.3	TRUBLESHOOTING FLASH CODE 38 .....	38- 4
<b>39</b>	<b>FLASH CODE 39</b>	
39.1	DESCRIPTION OF FLASH CODE 39 .....	39- 3
<b>40</b>	<b>FLASH CODE 40</b>	
40.1	DESCRIPTION OF FLASH CODE 40 .....	40- 3

<b>41</b>	<b>FLASH CODE 41 - TOO MANY SRS</b>	
41.1	DESCRIPTION OF FLASH CODE 41 .....	41- 3
41.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 41 .....	41- 3
41.3	TROUBLESHOOTING FLASH CODE 41 .....	41- 4
<b>42</b>	<b>FLASH CODE 42 - TOO FEW SRS</b>	
42.1	DESCRIPTION OF FLASH CODE 42 .....	42- 3
42.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 42 .....	42- 3
42.3	TROUBLESHOOTING FLASH CODE 42 .....	42- 4
<b>43</b>	<b>FLASH CODE 43 - COOLANT LEVEL LOW</b>	
43.1	DESCRIPTION OF FLASH CODE 43 .....	43- 3
43.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 43 .....	43- 3
43.3	TROUBLESHOOTING FLASH CODE 43 .....	43- 4
<b>44</b>	<b>FLASH CODE 44 - TEMP HIGH</b>	
44.1	DESCRIPTION OF FLASH CODE 44 .....	44- 3
44.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 44 .....	44- 3
44.3	TROUBLESHOOTING FLASH CODE 44 .....	44- 4
<b>45</b>	<b>FLASH CODE 45 - OIL PRESSURE LOW</b>	
45.1	DESCRIPTION OF FLASH CODE 45 .....	45- 3
45.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 45 .....	45- 3
45.3	TROUBLESHOOTING FLASH CODE 45 .....	45- 4
<b>46</b>	<b>FLASH CODE 46 - BATTERY VOLTAGE LOW</b>	
46.1	DESCRIPTION OF FLASH CODE 46 .....	46- 3
46.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 46 .....	46- 3
46.3	TROUBLESHOOTING FLASH CODE 46 .....	46- 4
<b>47</b>	<b>FLASH CODE 47 - AIR / FUEL PRESSURE HIGH</b>	
47.1	DESCRIPTION OF FLASH CODE 47 .....	47- 3
47.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 47 .....	47- 3
47.3	TROUBLESHOOTING FLASH CODE 47 .....	47- 3
<b>48</b>	<b>FLASH CODE 48 - AIR / FUEL PRESSURE LOW</b>	
48.1	DESCRIPTION OF FLASH CODE 48 .....	48- 3
48.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 48 .....	48- 3
48.3	TROUBLESHOOTING FLASH CODE 48 .....	48- 3
<b>49</b>	<b>FLASH CODE 49</b>	
49.1	DESCRIPTION OF FLASH CODE 49 .....	49- 3
<b>50</b>	<b>FLASH CODE 50</b>	
50.1	DESCRIPTION OF FLASH CODE 50 .....	50- 3
<b>51</b>	<b>FLASH CODE 51</b>	
51.1	DESCRIPTION OF FLASH CODE 51 .....	51- 3
<b>52</b>	<b>FLASH CODE 52 - ECM FAULT</b>	
52.1	DESCRIPTION OF FLASH CODE 52 .....	52- 3
52.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 52 .....	52- 3
52.3	TROUBLESHOOTING FLASH CODE 52 .....	52- 3

<b>53</b>	<b>FLASH CODE 53 - ECM MEMORY FAULT</b>	
53.1	DESCRIPTION OF FLASH CODE 53 .....	53- 3
53.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 53 .....	53- 3
53.3	TROUBLESHOOTING FLASH CODE 53 .....	53- 3
<b>54</b>	<b>FLASH CODE 54 - VSS FAULT</b>	
54.1	DESCRIPTION OF FLASH CODE 54 .....	54- 3
54.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 54 .....	54- 3
54.3	TROUBLESHOOTING FLASH CODE 54 .....	54- 3
<b>55</b>	<b>FLASH CODE 55 - J1939 DATA LINK FAULT</b>	
55.1	DESCRIPTION OF FLASH CODE 55 .....	55- 3
55.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 55 .....	55- 3
55.3	TROUBLESHOOTING FLASH CODE 55 .....	55- 3
<b>56</b>	<b>FLASH CODE 56 - J1587 DATA LINK FAULT</b>	
56.1	DESCRIPTION OF FLASH CODE 56 .....	56- 3
56.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 56 .....	56- 3
56.3	TROUBLESHOOTING FLASH CODE 56 .....	56- 4
<b>57</b>	<b>FLASH CODE 57 - J1922 DATA LINK FAULT</b>	
57.1	DESCRIPTION OF FLASH CODE 57 .....	57- 3
57.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 57 .....	57- 3
57.3	TROUBLESHOOTING FLASH CODE 57 .....	57- 4
<b>58</b>	<b>FLASH CODE 58</b>	
58.1	DESCRIPTION OF FLASH CODE 58 .....	58- 3
58.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 58 .....	58- 3
<b>59</b>	<b>FLASH CODE 59</b>	
59.1	DESCRIPTION OF FLASH CODE 59 .....	59- 3
<b>60</b>	<b>FLASH CODE 60</b>	
60.1	DESCRIPTION OF FLASH CODE 60 .....	60- 3
<b>61</b>	<b>FLASH CODE 61 - INJECTOR RESPONSE LONG</b>	
61.1	DESCRIPTION OF FLASH CODE 61 .....	61- 3
61.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 61 .....	61- 3
61.3	TROUBLESHOOTING FLASH CODE 61 .....	61- 4
<b>62</b>	<b>FLASH CODE 62 - OUTPUT FAULT</b>	
62.1	DESCRIPTION OF FLASH CODE 62 .....	62- 3
62.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 62 .....	62- 3
62.3	TROUBLESHOOTING FLASH CODE 62 .....	62- 4
<b>63</b>	<b>FLASH CODE 63 - PWM FAULT</b>	
63.1	DESCRIPTION OF FLASH CODE 63 .....	63- 3
63.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 63 .....	63- 3
63.3	TROUBLESHOOTING FLASH CODE 63 .....	63- 4
<b>64</b>	<b>FLASH CODE 64</b>	
64.1	DESCRIPTION OF FLASH CODE 64 .....	64- 3
64.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 64 .....	64- 3

<b>65</b>	<b>FLASH CODE 65 - THROTTLE VALVE FAULT</b>	
65.1	DESCRIPTION OF FLASH CODE 65 .....	65- 3
65.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 65 .....	65- 3
65.3	TROUBLESHOOTING FLASH CODE 65 .....	65- 4
<b>66</b>	<b>FLASH CODE 66 - KNOCK SENSOR FAULT</b>	
66.1	DESCRIPTION OF FLASH CODE 66 .....	66- 3
66.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 66 .....	66- 3
66.3	TROUBLESHOOTING FLASH CODE 66 .....	66- 4
<b>67</b>	<b>FLASH CODE 67 - MAP SENSOR FAULT</b>	
67.1	DESCRIPTION OF FLASH CODE 67 .....	67- 3
67.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 67 .....	67- 3
67.3	TROUBLESHOOTING FLASH CODE 67 .....	67- 3
<b>68</b>	<b>FLASH CODE 68 - IDLE VALIDATION FAULT</b>	
68.1	DESCRIPTION OF FLASH CODE 68 .....	68- 3
68.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 68 .....	68- 3
68.3	TROUBLESHOOTING FLASH CODE 68 .....	68- 4
<b>69</b>	<b>FLASH CODE 69</b>	
69.1	DESCRIPTION OF FLASH CODE 69 .....	69- 3
<b>70</b>	<b>FLASH CODE 70</b>	
70.1	DESCRIPTION OF FLASH CODE 70 .....	70- 3
<b>71</b>	<b>FLASH CODE 71 - INJECTOR RESPONSE SHORT</b>	
71.1	DESCRIPTION OF FLASH CODE 71 .....	71- 3
71.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 71 .....	71- 3
71.3	TROUBLESHOOTING FLASH CODE 71 .....	71- 4
<b>72</b>	<b>FLASH CODE 72 - VEHICLE OVERSPEED</b>	
72.1	DESCRIPTION OF FLASH CODE 72 .....	72- 3
72.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 72 .....	72- 3
72.3	TROUBLESHOOTING FLASH CODE 72 .....	72- 4
<b>73</b>	<b>FLASH CODE 73 — ESS FAULT</b>	
73.1	DESCRIPTION OF FLASH CODE 73 .....	73- 3
73.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 73 .....	73- 3
73.3	TROUBLESHOOTING FLASH CODE 73 .....	73- 4
<b>74</b>	<b>FLASH CODE 74 — OI SAFETY LOOP</b>	
74.1	DESCRIPTION OF FLASH CODE 74 .....	74- 3
74.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 74 .....	74- 3
74.3	TROUBLESHOOTING FLASH CODE 74 .....	74- 4
<b>75</b>	<b>FLASH CODE 75 - BATTERY VOLT HIGH</b>	
75.1	DESCRIPTION OF FLASH CODE 75 .....	75- 3
75.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 75 .....	75- 3
75.3	TROUBLESHOOTING FLASH CODE 75 .....	75- 3
<b>76</b>	<b>FLASH CODE 76 - ENGINE OVERSPEED / BRAKE</b>	
76.1	DESCRIPTION OF FLASH CODE 76 .....	76- 3



76.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 76 .....	76- 3
76.3	TROUBLESHOOTING FLASH CODE 76 .....	76- 3
<b>77</b>	<b>FLASH CODE 77 - FUEL TEMP HIGH</b>	
77.1	DESCRIPTION OF FLASH CODE 77 .....	77- 3
77.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 77 .....	77- 3
77.3	TROUBLESHOOTING FLASH CODE 77 .....	77- 3
<b>78</b>	<b>FLASH CODE 78</b>	
78.1	DESCRIPTION OF FLASH CODE 78 .....	78- 3
<b>79</b>	<b>FLASH CODE 79</b>	
79.1	DESCRIPTION OF FLASH CODE 79 .....	79- 3
<b>80</b>	<b>FLASH CODE 80</b>	
80.1	DESCRIPTION OF FLASH CODE 80 .....	80- 3
<b>81</b>	<b>FLASH CODE 81</b>	
81.1	DESCRIPTION OF FLASH CODE 81 .....	81- 3
81.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 81 .....	81- 3
<b>82</b>	<b>FLASH CODE 82</b>	
82.1	DESCRIPTION OF FLASH CODE 82 .....	82- 3
82.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 82 .....	82- 3
<b>83</b>	<b>FLASH CODE 83</b>	
83.1	DESCRIPTION OF FLASH CODE 83 .....	83- 3
83.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 83 .....	83- 3
<b>84</b>	<b>FLASH CODE 84</b>	
84.1	DESCRIPTION OF FLASH CODE 84 .....	84- 3
84.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 84 .....	84- 3
<b>85</b>	<b>FLASH CODE 85 - ENGINE OVERSPEED</b>	
85.1	DESCRIPTION OF FLASH CODE 85 .....	85- 3
85.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 85 .....	85- 3
85.3	TROUBLESHOOTING FLASH CODE 85 .....	85- 3
<b>86</b>	<b>FLASH CODE 86 - PGS SENSOR HIGH</b>	
86.1	DESCRIPTION OF FLASH CODE 86 .....	86- 3
86.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 86 .....	86- 3
86.3	TROUBLESHOOTING FLASH CODE 86 .....	86- 4
<b>87</b>	<b>FLASH CODE 87 - PGS SENSOR LOW</b>	
87.1	DESCRIPTION OF FLASH CODE 87 .....	87- 3
87.2	SAE J1587 EQUIVALENT CODE FOR FLASH CODE 87 .....	87- 3
87.3	TROUBLESHOOTING FLASH CODE 87 .....	87- 3
<b>88</b>	<b>FLASH CODE 88</b>	
88.1	DESCRIPTION OF FLASH CODE 88 .....	88- 3
<b>89</b>	<b>FLASH CODE 89</b>	
89.1	DESCRIPTION OF FLASH CODE 89 .....	89- 3

<b>90</b>	<b>ENGINE SENSOR HARNESS</b>	
90.1	DESCRIPTION OF ENGINE SENSOR HARNESS .....	90- 3
90.2	TROUBLESHOOTING ENGINE SENSOR HARNESS .....	90- 3
<b>91</b>	<b>VEHICLE HARNESS</b>	
91.1	DESCRIPTION OF VEHICLE HARNESS +5 VOLT SUPPLY .....	91- 3
91.2	TROUBLESHOOTING VEHICLE HARNESS +5 VOLT SUPPLY .....	91- 3
<b>92</b>	<b>ENGINE WIRING SCHEMATICS</b>	
92.1	INJECTOR HARNESS WIRING SCHEMATIC - SERIES 50 ENGINES WITH JAKE BRAKE .....	92- 3
92.2	INJECTOR HARNESS WIRING SCHEMATIC - SERIES 60 ENGINES ..	92- 4
92.3	INJECTOR HARNESS WIRING SCHEMATIC - SERIES 6V92 ENGINES .....	92- 6
92.4	INJECTOR HARNESS WIRING SCHEMATIC - SERIES 8V92 AND 8V149 ENGINES .....	92- 7
92.5	INTERNAL ENGINE BRAKE FOR ECM/WORLD TRANSMISSION INTERFACE .....	92- 8
92.6	INTERNAL ENGINE BRAKE FOR DDEC SYSTEM ECM .....	92-11
92.7	ENGINE HARNESS .....	92-13
<b>93</b>	<b>VEHICLE WIRING SCHEMATICS</b>	
93.1	VEHICLE INTERFACE HARNESS .....	93- 3
93.2	PRESSURE GOVERNOR SYSTEM - VEHICLE INTERFACE HARNESS CONNECTOR .....	93-12
93.3	ELECTRONIC FIRE COMMANDER HARNESS .....	93-13
93.4	POWER HARNESS - SINGLE ECM, SINGLE FUSE .....	93-14
93.5	POWER HARNESS - SINGLE ECM, DUAL FUSES .....	93-15
93.6	DDEC DIGITAL OUTPUT .....	93-16
93.7	COMMUNICATION HARNESS .....	93-17
<b>94</b>	<b>DDEC PRO-LINK OPERATION</b>	
94.1	DDEC PRO-LINK OPERATION .....	94- 3

## ABSTRACT

This manual provides instruction for troubleshooting the Detroit Diesel Electronic Controlled (DDEC® ) engines, with one (single) ECM.

Specifically covered in this manual are troubleshooting and repair steps that apply to the DDEC III and DDEC IV systems.

## **SAFETY INSTRUCTIONS**

To reduce the chance of personal injury and/or property damage, the instructions contained in this Troubleshooting Manual must be carefully observed. Proper service and repair are important to the safety of the service technician and the safe, reliable operation of the engine.


If part replacement is necessary, the part must be replaced with one of the same part number or with an equivalent part number. Do not use a replacement part of lesser quality. The service procedures recommended and described in this manual are effective methods of performing repair. Some of these procedures require the use of specially designed tools. Accordingly, anyone who intends to use a replacement part, procedure or tool which is not recommended, must first determine that neither personal safety nor the safe operation of the engine will be jeopardized by the replacement part, procedure or tool selected.

It is important to note that this manual contains various "Cautions" and "Notices" that must be carefully observed in order to reduce the risk of personal injury during repair, or the possibility that improper repair may damage the engine or render it unsafe. It is also important to understand that these "Cautions" and "Notices" are not exhaustive, because it is impossible to warn personnel of the possible hazardous consequences that might result from failure to follow these instructions.


## REVISION NOTIFICATION

Modifications to this manual are announced in the form of Service Information Bulletins. The bulletins include attachment pages and are posted on the World Wide Web. ([www.detroitdiesel.com/svc/sibinex.htm](http://www.detroitdiesel.com/svc/sibinex.htm)).

Revisions to this manual will be sent marked with a revision bar (see Example 2). Sections containing revisions will have added information in the page footer (compare Examples 1 and 2).



Example 1 - Unchanged Pages



Example 2 - Changed Pages

---

# 1 INTRODUCTION

Section	Page
1.1 INTRODUCTION .....	1- 3
1.2 TROUBLESHOOTING INFORMATION .....	1- 4



## 1.1 INTRODUCTION

Detroit Diesel Corporation is the world leader in diesel engine electronics. DDC has made technological leaps in engine performance and fuel economy. Today, we build the most dependable electronically controlled diesel engine in the industry.

Our goal at Detroit Diesel is to be the most customer focused and most responsive engine manufacturer in the world.



## 1.2 TROUBLESHOOTING INFORMATION

Troubleshooting of the DDEC III system and the DDEC IV system is identical. At the time of this printing, the available features are the same in both systems. The DDEC IV system allows for an increased processor speed and increased memory. DDEC III ECMs and DDEC IV ECMs are not interchangeable.

Instructions for repair in this manual are generic. For example, "Repair Open" is used to advise the technician that a particular wire has been determined to be broken. In some cases it may not be best to try and locate the open. It may be that the best repair technique is to replace a complete harness. The technician should make the determination of the proper repair, with the best interest of the customer in mind.

Instructions to "Contact Detroit Diesel Technical Service" indicate that at the time of this publication, all known troubleshooting checks have been included. Review any recent Service Information Bulletins (SIB) or Service Information letters before calling.

It is also suggested that other DDC outlets be contacted. e.g. if you are a dealer or user, contact your closest DDC Distributor.

Ensure you have the engine serial number when you call. The FAX number for Detroit Diesel Technical Service is 313-592-7888.

Instructions in this manual may suggest replacing a non DDC component. It may be required to contact the supplier of the component, e.g. truck manufacturer for a TPS concern, to obtain approval to replace the component.

Instructions to check terminals and connectors should include checking for proper contact tension. Using a mating terminal, a modest force should be required to remove a terminal from its mate. Replace terminals with poor tension.

After completing any repair, always clear fault codes that may have been generated during the troubleshooting process.

### ***Important:***

To ensure you receive updates to this manual should the need arise, you must fill out the Information Card in the front of this manual.

### **NOTE:**

Be aware that troubleshooting in this manual is mostly concerned with DDEC related codes. Codes associated with other components, e.g. construction and industrial, EDM and AIM, can be found in the related publication. Refer to section 2.4.

---

## 2 OPERATION

Section	Page
2.1 DDEC BENEFITS .....	2- 3
2.2 FEATURES .....	2- 4
2.3 DDEC SYSTEM--HOW IT WORKS .....	2- 5
2.4 DDEC RELATED PUBLICATIONS .....	2-18

---



## 2.1 DDEC BENEFITS

All Detroit Diesel On-Highway engines come standard with Detroit Diesel Electronic Controls (DDEC®). The state of the art Electronic Control Module (ECM) allows precise control of the engine management system that provides:

- ☐ Excellent engine performance
- ☐ Optimum fuel economy
- ☐ Emissions to meet current laws without after treatment
- ☐ Engine diagnostics
- ☐ Simple programming

## 2.2 FEATURES

The following features are part of the DDEC system:

- ☐ Engine Protection System
- ☐ Cruise Control
- ☐ Cruise Power
- ☐ Cruise Control Automatic Resume
- ☐ Progressive Engine Braking In Cruise Control
- ☐ Fan Controls
- ☐ Engine Fan Braking
- ☐ Progressive Shifting
- ☐ Vehicle Speed Limiting
- ☐ Vehicle Overspeed Diagnostics
- ☐ Vehicle ID Number
- ☐ Pressure Governor
- ☐ Starter Lockout
- ☐ Remote Throttle - PTO - Control
- ☐ High Idle Controls
- ☐ DDEC Ether Start
- ☐ Optimized Idle
- ☐ Idle Adjustment
- ☐ Idle Timer Shutdown
- ☐ Air Temperature Shutdown
- ☐ Auxiliary Engine Protection
- ☐ Customer Password
- ☐ Rating Security
- ☐ Maximum Security
- ☐ Low DDEC Voltage Light
- ☐ Low Coolant Light
- ☐ Low Oil Pressure Light
- ☐ High Oil Temperature Light
- ☐ High Coolant Temperature Light
- ☐ De-acceleration Light
- ☐ 12-volt or 24-volt ECM
- ☐ Communications Links SAE J1587, J1922, J1939

## 2.3 DDEC SYSTEM—HOW IT WORKS

The major components of the DDEC system consist of the electronic control module (ECM), the electronic unit injectors (EUI) and the various system sensors. The purpose of the sensors is to provide information to the ECM regarding various engine performance characteristics. The information sent to the ECM is used to instantaneously regulate engine and vehicle performance.

### 2.3.1 Electronic Unit Injector

An electronic unit injector incorporates a solenoid operated poppet valve which performs the injection timing and metering functions. When the solenoid valve is closed, pressurization and fuel injection is initiated. Opening the solenoid valve releases injection pressure, ending injection. The duration of valve closure determines the quantity of fuel injected. See Figure 2-1.





Figure 2-1 Electronic Unit Injector

### 2.3.2 Electrical Connectors

Provide water-tight connections for the harnesses between the sensors and the ECM.

### 2.3.3 Air Temperature Sensor


The air temperature sensor is located in the air intake manifold and monitors the air temperature entering the engine. The ECM adjusts the engine timing to reduce white smoke, improve cold starts, and provide engine protection. See Figure 2-2.



**Figure 2-2**      **Air Temperature Sensor**

### 2.3.4 Coolant Temperature Sensor

The coolant temperature sensor is located on the right side of the engine. The engine protection feature will be triggered if the coolant temperature exceeds the specified limits. See Figure 2-3.




**Figure 2-3**      **Coolant Temperature Sensor**



### 2.3.5 Fire Truck Pump Pressure Sensor


The fire truck pump pressure sensor is used to monitor water pressure for the Pressure Governor System in the DDEC system. The signal back to the ECM changes r/min which allows the fire truck water pump to maintain a steady water pressure during pumping operation in fire trucks. See Figure 2-4.



**Figure 2-4** Fire Truck Pump Pressure Sensor

### 2.3.6 The Synchronous Reference Sensor and Timing Reference Sensor

These sensors control the timing of the engine. The SRS sensor provides a "once per cam revolution" signal and the TRS sensor provides a "36 per crankshaft revolution" signal. Working together, these sensors tell the ECM which cylinder is at top-dead-center for cylinder firing. Precise monitoring of piston position allows for optimum injection timing, resulting in excellent fuel economy and performance with low emissions. See Figure 2-5 for the SRS and the TRS.




**Figure 2-5** Timing Reference Sensor and Synchronous Reference Sensor

### 2.3.7 Oil and Fuel Temperature Sensors

The oil temperature sensor optimizes idle speed and injection timing to improve cold startability and reduce white smoke. This sensor will activate the engine protection system if the oil temperature is higher than normal.


The fuel temperature sensor provides a signal to the ECM. The ECM utilizes the fuel temperature signal to adjust the fueling for changes in the fuel density as a function of temperature to maintain horsepower. See Figure 2-6.



**Figure 2-6 Oil and Fuel Temperature Sensors**

### 2.3.8 Electronic Control Module


The ECM is the brain of the computer system, receiving electronic inputs from the operator as well as from the engine and vehicle mounted sensors. See Figure 2-7.



**Figure 2-7 Electronic Control Module**

### 2.3.9 Coolant Level Sensor


The engine protection feature will be triggered if the coolant level sensor detects a low coolant level. See Figure 2-8.



**Figure 2-8**      **Coolant Level Sensor**

### 2.3.10 Throttle Position Sensor


The electronic foot pedal assembly instantaneously converts the operator's throttle input into a signal to the ECM. The throttle response is fast and accurate. This sensor is self-calibrated, and requires no maintenance. See Figure 2-9.



**Figure 2-9 Throttle Position Sensor**

### 2.3.11 Vehicle Speed Sensor


The vehicle speed sensor provides the ECM with the vehicle road speed for use with cruise control, vehicle speed limiting, and progressive shifting. See Figure 2-10.



**Figure 2-10**      **Vehicle Speed Sensor**

### 2.3.12 Turbo Boost Sensor

In monitoring turbocharger compressor discharge, the turbo boost sensor provides air pressure data to the ECM for smoke control during engine acceleration. See Figure 2-11.




**Figure 2-11 Turbo Boost Sensor**



### 2.3.13 Oil Pressure Sensor


The oil pressure sensor will activate the engine protection system when the oil pressure falls below a normal oil pressure at a given engine r/min. See Figure 2-12.



**Figure 2-12**      **Oil Pressure Sensor**

### 2.3.14 Fuel Pressure Sensor

The fuel pressure sensor monitors fuel pressure to warn the operator of impending power loss. This feature is optional. It is not used in international applications. See Figure 2-13.



**Figure 2-13 Fuel Pressure Sensor**

## 2.4 DDEC RELATED PUBLICATIONS

The following manuals, listed in Table 2-1, should be used for reference when troubleshooting DDEC components.

Publication	Number
DDEC III/IV Application and Installation manual	7SA800
Optimized Idle Installation and Troubleshooting	7SA741
Optimized Idle User Manual	6SE518
Optimized Idle Troubleshooting and Reprogramming	18SA366
Engine Synchro Shift (ESS) Troubleshooting Manual	6SE498
Construction and Industrial EDM and AIM Installation and Troubleshooting	7SA801
Construction and Industrial EDM and AIM User Manual	6SE710
DDC Ether Start	7SA727
Series 50G Application and Installation Engineering Guidelines, Bulletin 53	18SA365
DDEC III Automotive Code Chart, 3 color, 8.5 x 11	7SE444
DDEC III Codes, Reference Pamphlet	7SE414
DDEC II Troubleshooting Manual	6SE489
DDEC II Application and Installation manual	7SA707
Series 60 Driving Tips (includes VHS video)	25STV0161

**Table 2-1 DDEC Related Publications**

---


## 3 ECM AND SENSOR LOCATIONS

Section	Page
3.1 ECM AND SENSOR LOCATIONS .....	3- 3




### 3.1 ECM AND SENSOR LOCATIONS

For the DDEC system ECM see Figure 3-1.




**Figure 3-1 DDEC System ECM**

For the Series 60® sensor locations, see Figure 3-2.



**Figure 3-2**      **Series 60 Diesel ECM and Sensor Locations**

For the Series 50® diesel engine sensor locations, see Figure 3-3.




- |                                 |                                 |
|---------------------------------|---------------------------------|
| 1. Timing Reference Sensor      | 6. Oil Temperature Sensor       |
| 2. Fuel Temperature Sensor      | 7. Oil Pressure Sensor          |
| 3. Coolant Temperature Sensor   | 8. Turbo Boost Sensor           |
| 4. Synchronous Reference Sensor | 9. Air Inlet Temperature Sensor |
| 5. ECM                          |                                 |

**Figure 3-3      Series 50 Diesel ECM and Sensor Locations**




For the Series 50® gas engine sensor locations, see Figure 3-4.



- |                                       |                                 |
|---------------------------------------|---------------------------------|
| 1. Coolant Temperature Sensor         | 6. Oil Temperature Sensor       |
| 2. Air Temperature Sensor             | 7. Oil Pressure Sensor          |
| 3. Fuel Temperature Sensor            | 8. Synchronous Reference Sensor |
| 4. Manifold Air Pressure (MAP) Sensor | 9. SNEF Module                  |
| 5. Knock Sensor                       | 10. Timing Reference Sensor     |

**Figure 3-4**      **Series 50 Gas ECM and Sensor Locations**

For the Series 55™ engine sensor locations, see Figure 3-5.



- |                                 |                                 |
|---------------------------------|---------------------------------|
| 1. Coolant Temperature Sensor   | 5. Synchronous Reference Sensor |
| 2. Fuel Temperature Sensor      | 6. Timing Reference Sensor      |
| 3. Air Inlet Temperature Sensor | 7. Oil Temperature Sensor       |
| 4. Turbo Boost Sensor           | 8. Oil Pressure Sensor          |

**Figure 3-5      Series 55 Engine Sensor Locations**



---

## 4 BASIC KNOWLEDGE REQUIRED

Section	Page
4.1 DDEC DIAGNOSTIC CODE .....	4- 3
4.2 GENERAL DIAGNOSTIC INFORMATION .....	4- 4
4.3 READING CODES WITH DIAGNOSTIC DATA READER .....	4- 5
4.4 ELECTRICAL CIRCUITS .....	4- 8
4.5 USE OF DIGITAL VOLT-OHM METER .....	4- 9
4.6 IMPORTANT INFORMATION .....	4-11
4.7 EXPLANATION OF ABBREVIATIONS AND TERMS .....	4-12

---



## 4.1 DDEC DIAGNOSTIC CODE

Troubleshooting of the DDEC III system and the DDEC IV system is identical. At the time of this printing, the available features are the same in both systems. The DDEC IV system allows for an increased processor speed and increased memory. DDEC III ECMs and DDEC IV ECMs are not interchangeable.

A diagnostic code indicates a problem in a given circuit (i.e. diagnostic Code 14 indicates a problem in the oil or coolant temperature sensor circuit). This includes the oil or coolant temperature sensor, connector, harness, and Electronic Control Module (ECM). The procedure for finding the problem can be found in Flash Code 14, refer to section 14.3. Similar sections are provided for each code. Remember, diagnosis should always begin at the start of the section. For an oil or coolant temperature sensor problem, it will quickly lead you to section 14, but first you verify the code or symptom.

Since the self-diagnostics do not detect all possible faults, the absence of a code does not mean there are not problems in the system. If a DDEC problem is suspected, even in the absence of a code, refer to section 9.1, anyway. This section can lead you to other sections that can aid in the troubleshooting process - where DDEC problems may occur, but do not generate a code. Basic mechanical checks are not covered in this manual.

## 4.2 GENERAL DIAGNOSTIC INFORMATION

As a bulb and system check, the Check Engine Light (CEL) and Stop Engine Light (SEL) will come on for five seconds when the ignition switch is first turned on. If the unit is programmed for the cruise control feature, the "Cruise Active" light (if equipped) will also turn on for five seconds.

If the CEL comes on during vehicle operation, it indicates the self diagnostic system has detected a fault.

When the diagnostic request switch is held, the diagnostic system will flash the yellow or red light located on the dash of the vehicle. The light will be flashing the code(s) indicating the problem areas. If the SEL comes on during vehicle operation, it indicates the DDEC System has detected a potential engine damaging condition. The engine should be shut down immediately and checked for the problem.

Active codes will be flashed on the SEL in numerical flash code order. If there are no active codes, a code 25 will be flashed.

Inactive codes will be flashed on the CEL in most recent to least recent order. If there are no inactive codes, a code 25 will be flashed.

### 4.3 READING CODES WITH DIAGNOSTIC DATA READER

Flash codes are used for operator convenience to advise of an engine fault or sensor failure. SAE specific codes are read with the Diagnostic Data Reader (DDR). In some cases, one flash code may be used to cover more than one component fault. For this reason the DDR (or Diagnostic Data Link, DDL) must be used to identify the specific code.

The Diagnostic Code Menu selections are defined as follows.

- ☐ Active codes
- ☐ Inactive codes
- ☐ Clear codes

To read codes, start with the Menu Selection screen.

1. To call up active codes:
  - [a] Select ENGINE and ENTER three times.
2. To call up inactive codes:
  - [a] Select ENGINE and ENTER twice.
  - [b] Select INACTIVE CODES and ENTER.
3. To clear codes:
  - [a] Select ENGINE and push ENTER twice.
  - [b] Go down and select CLEAR CODES and ENTER.
  - [c] Left to YES, and ENTER.
  - [d] Wait and then push FUNC three times.
  - [e] Go to lines 1 and 2 of the Engine Data List, Active and Inactive Codes, and verify that both lines display NO.



### 4.3.1 Active Codes

Active codes are conditions that are presently occurring and causing the CEL to be illuminated. All current active codes will be displayed for the entire system, including single, dual and triple ECM applications. The display for each code is as follows:

Line 1: ## MID: XXX XXXXXXXXX

Line 2: PID Description

Line 3: FMI Description

Line 4: ↑ A## PID: XXX FMI: XX ↓

Explanation:

##: Indicates the DDC diagnostic flash code number

MID: Message Identification Character

PID: Parameter Identification Character

FMI: Failure Mode Identifier

A##: Numerical count of active codes

↑↓: Indicates additional codes are stored in ECM memory

### 4.3.2 Inactive Codes

Inactive codes are faults that have occurred previously. All current inactive codes will be displayed for the entire system, including single, dual, and triple ECM applications. The display for each code is as follows:

SCREEN #1; SCREEN #2

Line 1: ## MID: XXX XXXXXX XX ; Line 5: 1st: Last:

Line 2: PID Description; Line 6: Total#:

Line 3: FMI Description; Line 7: Total Time:

Line 4: ↑ |## PID: XXX FMI: XX ↓; Line 8: Min/Max:

Explanation:

##: Indicates the DDC diagnostic flash code number

|##: Numerical Count of inactive codes

1st: First occurrence of the diagnostic code in engine hours

Last: Last occurrence of the diagnostic code in engine hours

Total#: Total number of occurrences

Total Time: Total engine seconds that the diagnostic code was active

Min/Max: Minimum/Maximum value recorded during diagnostic condition

### 4.3.3 Clear Codes

This feature allows diagnostic codes stored in the ECMs to be erased. An audit trail of when the codes were last erased will be displayed in engine hours.

Engine Hours of Last Clear Codes: XXXX

### 4.3.4 Message Identification Descriptions

MID: 128 ENGINE, Single ECM applications

MID: 175 ENGINE, R1 Dual ECM application - engine #2 with first receiver ECM

MID: 183 ENGINE, R2 Triple ECM application - engine #3 w/second receiver ECM

MID: 184 PING, Pilot Injection Natural Gas ECM application

Diagnostic codes with Subsystem Identification Characters (SIDs) that reference Auxiliary Outputs # 1-8 (SIDs: 26, 40, 51, 52, 53, 54, 55, 56) will look up the parameter text description in a table to identify the function assigned to the auxiliary output channel.

Diagnostic codes with SIDs that reference PWM Outputs #1 through #4 (SIDs: 57, 58, 59 & 60) will look up the parameter text description in a table to identify the function assigned to the PWM output channel.

Injector Response Time Codes Long and Injector Response Time Codes Short will use a table of injector numbering to identify the appropriate engine cylinder number.

## 4.4 ELECTRICAL CIRCUITS

Before using this manual, you should understand the theory of electricity and know the meaning of voltage and ohms. You should understand what happens in a circuit with an open or shorted wire. You should be able to read and understand a wiring diagram.

You should be able to use jumper wires to make circuit checks.

## 4.5 USE OF DIGITAL VOLT-OHM METER

Before using this manual, you should be familiar with the digital volt-ohm meter (VOM). You should be able to measure voltage and resistance. You should be familiar with the controls of the meter and how to use it correctly.

For use of a typical digital volt-ohm meter, refer to section 4.5.1, refer to section 4.5.2, and refer to section 4.5.3.

### 4.5.1 Resistance Measurements

Perform the following steps to measure resistance:

1. Connect the red test lead to the V-  $\Omega$  (Volt-Ohm) input connector and the black lead to the com input connector on the meter.
2. Set the function/range switch to the desired  $\Omega$  position. If the magnitude of the resistance is not known, set the switch to the highest range, then reduce until a satisfactory reading is obtained.
3. If the resistance being measured is connected to a circuit, turn off the power to the circuit being tested. Turn off the ignition.
4. Connect the test leads to the circuit being measured. When measuring high resistance, be careful not to contact adjacent points, even if they are insulated. Some insulators have a relatively low insulation resistance which can affect the resulting measurement.
5. Read the resistance value on the digital display.

### 4.5.2 Continuity Checks


In addition to measuring the specific resistance value of a circuit, some meters will also register if a continuous electrical path exists. If a path exists, the circuit is said to have continuity. (This continuity check can be used in any section of this troubleshooting guide where the test is looking for greater than, less than, or equal to 5 ohms.) An open circuit (broken electrical path) would have  $\infty$  resistance and would not have continuity. To utilize the continuity feature of certain meters:

1. Place the function/range switch in any  $\Omega$  range.
2. Connect the red lead to the V-  $\Omega$  connector and the black lead to the com connector on the meter. With the test leads separated or measuring an out-of-range resistance, the digital display will indicate OL (over limit) Some meters show "1 +, 1, or  $\uparrow$ ."
3. Put one test probe at one end of the wire or circuit to be tested. Use the other test lead to trace the circuit. When continuity is established, an ohm ( $\Omega$ ) symbol will display in the upper left corner of the digital display. If contact in the wire is maintained long enough (about 1/4 second), the OL will disappear and the resistance value of the wire or circuit will display next to the symbol.
4. If your VOM does not work in the manner described above, you must know how your VOM operates in order to use this troubleshooting guide.

### 4.5.3 Voltage Measurements

Perform the following steps to measure voltage.

1. Connect the red test lead to the V-  $\Omega$  connector and the black lead to the com input on the meter. If a DC-AC switch is present, ensure it is switched to the DC position.
2. Set the function range/switch to the desired volts position. If the magnitude of the voltage is not known, set the switch to a range that will be able to read most voltages seen on a vehicle. Typically, a 20V range will do. Then, reduce the range until a satisfactory reading is obtained.
3. Connect the test leads to the circuit being measured. In the DDEC system diagnostic procedures, voltage measurements are always given as being taken at pins, sockets, battery +, or ground. Following the voltage measurement point, the color test lead to be used is given in parenthesis (red is the V-  $\Omega$  connection, and black is the com connection). Example: If the procedure displays, "Take voltage reading at socket A3 (red lead) to socket C3 (black lead)", see Figure 4-1 for the hook-up.



1. Red Lead

2. Black Lead

**Figure 4-1 Voltage Measurement Hook-up**

## 4.6 IMPORTANT INFORMATION

The following items must be read and thoroughly understood before using this manual.

1. The engine and ignition should always be off before the harness connectors are disconnected or reconnected.
2. When disconnecting harness connectors, ensure the pulling force is applied to the connectors themselves and not the wires extending from them.

<b>NOTICE:</b>
To avoid damage to the harness connectors, ensure the pulling force is applied to the connections themselves and not the wires extending from them.

3. After harness connectors are reconnected to the DDEC system, the codes logged should be ignored and cleared.
4. In most all areas of repair/troubleshooting, a DDR will be required.
5. In diagnosing an intermittent problem, wiggling wires or harnesses may allow the fault to be repeated. This may allow a technician to better isolate the problem area.

## 4.7 EXPLANATION OF ABBREVIATIONS AND TERMS

The following abbreviations and terms listed in Table 4-1, will be used throughout the electrical flowcharts.

Abbreviations	Terms
A/C	Air Conditioning
ACG	Air Compressor Governor
A/D	Analog to Digital: The computer inside the ECM uses an A/D converter to convert a sensor voltage into a number with which the computer can work.
ASR	Anti-Skid Regulation: Data supplied by the ECM for use with ABS (anti-lock braking system).
ATI	Auxiliary Timed Input
ATS	Air Temperature Sensor: Monitors engine air temperature.
BAT	Battery
BOI	Beginning of Injection: The number of crank angle degrees, before top-dead-center (TDC), where the ECM is requesting the injectors be turned on.
BPS	Bypass Position Sensor
CAN	Controller Area Network: J 1939 high speed control data link.
CCM	Crankcase Monitor Sensor: Monitors crankcase pressure (currently on 149 engines only).
CCPS	Crankcase Pressure Sensor
CEL	* Check Engine Light: Typically mounted on the instrument panel. The CEL has two functions:1. It is used as a warning lamp to inform the operator of the vehicle that a fault has occurred and the unit should be taken in for service as soon as possible.2. It is used by the operator or technician to "flash out inactive trouble codes to help diagnose a problem.
CKT	Circuit
CLS	Coolant Level Sensor: Monitors coolant level at the radiator top tank or heat exchanger.
COM	Common
CPS	Coolant Pressure Sensor: Monitors coolant pressure.
CTS	Coolant Temperature Sensor: Monitors coolant temperature.
DDEC	Detroit Diesel Electronic Controls
DDEC III	Third generation Detroit Diesel Electronic Controls
DDEC IV	Fourth generation Detroit Diesel Electronic Controls
DDL	Diagnostic Data Link: The lines (wires) over which the ECM transmits information that can be read by a Diagnostic Data Reader.
DDL+	Data Link, positive side: J 1587 data link.
DDL-	Data Link, negative side: J 1587 data link.
DDR	Diagnostic Data Reader: The hand held tool used for troubleshooting the DDEC system. MPSI PRO-LINK 9000.

Abbreviations	Terms
ECM	Electronic Control Module: The controller of DDEC system. It reads the engine and vehicle inputs, sensors and switches, calculates injector firing and duration, and fires injectors at appropriate times.
EEPROM	Electrically Erasable Programmable Read Only Memory.
EFC	Electronic Fire Commander
EFPA	Electronic Foot Pedal Assembly: Contains the throttle position sensor.
EOP	Engine Over-temperature Protection
ESH	Engine Sensor Harness
ESS	Engine Synchro Shift
EUI	Electronic Unit Injector
FEI	Fuel Economy Incentive
FPS	Fuel Pressure Sensor: Monitors fuel pressure.
FTS	Fuel Temperature Sensor: Monitors fuel temperature.
GND	Ground
INJ	Injector (fuel)
ISD	Idle Shutdown: Programmable feature of the DDEC system.
IVS	Idle Validation Switch: A switch used to establish the idle speed position.
LSG	Limiting Speed Governor.
MPG	Miles Per Gallon
N/A	Not Applicable.
OEM	Original Equipment Manufacturer
OI	Optimized Idle
OLS	Oil Level Sensor: Monitors oil level.
OPS	Oil Pressure Sensor: Monitors oil pressure.
OTS	Oil Temperature Sensor: Monitors oil temperature.
PGS	Pressure Governor System: Regulates engine speed to maintain a selected external pump pressure.
PTO	Power Take-Off. Also, referred to as VSG (Variable Speed Governor).
PW	Pulsewidth
PWM	Pulsewidth Modulated: Modulated signal provided by the DDEC system.
RES/ACCEL	Resume/Accelerate Switch used for cruise control.
SEL	† Stop Engine Light: Typically mounted on the instrument panel. It has two functions:1.It is used as warning to the operator that a potential engine damaging condition has been detected. If the DDEC system is programmed for shutdown, the engine will shutdown on its own within 30 seconds. The engine should not be run until the condition is corrected.2.It is used by the operator or technician to "flash" out active trouble codes.
SEO	Stop Engine Override: Allows the stop engine condition to be overridden in case it is required.



Abbreviations	Terms
SET/COAST	Set/Coast Switch: Used in cruise control.
SRS	Synchronous Reference Sensor: Indicates a specific cylinder in the firing order.
TBS	Turbocharger Boost Sensor: Monitors turbo boost.
TBD	To be determined.
TD	Tachometer Driver: An output from the ECM for electronic tachometers and or data loggers.
TPS	Throttle Position Sensor: Used to detect throttle request (a component of the EFPA). Also, referred to as LSG.
TRS	Timing Reference Sensor: Used to detect whenever any cylinder is about to be fired.
VIH	Vehicle Interface Harness (OEM Wiring)
VIN	Vehicle Identification Number
VSG	Variable Speed Governor. Also, referred to as PTO (Power Take-Off).
VSS	Vehicle Speed Sensor: Used to detect vehicle speed.
VSS OC	Vehicle Speed Sensor Open Collector: An ECM input which must be used in addition to the VSS positive input when certain types of vehicle speed sensors are used. Refer to the Application and Installation manual for installation.

\* As a light bulb check and system check, the check engine light will come on for about 5 seconds when the ignition is turned on. If the CEL remains on, or comes back on, the self diagnostic system has detected a problem. If the problem goes away, the light will go out, but a trouble code will be stored in the ECM as an inactive code.

† As a light bulb check and system check, the stop engine light will come on for about 5 seconds when the ignition is turned on.

**Table 4-1 Abbreviations and Terms**

---

## 5 FLASH CODES VS SAE CODES

Section	Page
5.1 READING THE DIAGNOSTIC CODES - FLASH METHOD .....	5- 3
5.2 READING CODES .....	5- 5
5.3 DDEC DESCRIPTIONS .....	5- 6



## 5.1 READING THE DIAGNOSTIC CODES - FLASH METHOD

The following steps describe the flash method to interpret diagnostic codes:

**NOTE:**

If you are here to begin diagnosis of a problem and already know how to read codes, as well as understand active and inactive codes, refer to section 9.1.

1. Active versus Inactive codes:

- [a] Active codes are the codes which are currently keeping the "Check or Stop Engine" light on. Active codes are flashed via the Stop Engine Light (SEL).
- [b] Inactive codes are all the codes previously logged in the ECM. These codes can be cleared by using the DDR. Inactive codes are flashed via the Check Engine Light (CEL).

**NOTE:**

The Diagnostic Request Switch reads codes on the CEL and SEL when an DDR is not available. The following steps will enable you to obtain codes.

2. Turn vehicle ignition switch ON.


3. Depress and hold the diagnostic request switch.

- [a] As an example, observe Code 13 (active) and Code 21 (inactive) flashing out on the CEL and SEL; see Figure 5-1.
- [b] If input used is SEO/Diagnostic Request, press and release the switch.

[c] If input used is Diagnostic Request, press and hold switch.

**NOTE:**

Active codes are flashed in ascending numerical flash code order. Inactive codes are flashed in most recent to least recent order.



**Figure 5-1 Flash Code Method**

### 5.1.1 Clearing Codes


Fault codes can only be cleared using the DDR.

**NOTE:**

Removing the battery cables will not clear codes.

## 5.2 READING CODES

For instructions for using the DDR or Pro-Link 9000®, ( see Figure 5-2), refer to the Pro-Link Users Manual. For a list of Flash Codes and SAE Fault Codes, refer to section 5.3. Refer to flowchart.



**Figure 5-2**      **Pro-Link 9000**

## 5.3 DDEC DESCRIPTIONS

To read codes, use the diagnostic data reader or depress and hold the diagnostic request switch with the ignition ON, engine at idle or not running. Active codes will be flashed on the SEL. Inactive codes will be flashed on the CEL. The cycle will repeat until the operator releases the diagnostic request switch. Flash codes and descriptions are listed in Table 5-1.

Flash Codes	DDEC Description
11	VSG sensor input voltage low
12	VSG sensor input voltage high
13	Coolant level sensor input voltage low
14	Oil, coolant, or intercooler, temperature sensor input voltage high
15	Oil, coolant, or intercooler, temperature sensor input voltage low
16	Coolant level sensor input voltage high
17	Bypass or throttle, valve position sensor input voltage high
18	Bypass or throttle, valve position sensor input voltage low
21	TPS input voltage high
22	TPS input voltage low
23	Fuel temperature sensor input voltage high
24	Fuel temperature sensor input voltage low
25	No active codes
26	Auxiliary shutdown #1, or #2, input active
27	Air inlet or intake air, temperature sensor input voltage high
28	Air inlet or intake air, temperature sensor input voltage low
31	Auxiliary high side output open circuit or short to ground
32	CEL or SEL short to battery (+) or open circuit
33	Turbo boost sensor input voltage high
34	Turbo boost sensor input voltage low
35	Oil pressure sensor input voltage high
36	Oil pressure sensor input voltage low
37	Fuel pressure sensor input voltage high
38	Fuel pressure sensor input voltage low
41	Too many SRS (missing TRS)
42	Too many SRS (missing SRS)
43	Coolant level low
44	Oil, coolant, intercooler or intake air, temperature high
45	Oil pressure low
46	ECM battery voltage low
47	Fuel, air inlet, or turbo boost, pressure high

Flash Codes	DDEC Description
48	Fuel or air inlet pressure low
52	ECM A/D conversion fault
53	ECM non volatile memory fault
54	Vehicle speed sensor fault
55	J1939 data link fault
56	J1587 data link fault
57	J1922 data link fault
58	Torque overload
61	Injector response time long
62	Auxiliary output short to battery (+) or open circuit, or mechanical fault
63	PWM drive short to battery (+) or open circuit
64	Turbo speed sensor input fault
65	Throttle valve position input fault
66	Engine knock sensor input fault
67	Coolant or air inlet, pressure sensor input voltage fault
68	TPS idle validation switch open circuit or short to ground
71	Injector response time short
72	Vehicle overspeed
73	Gas valve position input fault or ESS fault
74	Optimized idle safety loop short to ground
75	ECM battery voltage high
76	Engine overspeed with engine brake
77	Fuel temperature high
81	Oil level, crankcase pressure, dual fuel BOI, or exhaust temperature voltage high
82	Oil level, crankcase pressure, dual fuel BOI, or exhaust temperature voltage low
83	Oil level, crankcase pressure, exhaust temperature, or external pump pressure high
84	Oil level or crankcase pressure low
85	Engine overspeed
86	External pump or barometer pressure sensor input voltage high
87	External pump or barometer pressure sensor input voltage low
88	Coolant pressure low

**Table 5-1 Flash Codes and Descriptions**



SAE faults and flash codes with descriptions are listed in Table 5-2.

SAE Faults	Flash Code	DDEC Description
p051 0	65	Throttle valve position above normal range
p051 1	65	Throttle valve position below normal range
p051 3	17	Throttle valve input voltage high
p051 4	18	Throttle valve input voltage low
p051 7	65	Throttle valve not responding
p052 0	44	Intercooler temperature high
p052 3	14	Intercooler sensor input voltage high
p052 4	15	Intercooler sensor input voltage low
p070 4	74	Optimized idle safety loop short to ground
p072 3	17	Bypass position sensor input voltage high
p072 4	18	Bypass position sensor input voltage low
p073 0	83	External pump pressure high
p073 3	86	Pump pressure sensor input voltage high
p073 4	87	Pump pressure sensor input voltage low
p084 0	72	Vehicle overspeed (fueled)
p084 11	72	Vehicle overspeed (absolute)
p084 12	54	Vehicle speed sensor failure
p091 3	21	Throttle position sensor input voltage high
p091 4	22	Throttle position sensor input voltage low
p092 0	58	Torque overload
p094 0	47	Fuel pressure high
p094 1	48	Fuel pressure low
p094 3	37	Fuel pressure sensor input voltage high
p094 4	38	Fuel pressure sensor input voltage low
p098 0	83	Oil level high
p098 1	84	Oil level low
p098 3	81	Oil level sensor input voltage high
p098 4	82	Oil level sensor input voltage low
p100 1	45	Oil pressure low
p100 3	35	Oil pressure sensor input voltage high
p100 4	36	Oil pressure sensor input voltage low
p101 0	83	Crankcase pressure high
p101 1	84	Crankcase pressure low
p101 3	81	Crankcase pressure sensor input voltage high
p101 4	82	Crankcase pressure sensor input voltage low

SAE Faults	Flash Code	DDEC Description
p102 0	47	Turbo boost pressure high
p102 3	33	Turbo boost pressure sensor input voltage high
p102 4	34	Turbo boost pressure sensor input voltage low
p103 8	64	Turbo speed sensor input failure
p105 0	44	Intake air temperature high
p105 3	27	Intake air temperature sensor input voltage high
p105 4	28	Intake air temperature sensor input voltage low
p106 0	47	Air inlet pressure high
p106 1	48	Air inlet pressure low
p106 3	67	Air inlet pressure sensor input voltage high
p106 4	67	Air inlet pressure sensor input voltage low
p108 3	86	Barometer pressure sensor input voltage high
p108 4	87	Barometer pressure sensor input voltage low
p109 1	88	Coolant pressure low
p109 3	67	Coolant pressure sensor input voltage high
p109 4	67	Coolant pressure sensor input voltage low
p110 0	44	Coolant temperature high
p110 3	14	Coolant temperature sensor input voltage high
p110 4	15	Coolant temperature sensor input voltage low
p111 1	43	Coolant level low
p111 3	16	Coolant level sensor input voltage high
p111 4	13	Coolant level sensor input voltage low
p121 0	76	Engine overspeed with engine brake
p168 0	75	ECM battery voltage high
p168 1	46	ECM battery voltage low
p172 3	27	Air temperature sensor input voltage high
p172 4	28	Air temperature sensor input voltage low
p173 0	83	Exhaust temperature high
p173 3	83	Exhaust temperature sensor input voltage high
p173 4	83	Exhaust temperature sensor input voltage low
p174 0	77	Fuel temperature high
p174 3	23	Fuel temperature sensor input voltage high
p174 4	24	Fuel temperature sensor input voltage low
p175 0	44	Oil temperature high
p175 3	14	Oil temperature sensor input voltage high
p175 4	15	Oil temperature sensor input voltage low

SAE Faults	Flash Code	DDEC Description
p187 3	12	VSG sensor input voltage high
p187 4	11	VSG sensor input voltage low
p187 7	11	VSG switch system not responding
p190 0	85	Engine overspeed
p251 10	-	Clock module abnormal rate
p251 13	-	Clock module fault
s001 0	61	Injector #1 response time long
s001 1	71	Injector #1 response time short
s002 0	61	Injector #2 response time long
s002 1	71	Injector #2 response time short
s003 0	61	Injector #3 response time long
s003 1	71	Injector #3 response time short
s004 0	61	Injector #4 response time long
s004 1	71	Injector #4 response time short
s005 0	61	Injector #5 response time long
s005 1	71	Injector #5 response time short
s006 0	61	Injector #6 response time long
s006 1	71	Injector #6 response time short
s007 0	61	Injector #7 response time long
s007 1	71	Injector #7 response time short
s008 0	61	Injector #8 response time long
s008 1	71	Injector #8 response time short
s009 0	61	Injector #9 response time long
s009 1	71	Injector #9 response time short
s010 0	61	Injector #10 response time long
s010 1	71	Injector #10 response time short
s011 0	61	Injector #11 response time long
s011 1	71	Injector #11 response time short
s012 0	61	Injector #12 response time long
s012 1	71	Injector #12 response time short
s013 0	61	Injector #13 response time long
s013 1	71	Injector #13 response time short
s014 0	61	Injector #14 response time long
s014 1	71	Injector #14 response time short
s015 0	61	Injector #15 response time long
s015 1	71	Injector #15 response time short

SAE Faults	Flash Code	DDEC Description
s016 0	61	Injector #16 response time long
s016 1	71	Injector #16 response time short
s020 3	81	Dual fuel BOI input voltage high
s020 4	82	Dual fuel BOI input voltage low
s021 0	41	Too many SRS (missing TRS)
s021 1	42	Too few SRS (missing SRS)
s025 11	26	Auxiliary engine shutdown #1 input active
s026 3	62	Auxiliary output #1 short to battery (+)
s026 4	62	Auxiliary output #1 open circuit
s026 7	62	Auxiliary output #1 mechanical system not responding properly
s040 3	62	Auxiliary output #2 short to battery (+)
s040 4	62	Auxiliary output #2 open circuit
s040 7	62	Auxiliary output #2 mechanical system not responding properly
s047 0	61	Injector #17 response time long
s047 1	71	Injector #17 response time short
s048 0	61	Injector #18 response time long
s048 1	71	Injector #18 response time short
s049 0	61	Injector #19 response time long
s049 1	71	Injector #19 response time short
s050 0	61	Injector #20 response time long
s050 1	71	Injector #20 response time short
s051 3	31	Auxiliary output #3 open circuit
s051 4	31	Auxiliary output #3 short to ground
s052 3	31	Auxiliary output #4 open circuit
s052 4	31	Auxiliary output #4 short to ground
s053 3	62	Auxiliary output #5 short to battery (+)
s053 4	62	Auxiliary output #5 open circuit
s053 7	62	Auxiliary output #5 mechanical system not responding properly
s054 3	62	Auxiliary output #6 short to battery (+)
s054 4	62	Auxiliary output #6 open circuit
s054 7	62	Auxiliary output #6 mechanical system not responding properly
s055 3	62	Auxiliary output #7 short to battery (+)
s055 4	62	Auxiliary output #7 open circuit
s055 7	62	Auxiliary output #7 mechanical system not responding properly
s056 3	62	Auxiliary output #8 short to battery (+)
s056 4	62	Auxiliary output #8 open circuit

SAE Faults	Flash Code	DDEC Description
s056 7	62	Auxiliary output #8 mechanical system not responding properly
s057 3	63	PWM driver #1 short to battery (+)
s057 4	63	PWM driver #1 open circuit
s058 3	63	PWM driver #2 short to battery (+)
s058 4	63	PWM driver #2 open circuit
s059 3	63	PWM driver #3 short to battery (+)
s059 4	63	PWM driver #3 open circuit
s060 3	63	PWM driver #4 short to battery (+)
s060 4	63	PWM driver #4 open circuit
s061 11	26	Auxiliary engine shutdown #2 input active
s072 0	61	#21 injector response time long
s072 1	71	#21 injector response time short
s073 0	61	#22 injector response time long
s073 1	71	#22 injector response time short
s074 0	61	#23 injector response time long
s074 1	71	#23 injector response time short
s075 0	61	#24 injector response time long
s075 1	71	#24 injector response time short
s076 0	66	Engine knock level above normal range
s076 3	66	Engine knock sensor input voltage high
s076 4	66	Engine knock sensor input voltage low
s076 7	66	Engine knock sensor torque reduction
s077 0	73	Gas valve position above normal range
s077 1	73	Gas valve position below normal range
s077 3	73	Gas valve position input voltage high
s077 4	73	Gas valve position input voltage low
s151 14	73	System Diagnostic Code #1 (ESS)
s226 11	73	Transmission Neutral Switch (ESS)
s227 4	73	Auxiliary analog input #1 voltage low (ESS)
s227 3	73	Auxiliary analog input #1 voltage high (ESS)
s227 2	73	Auxiliary analog input #1 data erratic, intermittent or incorrect (ESS)
s230 5	68	TPS idle validation switch open circuit
s230 6	68	TPS idle validation switch short to ground
s231 12	55	J1939 data link fault
s238 3	32	SEL short to battery (+)
s238 4	32	SEL open circuit

SAE Faults	Flash Code	DDEC Description
s239 3	32	CEL short to battery (+)
s239 4	32	CEL open circuit
s240 2	-	Fram checksum incorrect
s248 8	55	Proprietary data link fault (master)
s248 9	55	Proprietary data link fault (slave)
s249 12	57	J1922 data link fault
s250 12	56	J1587 data link fault
s253 2	53	Non volatile memory data incorrect
s253 12	53	Non volatile memory fault
s253 13	-	Incompatible calibration version
s254 0	-	External failed RAM
s254 1	-	Internal failed RAM
s254 6	-	Entered boot via switches
s254 12	52	ECM A/D conversion fail

**Table 5-2 SAE Faults and Flash Codes**



---

## 6 TESTING / SERVICE TOOLS / TIPS

Section	Page
6.1 BASICS .....	6- 3
6.2 OPERATOR INFORMATION .....	6- 5
6.3 SERVICE TOOLS .....	6- 7

---






## 6.1 BASICS

The following listed items should be checked prior to starting any troubleshooting:

- ☐ Ensure engine serial number on the ECM matches the serial number on the cylinder block.
- ☐ Walk around the vehicle. Look for obvious problems such as leaks (air or liquid).
- ☐ Inspect ECM for worn isolators, debris or bolts lodged between ECM and cylinder block.
- ☐ Broken wiring connectors.
- ☐ Fuel Supply - Full on.
- ☐ Fuel tank level.
- ☐ Vehicle damage.
- ☐ Investigate any prior repairs, if applicable.
- ☐ Check for poor mating of the connector halves or terminals not fully seated in the connector body (backed out terminals).
- ☐ Look for improperly formed or damaged terminals. All connector terminals in the problem circuit should be carefully inspected to determine proper contact tension. Use a mating terminal to test the contact tension.
- ☐ Electrical system interference caused by a defective relay, ECM driven solenoid, or a switch causing an electrical surge. Look for problems with the charging system (alternator, etc.). In certain cases, the problem can be made to occur when the faulty component is operated as in the case of a relay.
- ☐ Verify alternator grounds are clean and making good contact. Disconnect the alternator belt to test.
- ☐ Wiggle wires and harnesses to try to make the problem active, or re-occur.


### 6.1.1 ECM Programming

The following label is attached to the ECM. See Figure 6-1.



**Figure 6-1 ECM Label**

- ☐ Every DDEC system engine serial number has its own file in the DDC Mainframe.



- ☐ ECM programming must be done to match the serial number you are currently working on. Failure to do so may result in incorrect calibration and engine damage.
- ☐ Programming a DDEC III ECM must be done with an engine file set up for the DDEC III system.
- ☐ Programming a DDEC IV ECM must be done with an engine file set up for the DDEC IV system.
- ☐ For a summary of features and how to change them, refer to section 7.

## 6.2 OPERATOR INFORMATION

This section should serve as a guideline for the technician:

- ☐ Intermittent Problems - Talk to the operator/driver. Be specific!
- ☐ Develop your own Driver Questionnaire. Refer to section 6.2.1.

### 6.2.1 Driver Questionnaire

Ask the driver to answer the following questions before attempting to repair an intermittent problem, or a problem with symptoms but no diagnostic codes. Use this and the response guideline to these questions.

1. How often does the problem occur? Can you and the driver take the vehicle and demonstrate the problem in a short time?
2. Has the vehicle been to other shops for the same problem? If so, what was done there?
3. Did the radio, dash gages, or lights momentarily turn OFF when the problem occurred?
4. Does the problem occur only at specific operating conditions? If so, at what load? Is it light, medium, or heavy?
5. Does the problem occur at a specific engine operating temperature? If so, at what engine temperature?
6. Does the problem occur only when above or below specific outside temperatures? In what temperature range?
7. Does the problem occur during other conditions e.g. during or after rain, spray washing, snow?
8. Did the problem occur at a specific vehicle speed? If so, at what vehicle speed?
9. Does the problem occur at specific engine r/min? If so, at what engine r/min?

## 6.2.2 Questionnaire Response Guideline

The following are typical responses to the Driver Questionnaire:


1. If the problem is repeatable, take the vehicle for a drive with the DDR connected and note the conditions when the problem occurs. Be prepared to take snapshot data using the DDR. Ensure you operate the vehicle after correcting the problem and duplicate the operating conditions before releasing the unit, to verify the problem is corrected.
2. If the vehicle has been to other shops for the same problem, call the other shops and find out what has been done. Avoid replacing the same components again unless absolutely sure they are the problem! It is unlikely a component will fail again following a recent replacement.
3. If other vehicle devices are affected, this indicates there may be something wrong with the ignition wiring. Refer to section 91.2 for information on inspecting the ECM battery connections.
4. Operate the engine under similar load conditions. Check the fuel system for restrictions, primary filter, and fuel tanks for foreign objects blocking the fuel supply. Also, check the air system. Utilize the DDR snapshot feature.
5. Operate the engine at this temperature while attempting to duplicate the problem. Use the snapshot feature on the DDR.
6. If possible, troubleshoot the problem in this temperature range.
7. If the problem seems to occur during or after the engine is subjected to rain/spray washing, thoroughly inspect the connectors for moisture entry.
8. If the problem occurs at a specific vehicle speed, check the parameters affecting vehicle speed to verify they are programmed close to the vehicle speed where the problem occurs. Check Vehicle Speed and watch the DDR (snapshot) for changes to see if the pulse wheel (VSS signal) is loose.
9. If the problem occurs at a specific engine r/min, unplug the oil, coolant, and air temperature sensors, and note any changes to the problem. Gather this data and contact Detroit Diesel Technical Service.

### 6.3 SERVICE TOOLS


Listed in Table 6-1 are the service tools required to perform troubleshooting procedures for the DDEC-equipped engine.

Tool Number	Tool Name
J 39299	Volt-Ohm Meter; see Figure 6-2
J 38500	Pro-Link® Diagnostic Data Reader; see Figure 6-3
J 41005	DDEC III Vehicle Interface Module; see Figure 6-4
J 38480	Pro-Link Printer; see Figure 6-5
J 38852 or J 39848	Crimping Tools; see Figure 6-6
23516937	Digital Diesel Sensor Simulator; see Figure 6-7 (Optional Tool)
J 35751	Jumper Wire Kit


**Table 6-1 Service Tools**



**Figure 6-2 Volt-Ohm Meter, J 39299**




**Figure 6-3** Pro-Link Diagnostic Data Reader, J 38500




21655J

**Figure 6-4**      **DDEC III Vehicle Interface Module, J 41005**  
**(Will Operate DDEC IV Also)**






**Figure 6-5**      **Pro-Link 9000 Printer, J 38480**



**Figure 6-6**      **Crimping Tool, J 38852 or J 39848**



**Figure 6-7**      **Digital Diesel Sensor Stimulator, P/N: 23516937**

---

## 7 DDEC ECM SOFTWARE FEATURES

Section	Page
7.1 DDEC ECM SOFTWARE FEATURES .....	7- 3
7.2 DDEC FEATURE SUMMARY .....	7-15



## 7.1 DDEC ECM SOFTWARE FEATURES

This section is a brief description of DDEC system ECM software features and what is required to activate the feature (DDR, PC, etc.).

### NOTE:

For a complete description of features, refer to publication 7SA800, *DDEC III Application and Installation* manual.

### 7.1.1 Air Compressor Governor System

The air compressor governor system can be set on the mainframe only. This system is similar to the pressure governor system, but for air compressor applications. 6N4C change adjusts the engine speed to compensate for air pressure loads. ECM Software 4.01 is required.

### 7.1.2 Cruise Control

Cruise control can be set with the DDR or programming station.

- ☐ Auto Resume
  - ☐ Yes or No. Will re-engage cruise if clutch switch is used to disable. Second press of clutch must be done within 3 seconds of the disengage and cruise will resume at the previously set speed.
- ☐ Minimum Cruise Speed
  - ☐ Can be set with the DDR or programming station. Normally 20 mph, newer ECM software may allow setting to as low as 10 mph.
- ☐ Maximum Cruise Speed
  - ☐ Can be set with the DDR or programming station. Limited to the calculated gear bound vehicle speed at rated engine r/min, or if progressive shift = yes, then max cruise speed is limited to high gear r/min. Also limited to vehicle speed limit (if set).
- ☐ Engine Brake Cruise
  - ☐ Can be set with the DDR or programming station. Refer to engine brake information. Refer to section 7.1.5.

### 7.1.3 Cruise Switch Variable Speed Governor

The cruise switch can be set with the DDR or programming station. Requires Vehicle Speed Sensor (VSS) set to Yes.

- ☐ Initial r/min= 1000 r/min default, initial r/min to ramp up to when set.
- ☐ R/min incr= 25 r/min default, r/min increase when res/accl switch is enabled.

### 7.1.4 Data Pages

Enable data pages on the mainframe (up to 7.00 ECM software). This is automatic with ECM software level 20.xx or higher.

### 7.1.5 Engine Brake (Jake Brake)

Enabling the engine brake is done on the mainframe. Once turned on, output cavities S3 and T3 are automatically configured to provide voltage to the brake solenoids when the ECM calibrated parameters are met allowing activation.

Also requires two inputs, engine brake low and engine brake med.

Several options are available (programming station or DDR set) relative to engine brake operations:

- ☐ Dynamic Fan Braking
  - ☐ Enables the cooling fan whenever the engine brake is in high mode. This feature is able to be configured with the programming station or DDR. (DDR software level 2.0 or higher.)
- ☐ Engine Brake / Service Brake
  - ☐ This feature forces the operator to, in addition to the normal requirements, press the service brake in order to initiate the engine brake(s). Can be set with the DDR or programming station.
- ☐ Engine Brake Minimum MPH
  - ☐ This feature allows the customer to set a minimum mph to allow the engine brake to activate. Can be set with the DDR or programming station.
- ☐ Engine Brake Cruise
  - ☐ Allows engine brakes to activate to programmed levels automatically based on vehicle speed increases. Initial speed is low. The speed of the increments is medium, then high. Level (high, med, low) is limited by dash position switch.
  - ☐ Can be set with the DDR or programming station.

## 7.1.6 Engine Protection Features

Engine protection features can be set with the DDR or programming station. Three features are available:

- ☐ Shutdown
- ☐ Rampdown
- ☐ Warning

## 7.1.7 Engine Synchro Shift

Engine Synchro Shift™ (ESS) can be set with the programming station. ESS is a joint development between DDC and Rockwell.

The ESS system automatically synchronizes the transmission by matching the engine r/min speed to the road speed of the vehicle, eliminating the need to use the clutch pedal for shifting gears. Refer to publication number 6SE498, *Engine Synchro Shift (ESS) Troubleshooting Manual*.

Requires an ESS transmission type, two inputs (in gear and in neutral), and two outputs (high range solenoid and low range solenoid).

## 7.1.8 Ether Start

Ether start can be set with the programming station only. Requires ECM software level to be greater than 3.00, and enable output for Ether Start. Refer to *Ether Start* manual, 7SA727.

## 7.1.9 Fan Controls

Fan type is set in the mainframe; None; Single; Dual; Two Speed; are the allowed types. The correct inputs (if any are needed or desired) and outputs must be configured to an available cavity with the programming station.

- ☐ Required Outputs: Configure to any output cavity
  - ☐ Fan control #1 for Single
  - ☐ Fan control #1 and Fan control #2 for Dual or Two-Speed types
- ☐ Inputs are optional: Configure to any input cavity with the programming station
  - ☐ Auxiliary Fan Control
  - ☐ Fan Override



### 7.1.10 Fuel Economy Incentive

Fuel Economy Incentive (FEI) can be set with the DDR or programming station.

FEI is a DDEC feature that allows vehicle owners to set driver goals of fuel economy while offering the driver an incentive which is a result of his/her good driving habits. The FEI will automatically allow a higher vehicle speed (speed increase is dependent on the customer selected settings) than is set in the road speed limiting area of the ECM. FEI was released with ECM software level 5.00.

There are four items relative to FEI:

- ☐ Minimum MPG (MIN MPG)
  - ☐ This would be defined as the customer's minimum fuel economy goal. Any fuel economy obtained by the driver greater than this figure would result in a allowed speed increase. Each increase of 0.1 mpg will provide the speed increase dictated by the Conversion factor (or Scaler MPH/MPG).
- ☐ Maximum MPH (MAX MPH)
  - ☐ This would be the absolute maximum speed increase to which the customer wants the vehicle limited. The value is an increase above the vehicle speed limit. The allowed values are 0 to 20. A value of 0 disables the FEI feature. A value of 1 to 20 enables the FEI feature.
- ☐ Conversion Factor (Scaler MPH/MPG)
  - ☐ The miles per hour you want to allow for each full mile per gallon above the minimum mpg. Example: a value of 10 will allow the driver to go 10 mph above the road speed limit for each full (1) mile per gallon above the minimum mpg. If the minimum mpg is 7.0, and the driver is getting 7.1 mpg, then the system will allow one additional mile per hour increase, etc. The unit will still be limited to the maximum MPH.
- ☐ Calculation Type (CALC TYPE)
  - ☐ Two choices can be found under this item; FILTERED, or TRIP. This is what you want the FEI to use to base its calculations. Filtered bases the calculations on the fuel information, by periodic sampling of fuel consumption, recorded in the ECM. Trip bases the calculations on the *trip* portion of the fuel usage information.

FEI is only able to be set by the customer or service outlet and only with the DDR or programming station. Requires MPSI DDR version 5.0 or higher.

### 7.1.11 Fuel Pressure Sensor

Fuel pressure sensing is currently only configured for some industrial engines. It is not available on all series. The fuel pressure sensor used is the same as the oil pressure sensor.

### 7.1.12 Full Power Continuous Override

Full Power Continuous Override allows the operator to override the shutdown protection and maintain full power rather than ramp down to a reduced performance. This is set on the mainframe.

### 7.1.13 Function Lockout

Function Lockout was added to the release of 4.00 ECM and DDR software.

The purpose of this new option is to allow users to have a selected area or areas of the customer parameters password protected. For example, a customer can now function lockout the cruise control parameters with a user entered password, and still have the other areas accessible with the DDR with no (four zeros) password.

The function lockout parameters are able to be selected and customized to the customers request. The areas that are able to be protected by function lockout are:

- ☐ Idle Shutdown
- ☐ VSG Configuration
- ☐ Engine Protection
- ☐ Cruise Control
- ☐ Progressive Shift
- ☐ Engine Droop
- ☐ Engine/Vehicle Options
- ☐ Air Compressor
- ☐ ESS Transmission

When making changes with the DDR under the Reprogram Calibration section, you will already have entered a password to get past this step. If any of the functions in the selection list are function lockout protected, the DDR will ask for the function lockout password after that selection is made.

### 7.1.14 Half Engine Enable

Half engine enable can be set with the DDR for ECMs with 7.00 ECM software or higher. A current DDR is required. Half engine options are:

- ☐ No half engine - (OFF)
- ☐ Half engine when cold air inlet temperature is less than 12.5°C (55°F), with parking brake set - (IF COLD)
- ☐ Half engine all the time, whenever park brake is set - (ON)
- ☐ N/A is displayed when changing half engine with the DDR or laptop is not allowed in the engine calibration. The engine may have half engine program as part of that engine calibration. View "Diagnostic Data List" to see if the engine is currently operating in half engine mode.

### 7.1.15 Idle Shutdown

Idle shutdown can be set with the DDR or programming station.

- ☐ Enabled: Yes/No
- ☐ Time: 01 - 99 minutes
- ☐ Enabled on VSG: Yes/No; this determines if you want the idle timer to shut the engine down during idle only
  - ☐ No
  - ☐ Yes (Idle and High Idle)
- ☐ Override:
  - ☐ Yes/No, will flash the CEL 90 seconds before shutdown to allow the driver to press the pedal that will cancel the idle shutdown, and run until the key is cycled or by pressing the pedal again.
  - ☐ Ambient Air Temp disallows override: Can be set with the DDR or programming station. (Override Temp Disable) Lower Limit = XX; Upper Limit =XX. (When upper and lower limits are set, the operator will only be able to override ISD if the calculated ambient air temperature is above or below these temperatures. Upper and lower limit both set to 167°F = disables the feature.
- ☐ Adding Ambient Temp Sensor: DDC offers an *actual* ambient temperature sensor.

#### NOTE:

If the override temperature disable function is wanted by a customer, it is recommended that this be added (Kit P/N: 23518521, with instructions 18SP397).

### 7.1.16 Idle Speed

Idle speed can be set on the mainframe for some industrial applications to a maximum of 1000 r/min. It is a fixed speed for on-highway engines.

### 7.1.17 Idle Speed Offset

The Idle Speed Offset is read by the DDR as Idle Adjust.

Idle speed offset can be adjusted from + 100 r/min, to - 25 r/min using the DDR. Maximum combined speed for automatic transmission applications is 700 r/min. (Some special applications allow 750 r/min.)

### 7.1.18 Injector Calibration Codes

Injector calibration codes can be set with the DDR or programming station only. Codes are password protected. Allowed range is 01 - 99.

### 7.1.19 Input Functions

DDEC has twelve digital input ports listed in Table 7-1, located on the Vehicle Interface Harness. These digital inputs can be configured for various functions, listed in Table 7-2. These functions can be ordered at the time of engine order. Any digital input function is able to be customized by programming the ECM with a the programming station.

Input Cavities		Input Cavities	
E1	#451	G2	#543
F1	#542	H2	#524
G1	#528	J2	#531
H1	#523	K2	#583
J1	#541	G3	#545
F2	#544	K3	#979

**Table 7-1 Input Cavities**

Functions	Functions	Functions
None	Limiting Torque Curve	Trans Retarder Status
Engine Brake Low	Diagnostic Request	Dual Throttle (LSG)
Engine Brake Med	Alt Min VSG/Fast Idle	A/C Fan Status
Aux Shutdown #1	Service Brake Release	Aux CLS
Aux Shutdown #2	Clutch Released	Fan Control Override
Park Brake / ISD	Set Coast OFF DDEC II	VSG Station Change
Idle Validation	Set / Coast ON	VSG Station Complement
Pressure / RPM Mode	Resume/Accel OFF DDEC II	Air Load Switch
Throttle Inhibit	Resume / Accel ON	In Neutral Switch
RPM Sync (Marine)	Cruise Enable	In Gear Switch
RPM Freeze (Marine)	PGS System Enable	KD Brake
Rating Switch #1	SEO / DIAG Request	Gas Valve Diagnostic
Rating Switch #2	Engine Brake Disable	-

**Table 7-2 Available Input Functions**

### 7.1.20 Jake Brake (See Engine Brake)

For information on the Jake Brake®, refer to section 7.1.5.

### 7.1.21 Optimized Idle Feature

The Optimized Idle® feature can be set with the mainframe. Refer to the *Optimized Idle Installation and Troubleshooting Manual*, 7SA734, for all required information.

### 7.1.22 Output Functions

The DDEC system has three digital output ports located on the vehicle interface harness and three digital output ports located on a pigtail off the engine sensor harness. These digital outputs can be configured for various functions. The digital output cavities are listed in Table 7-3. These functions can be ordered at the time of engine order. The digital output functions available are listed in Table 7-4. Any digital output function can be customized by programming the ECM with the programming station.

Output Cavities		Output Cavities	
VIH		ESH	
A1	#988	W3	#563
A2	#555	X3	#564
F3	#499	Y3	#565

**Table 7-3 Output Cavities**

Functions	Functions	Functions
No Function	Fan Control #2	Turbo Recirc Valve
Low DDEC Volt	Deceleration Light	Optimized Idle Active
RPM Sync Active	Engine Brake Active	Low Range Solenoid (ESS)
PGS Active Light	VSG Active Indication	High Range Solenoid (ESS)
Vehicle Power Down	Oil Pressure Low Light	Shift Solenoid (Top2)
Starter Lockout	Oil Temp High Light	Shift Lockout (Top2)
Ext Brake Enable	Coolant Temp High Light	Gas Throttle Actuator
Trans Retarder Enable	Air Comp Solenoid	Fuel Supply Solenoid
Coolant Level Low Light	Crankcase Pressure High	KD Brake Solenoid
Cruise Active Light	Coolant Pressure Low	-
Fan Control #1	Ether Start	-

**Table 7-4 Available Output Functions**

### 7.1.23 Passwords

DDEC ECMs have the ability to have unique and separate passwords in the following areas:

- ☐ Update customer calibration (calibration change)
- ☐ Rating change
- ☐ Function lockout (4.00 or higher ECM software function)
- ☐ Injector calibration (Only the DDR will change this password)

#### 7.1.23.1 Changing Passwords \ Using the Diagnostic Data Reader

DDR software level **must** be 2.00 or higher.

1. In the event a customer loses or forgets his/her password, contact a Detroit Diesel Regional Office, or the Detroit Diesel Technical Service Department with the engine serial number. These contacts can provide an alternate (backdoor) password. You should also ensure that there is not any "maximum" or "rating" security enabled on the mainframe for that unit.
2. Using the DDR select the Password Change option in the area that you need to change. Password changing for Customer Password can be found in the "ENGINE" section, under "Calibration Change". Changing the password for engine rating and function lockout is found under their respective headings under the "Reprogram Cal" menu. Changing the injector password is found in the "ENGINE" section, under "Fuel Injector Information".
3. Enter the alternate password as the current password. The alternate password is a six character alpha numeric code. Enter alpha characters with the DDR by using the up or down arrow keys, that scroll you through the alphabet. Use the side arrow keys to move the cursor to the next position, or to back up to correct an entry.
4. Once all six positions are filled press the enter key.
5. Enter the new password you wish to enter (maximum four positions). Press enter.
6. Depending on the area you are changing, you will get a message that the password is successfully changed, or prompt you to confirm that this is what you really want to do.
7. Turn the ignition off, unplug the DDR.

### **7.1.24 Pressure Governor System (Fire Truck)**

The pressure governor system allows the engine speed to fluctuate to maintain a steady water pump outlet pressure.

**NOTE:**

This system can be set on the mainframe only (Fire Truck Applications 6N4C change).

The system requires the mainframe to be set to enable the feature. A pressure transducer is required.

**NOTE:**

The same transducer is used for DDEC II systems and III systems.

Control of the system can be done with switches/Mastermind for DDEC II systems or with Switches/Mastermind or Electronic Fire Commander (EFC) for DDEC III systems. Basic operation is the same for all systems.

The mastermind part number differs for DDEC II systems vs. DDEC III systems.

### **7.1.25 Progressive Shift Configuration**

Progressive shift configuration can be set with the DDR or programming station and can be used to force shifting. It is also useful to limit engine r/min in certain gears, to force shifting to a higher gear. Use Spec Manager to determine values to enter.

### **7.1.26 Rating Selections**

Ratings can be selected with DDR or programming station. Selections are limited to ratings available within the 6N4D group.

### **7.1.27 Top 2 (Eaton)**

Top 2 can be set with the programming station. Two outputs are required - shift solenoid and shift lockout. The transmission type is manual.

### 7.1.28 Transmission Type

Transmission type can be set with the programming station only. Choices at time of print (may be limited by the application code) are listed in Table 7-5.

	Transmission		Transmission		Transmission
00	Manual	14	Other Automatic	20	Rockwell RSX9-R
01	Allison Hydraulic	15	GE Statex III	21	Rockwell RS10
03	Voith	16	Autoshift / J1939	22	Rockwell RSX10
04	Z-F Ecomat	17	Rockwell RS9	23	Reserved - RSX10-C
09	Allison Electronic	18	Rockwell RSX9-A	-	-
12	Allison WT	19	Rockwell RSX9-B	-	-

**Table 7-5 Available Transmission Selections**

### 7.1.29 Vehicle Overspeed Parameters

Vehicle overspeed parameters can be set with the DDR or programming station. Customer decided parameters log vehicle overspeed codes. The parameter is typically set for +3 mph and +5 mph greater than the current vehicle speed limit; e.g. vehicle speed limit 65. Maximum overspeed limit is 68 and maximum speed no fuel is 70. Setting both to zero disables the function.

**NOTE:**

Remember to review these figures if Fuel Economy Incentive is activated.



### **7.1.30 Vehicle Speed Limiting**

Vehicle speed limiting can be set with the DDR or programming station. Requires VSS set to Yes.

Vehicle Speed Limit = Yes/No; Maximum speed = XX mph. Limited to the calculated gear bound vehicle speed at rated engine r/min, or if progressive shift = yes, then max cruise speed is limited to high gear r/min. (XX refers to customer selections.)

### **7.1.31 Variable Speed Governor or Limited Speed Governor Vehicle Speed Limiting Diagnostics**

If low side diagnostics need to be enabled or disabled, this is set on the mainframe.

Low side diagnostics refers to throttle position sensor (TPS) or variable speed governor (VSG) "low volt" codes. This occurs when an ECM is configured to be looking for a signal at one of these items, but nothing is wired to it.

### **7.1.32 Vehicle Speed Sensor Anti-Tamper**

Vehicle Speed Sensor (VSS) anti-tamper can be set with the DDR, or special ECM software available via parts.

Once set, VSS anti-tamper requires 5.0 level DDR or higher to disable.

## 7.2 DDEC FEATURE SUMMARY

The "x" in a column indicates that this feature has always been available. The numbers indicate the software release that the feature was introduced. A number in the DDR column represents the ECM software release that made the feature available, or able to be changed with the tool listed in the comments column. Parameters that are configured in the Application Code Only are listed in Table 7-6.

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
Air Compressor Governor System	4	-	-	-	-
Air Temp Sensor	x	-	-	-	-
Air Temp Torque Reduction	3	-	-	-	-
Barometric Pressure Sensor	x	-	-	-	-
Coolant Level Sensor	x	-	-	-	-
Coolant Pressure Sensor	x	-	-	-	-
Crankcase Pressure Sensor	x	-	-	-	-
Cruise MIN r/min	x	-	-	-	Typically 1100 r/min
Disable EOP on VSG	x	-	-	-	Typically fire trucks only
Dual Fuel BOI	x	-	-	-	Methanol engines; replaces fuel pressure sensor
Enable Engine Brakes	x	-	-	-	May be Jakes, KD (S55) or DVB (S55) beginning w/R4
Engine Overtemp Protection	x	-	-	-	Engine power limiting based on high engine temps OTS, CTS, ICTS
Engine Protection Configuration	x	-	-	-	Temp limits F & amt of power/speed reduction
Engine Sync	x	-	-	-	-
Engine Sync Pulses	x	-	-	-	Typically 12
Fan Control Configuration	x	-	-	-	Includes activation temps
Fuel Pressure Sensor	x	-	-	-	-
Glow Plugs	x	-	-	-	Methanol engines
Idle Operation at Zero VSG	x	-	-	-	Typically set for on-highway applications
Intercooler Temp Sensor	x	-	-	-	-

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
LSG Low Side Diagnostics (Code 22)	x	-	-	-	-
LSG Override VSG	x	-	-	-	-
Oil Pressure Sensor	x	-	-	-	-
Oil Temp Sensor	x	-	-	-	-
Pressure Governor System	x	-	-	-	Fire truck applications
PWM Fan Control	3	-	-	-	Assigned to PWM4 w/R3; can be programmed for PWM2 or PWM4 w/R4*
PWM Fan Control Configuration	3	-	-	-	Includes duty cycle levels and temperatures
VSG	x	-	-	-	-
VSG Low Side Diagnostics (Code 11)	x	-	-	-	Typically not set for on-highway applications
VSG Operation at Higher Vehicle Speeds	5	-	-	-	Typically set to 3 mph
VSG Using Foot Pedal	x	-	-	-	Changes scale of r/min per count

\* Typically PWM2 for S149; PWM4 for S50/S60

**Table 7-6 Parameters That Are Configured in Application Code Only**

The parameters that are configured in the mainframe screens only are listed in Table 7-7.

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
6N4C Group	-	x	-	-	-
6N4D Group	-	x	-	-	-
ATI Port	-	4	-	-	None or TURBO SPD or NAT GAS or VSG FREQ (Pin X-1)
Digital Torque Limiting	-	5	-	-	Utilizes selection of a predefined torque curve and/or speed
Fan Type (Digital Output)	-	x	-	-	-
Full Power Continuous Override	-	x	-	-	-
Hot Idle Speed	-	x	-	-	Some industrial only max 1400 r/min
Max Cold Idle Speed	-	3	-	-	Restricted for automatic trans to 700 r/min
Maximum Security	-	x	-	-	-
Override CCPS Faults	-	3	-	-	Intended for EMD
Override OPS Low Faults	-	3	-	-	Intended for EMD
Rating Security	-	x	-	-	-
Starter Lockout Speed Settings	-	5	-	-	Allows use of this out- put for other functions
VSG is Primary	-	x	-	-	-

**Table 7-7 Parameters that are Configured in the Mainframe Screens Only**

Parameters that can be configured by the OEM, programming station, and/or the DDR are listed in Table 7-8.

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
ACG Integral Gain	-	4	4	-	Air Compressor Gov
ACG Pressure Increment	-	4	4	-	-
ACG Proportional Gain	-	4	4	-	-
Engine Sensor Harness Outputs (3)	-	x	x	-	-
Fan A/C Timer	-	5	5	-	Typically set to 180 seconds (3 minutes)
PGS Cavitation Time Out	-	x	x	-	-
PGS Engine Speed Increment	-	x	x	-	-
PGS Integral Gain	-	x	x	-	-
PGS Proportional Gain	-	x	x	-	-
PGS Pump Pressure Increment	-	x	x	-	-
Vehicle Interface Harness Inputs (12)	-	x	x	-	-
Vehicle Interface Harness Outputs (3)	-	x	x	-	-
ACG Delta Pressure to Load	-	4	4	4	Air Compressor Gov
ACG Delta Pressure to Unload	-	4	4	4	-
ACG Maximum Pressure - 1,2,3	-	4	4	4	-
ACG Minimum Pressure - 1,2,3	-	4	4	4	-
Auxiliary Stop 1 or 2 Protection Level	-	x	x	x	-
Coolant Level Protection Level	-	x	x	x	-
Crankcase Pressure Protection Level	-	x	x	x	-
Cruise Auto Resume	-	x	x	x	-
Cruise Control Enable	-	x	x	x	-

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
Cruise Maximum Speed	-	x	x	x	-
Cruise Minimum Speed	-	x	x	x	-
Dynamic Fan Braking	-	x	2	2	-
Engine Brake Cruise	-	x	x	x	-
Engine Brake Increment	-	x	x	x	-
Engine Brake Low	-	x	x	x	-
Engine Brake-Svc Brake Activation	-	-	5	5	When set requires tap of svc brake to activate Jakes
Engine Brake - Minimum mph	-	-	5	5	Allows deactivation of Jakes below a vehicle speed
FEI - Calculation Type	-	5	5	5	Fuel Economy Incentive
FEI Conversion Factor, mph per mpg	-	5	5	5	-
FEI - Maximum mph	-	5	5	5	-
FEI - Minimum mpg	-	5	5	5	-
Feature Password Protection	-		5	4	(Function Lockout)
Half Engine Enable	-	-	-	7	Enable/disable Half engine idle, Off, If Cold, On, N/A
Idle Shutdown Override	-	x	x	x	-
Idle Speed Offset	-	-	-	x	Idle Adjust Normal +100 to -25 rpm
Idle Timer	-	x	x	x	-
Idle Timer Operates ON	-	x	x	x	Idle Gov only, or Idle and VSG Governor
Idle Timer Override Defeat, max temp	-	2	2	2	-
Idle Timer Override Defeat, min temp	-	2	2	2	-
Idle Timer Shutdown	-	x	x	x	-
Injector Calibration Codes	-	-	-	x	-
Intercooler Temp Protection Level	-	x	x	x	-
LSG Droop	-	x	x	x	-

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
Max Vehicle Overspeed with Fuel	-	x	x	x	-
Max Vehicle Overspeed w/o Fuel	-	x	x	x	-
Oil Pressure Protection Level	-	x	x	x	-
Oil Temp Protection Level	-	x	x	x	-
Progressive Shift Configuration	-	x	x	x	-
Rating Selection (Rating Override)	-	6N4M	x	x	-
Transmission Type (PWM #1)	-	x	x	x	-
Unit Number	-	-	-	4	-
Vehicle Speed Limiting	-	x	x	x	-
Vehicle Speed Max	-	x	x	x	-
Vehicle Speed Sensor	-	x	x	x	-
VIN	-	-	x	x	-
VSG Alt Min RPM	-	x	x	x	-
VSG Cruise Init Speed	-	x	x	x	-
VSG Cruise RPM Increment	-	x	x	x	-
VSG Droop	-	x	x	x	-
VSG Maximum RPM	-	x	x	x	-
VSG Minimum RPM	-	x	x	x	-
VSG Using Cruise Switch	-	x	x	x	-
VSS Anti Tamper	-	-	7	5	-
VSS Axle Ratio	-	x	x	x	-
VSS Final Gear Ratio	-	x	x	x	-
VSS Number of Teeth	-	x	x	x	-
VSS Sensor Type	-	x	x	x	Typically tailshaft; also wheel or J1939

Parameter Name	APPL Code 6N4C Only	Mainframe Only	Program Station	DDR / DDL	Comments
VSS Signal Type	-	2	2	2	Typically magnetic; also open-collector/switch
VSS Tire Revolutions	-	x	x	x	-

**Table 7-8 Parameters that can be Configured by the OEM, Programming Station, and/or the DDR**

DDEC Features, code 6N5, are listed in Table 7-9.

Parameter Name	Code	Mainframe Only	Program Station	DDR	Comments
No DDEC Feature	6N5-NONE	-	-	-	-
ECM Data Pages Only	6N5-0001	-	-	-	-
Optimized Idle Only	6N5-0002	-	-	-	-
Data Pages and Optimized Idle	6N5-0003	-	-	-	-

**Table 7-9 6N5 - DDEC Features**





---

## 8 CONNECTORS, TERMINALS, AND SPLICING

Section	Page
8.1 CRIMP AND REMOVAL TOOLS .....	8- 3
8.2 METRI-PACK 150 CONNECTORS .....	8- 4
8.3 WEATHER PACK AND METRI-PACK 280 CONNECTORS .....	8-11
8.4 DEUTSCH CONNECTORS .....	8-18
8.5 SPLICING GUIDELINES .....	8-23
8.6 STRAIGHT LEADS .....	8-24
8.7 SOLDER .....	8-25
8.8 SHRINK WRAP .....	8-25
8.9 MULTIPLE BROKEN WIRES .....	8-26
8.10 THREE-WIRE SPLICE .....	8-27

---



## 8.1 CRIMP AND REMOVAL TOOLS

Crimp tools and connector removing tools can be purchased from Kent-Moore. The part and associated part numbers are listed in Table 8-1.

Connector	Tool	Part Number
Metri-Pack 150	Removing	J 35689
	Crimp	J 35123
Weather Pack	Removing	J 36400-5
	Crimp	J 35606
Metri-Pack 280	Removing (18 AWG)	J 33095
	Crimp (18 AWG)	J 38125-6
	Removing (12 AWG - Used for power harness)	J 33095
	Crimp (12 AWG - Used for power harness)	J 39848
Deutsch	Removing (12 AWG)	J 37451
	Removing (16-18 AWG)	J 34513
	Crimp	J 34182

**Table 8-1 Crimp and Removal Tools**

## 8.2 METRI-PACK 150 CONNECTORS

Metri-Pack 150 series connectors are "pull-to-seat" connectors. Each wire must be pushed through the connector prior to crimping the terminal. Cable seals are inserted into the shell of the connector and hold many wires. Metri-Pack 150 connectors are listed in Table 8-2.


ECM Engine Harness		ECM Vehicle Interface Harness	
Connector	P/N: 12034400	Connector	P/N: 12034398
Terminal	P/N: 12103881	Terminal	P/N: 12103881
Seal	In Connector	Seal	In Connector
Plug	P/N: 12034413	Plug	P/N: 12034413
ECM Communication Harness Connector		Temperature Sensor Harness	
Connector	P/N: 12066317	Connector	P/N: 12162193
Terminal	P/N: 12103881	Terminal	P/N: 12103881
Seal	In Connector	Seal	In Connector
Plug	P/N: 12034413	Plug	P/N: Not Applicable
Pressure Sensor Harness		Fire Truck Pressure Sensor (PGS)	
Connector	P/N: 12047909	Connector	P/N: 12065287
Terminal	P/N: 12103881	Terminal	P/N: 12103881
Seal	In Connector	Seal	In Connector
Plug	P/N: Not Applicable	Plug	P/N: Not Applicable
SRS Harness		TRS Harness	
Connector	P/N: 12162193	Connector	P/N: 12162197
Terminal	P/N: 12103881	Terminal	P/N: 12103881
Seal	In Connector	Seal	In Connector
Plug	P/N: Not Applicable	Plug	P/N: Not Applicable
Injector (Gray)		Injector (Black)	
Connector	P/N: 12162830	Connector	P/N: 12040947
Terminal	P/N: 12103881	Terminal	P/N: 12103881
Seal	P/N: Not Applicable	Seal	P/N: Not Applicable
Plug	P/N: 12034413	Plug	P/N: 12034413

**Table 8-2 Metri-Pack 150 Connector Part Numbers**

## 8.2.1 Installation

Metri-Pack 150 connectors are of the "pull-to-seat" design. The cable is pushed through the seal and correct cavity of the connector before crimping the terminal to the cable. It should be stripped of insulation *after* it is placed through the seal and connector body. Use the following instructions for terminal installation:


1. Position the cable through the seal and correct cavity of the connector. See Figure 8-1.



**Figure 8-1**      **Inserting Wire in Connector**


2. Strip the end of the cable using wire strippers to leave  $5.0 \pm 0.5$  mm ( $0.2 \pm 0.02$  in.) of bare conductor.
3. Squeeze the handles of the crimping tool together firmly to cause the jaws to automatically open.
4. Hold the "wire side" facing you.

5. Push the terminal holder to the open position and insert the terminal until the wire attaching portion of the terminal rests on the 20-22 anvil. Be sure the wire core wings and the insulation wings of the terminal are pointing toward the upper jaw of the crimping tool. See Figure 8-2.



**Figure 8-2**      **Terminal and Crimping Tool Position**

6. Insert the cable into the terminal until the stripped portion is positioned in the wire core wings, and the insulation portion ends just forward of the insulation wings. See Figure 8-3.




**Figure 8-3**      **Cable to Terminal Alignment**

7. Compress the handles of the crimping tool until the ratchet automatically releases and the crimp is complete.



**NOTE:**


For faster, more efficient crimping operation, a bracket or bench rest may be used to cradle one handle of the tool. The operator can apply the terminals by grasping and actuating only one handle of the tool. See Figure 8-4.



**Figure 8-4 Crimping Operation**

8. Release the crimping tool with the lock lever located between the handles, in case of jamming.
9. Align the locking tang of the terminal with the lettered side of the connector.

10. Pull the cable back through the connector until a click is heard. See Figure 8-5. Position the seal into the connector.



**Figure 8-5**      **Pulling the Terminal to Seat**


**NOTE:**

For ECM 30-pin connectors, put locking tang opposite lettered side.

### 8.2.2 Removal and Repair

A tang on the terminal locks into a tab molded into the plastic connector to retain the cable assembly. Remove Metri-Pack 150 terminals using the following instructions.

1. Insert the removal tool into the cavity of the connector, placing the tip of the tool between the locking tang of the terminal and the wall of the cavity. See Figure 8-6.



**Figure 8-6 Terminal Removal**

2. Depress the tang of the terminal to release it from the connector.
3. Push the cable forward through the terminal until the complete crimp is exposed.
4. Cut the cable immediately behind the damaged terminal to repair it.
5. Follow the installation instructions for crimping the terminal and inserting it into the connector.

### 8.3 WEATHER PACK AND METRI-PACK 280 CONNECTORS

Weather Pack and Metri-Pack 280 series connectors are push-to-seat. The terminal is crimped onto each wire before it is inserted into the connector. A cable seal is crimped on each wire at the same time the terminal is crimped onto the wire. Weather Pack connectors use a secondary lock on both male and female connector bodies and the lock snaps into place over the cable seals after installation. Some Metri-Pack connectors have secondary locks as well. Weather Pack connectors and their associated part numbers are listed in Table 8-3. Metri-Pack 280 connectors and their associated part numbers are listed in Table 8-4.

Turbo Boost Pressure Sensor Harness		Engine Brake Connector, Series 60	
Connector	P/N: 12015384	Connector	P/N: 12010973 / 12162000
Terminal	P/N: 12089040	Terminal	P/N: 12048074 / 12045773
Seal	P/N: 12015323	-	-
Throttle Position Sensor Harness Side		Throttle Position Sensor Sensor Side	
Connector	P/N: 12015793	Connector	P/N: 12010717
Terminal	P/N: 12089188	Terminal	P/N: 12089040
Seal	P/N: 12015323	Seal	P/N: 12015323
Plug	P/N: Not Applicable	Plug	P/N: Not Applicable
Ignition Connector Power Harness Side		Ignition Connector Vehicle Interface Harness Side	
Connector	P/N: 12034074	Connector	P/N: 12015378
Terminal	P/N: 12089040	Terminal	P/N: 12089188
Allison Interface Module		Allison Interface Module Maximum Feature	
Connector	P/N: 12015791	Connector	P/N: 12015799
Terminal	P/N: 12089188	Terminal	P/N: 12089188
Seal	P/N: 12015323	Seal	P/N: 12015323
		Plug	P/N: 12010300

**Table 8-3 Weather Pack Connectors and Part Numbers**


Coolant Level Sensor Connector		Power Harness	
Connector	P/N: 15300027	Connector	P/N: 12124634
Terminal	P/N: 12077411	Terminal	P/N: 12077413
Seal	P/N: 12015323	Seal	P/N: 12015193
Secondary Lock	P/N: 15300014	Secondary Lock	P/N: 12052816
Plug	P/N: Not Applicable	Plug	P/N: Not Applicable

**Table 8-4 Metri-Pack 280 Connectors and Part Numbers**

### 8.3.1 Installation


Use the following instructions for terminal installation:

1. Insert the terminal into the locating hole of the crimping tool using the proper hole according to the gage of the cable to be used. See Figure 8-7.



**Figure 8-7**      **Terminal Position**


2. Insert the cable into the terminal until the stripped portion is positioned in the cable core wings, and the seal and insulated portion of the cable are in the insulation wings. See Figure 8-8.



**Figure 8-8 Cable and Terminal Position Before and After Crimping**

3. Compress the handles of the crimping tool until the ratchet automatically releases and the crimp is complete. A properly crimped terminal is shown. See Figure 8-8.
4. Release the crimping tool with the lock lever located between the handles, in case of jamming.

5. Push the crimped terminal into the connector until it clicks into place. Gently tug on the cable to make sure it is secure. See Figure 8-9.




**Figure 8-9**      **Inserting Terminal in Connector**

### 8.3.2 Removal and Repair

Two locking tangs are used on the terminals to secure them to the connector body. Use the following instructions for removing terminals from the connector body.

1. Disengage the locking tang, securing the connector bodies to each other. Grasp one half of the connector in each hand and gently pull apart.
2. Unlatch and open the secondary lock on the connector. See Figure 8-10.




**Figure 8-10 Unlatched Secondary Lock**

3. Grasp the cable to be removed and push the terminal to the forward position.
4. Insert the removal tool straight into the front of the connector cavity until it stops.




5. Grasp the cable and push it forward through the connector cavity into the tool while holding the tool securely in place. See Figure 8-11.



**Figure 8-11 Removal Tool Procedure**


6. The tool will press the locking tangs of the terminal. Pull the cable rearward (back through the connector). Remove the tool from the connector cavity.
7. Cut the wire immediately behind the cable seat and slip the new cable seal onto the wire.

8. Strip the end of the cable using strippers to leave  $5.0 \pm 0.5$  mm ( $0.2 \pm 0.02$  in.) of bare conductor. Position cable seal as shown. See Figure 8-12.



**Figure 8-12** Proper Cable Seal Position

9. Crimp new terminal onto wire using the crimp tool. See Figure 8-13.



**Figure 8-13** Crimping Procedure

## 8.4 DEUTSCH CONNECTORS

Deutsch connectors have cable seals molded into the connector. These connectors are push to seat connectors with cylindrical terminals. The diagnostic connector terminals are gold plated for clarity. Deutsch connectors and their associated part numbers are listed in Table 8-5.


Diagnostic Connector	
Connector	P/N: 23513052
Terminal	P/N: 23513053
Protective Cap	P/N: 23413054
Plug	P/N: 23507136
Engine Minder	
Connector	P/N: 23512222
Terminal	P/N: 23507132
Plug	P/N: 23507136
Mastermind - Power and Communication Link	
Connector	P/N: 23512221
Terminal	P/N: 23507132
Plug	P/N: 23507136
Mastermind - Inputs and Outputs	
Connector	P/N: 23512223
Terminal	P/N: 23507066
Plug	P/N: 23507136

**Table 8-5      Deutsch Connectors and Part Numbers**

### 8.4.1 Installation

Use the following instructions for installation:


1. Strip approximately  $\frac{1}{4}$  in. (6 mm) of insulation from the cable.
2. Remove the lock clip, raise the wire gage selector, and rotate the knob to the number matching the gage wire that is being used.
3. Lower the selector and insert the lock clip.
4. Position the contact so that the crimp barrel is  $\frac{1}{32}$  of an inch above the four indenters. See Figure 8-14. Crimp the cable.



**Figure 8-14**      **Setting Wire Gage Selector and Positioning the Contact**


5. Grasp the contact approximately one inch behind the contact crimp barrel.

6. Hold the connector with the rear grommet facing you. See Figure 8-15.



**Figure 8-15 Pushing Contact Into Grommet**

7. Push the contact into the grommet until a positive stop is felt. See Figure 8-15. A slight tug will confirm that it is properly locked into place. See Figure 8-16.




**Figure 8-16 Locking Terminal Into Connector**

### 8.4.2 Removal


The appropriate size removal tool should be used when removing cables from connectors. The proper removal tool size is listed in Table 8-1.

1. With the rear insert toward you, snap the appropriate size remover tool over the cable of contact to be removed. See Figure 8-17.



**Figure 8-17**      **Removal Tool Position**

2. Slide the tool along the cable into the insert cavity until it engages and resistance is felt. Do not twist or insert tool at an angle. See Figure 8-18.



**Figure 8-18 Removal Tool Insertion**

3. Pull contact cable assembly out of the connector. Keep reverse tension on the cable and forward tension on the tool.

## **8.5 SPLICING GUIDELINES**

The following are guidelines which may be used for splices. The methods described are not the only acceptable methods. Any method should produce a high quality, tight splice with durable insulation that can be expected to last the life of the vehicle.

The selection of crimpers and splice connectors is optional. Select a high quality crimper equivalent to the Kent-Moore tool, J 38706, and commercially available splice clips.

### **8.5.1 Tools Required**

The following is a list of tools required for splicing wires:


- ☐ Soldering iron
- ☐ Rosin core solder
- ☐ Wire strippers
- ☐ Heat shrink tubing
- ☐ Splice clips
- ☐ Crimp pliers



## 8.6 STRAIGHT LEADS

To splice straight leads:

1. Locate broken wire.
2. Remove insulation as required; be sure exposed wire is clean and not corroded.
3. Slide a sleeve of shrink wrap on the wire long enough to cover the splice and overlap the wire insulation, about  $\frac{1}{4}$  in. on both sides.
4. Insert one wire into splice clip (P/N: 0597428 or equivalent) and crimp.
5. Insert the other wire into splice and crimp. See Figure 8-19.



**Figure 8-19**      **Spliced Wire**

## 8.7 SOLDER

Soldering splice connectors is optional. To solder splice connectors:

1. You *must* use rosin core solder.
2. Check the exposed wire before the splice is crimped in its connector. The exposed wire *must* be clean before the splice is crimped.
3. Use a suitable electronic soldering iron to heat the wires. Apply the solder to the heated wire (not to the soldering iron) allowing sufficient solder flow into the splice joint.
4. Pull on connection to assure crimping and soldering integrity.

## 8.8 SHRINK WRAP

Shrink wrap is required. Alpha FIT-300, Raychem TAT-125 or any equivalent heat shrink dual wall epoxy encapsulating adhesive polyolefin is required. Listed in Table 8-6

### Alpha Wire Corp

711 Lidgerwood Ave

P.O. Box 711

Elizabeth; NJ 07207-0711

1-800-52ALPHA

### Raychem Corporation

Thermofit Div

300 Constitution Drive, Bldg. B

Menlo Park, CA 94025

650-361-3860

**Table 8-6      Shrink Wrap Sources**


To heat shrink wrap a splice:

1. Select the correct diameter to allow a tight wrap when heated. The heat shrink wrap *must* be long enough to overlap the wire insulation about  $\frac{1}{4}$  in. on both sides of the splice.
2. Heat the shrink wrap with a heat gun; do not concentrate the heat in one location, but play the heat over the entire length of shrink wrap until the joint is complete.

## 8.9 MULTIPLE BROKEN WIRES

To splice multiple broken wires:


1. Stagger the position of each splice as illustrated. See Figure 8-20.
2. You *must* stagger positions to prevent a large bulge in the harness and to prevent the wires from chafing against each other.



**Figure 8-20** Multiple Splices

## 8.10 THREE-WIRE SPLICE

Three-way splice connectors are commercially available to accommodate three-wire splices. The technique is the same as a single butt splice connector. See Figure 8-21.



**Figure 8-21**      **Three-Way Splice**



---

## 9    DIAGNOSING A DDEC SYSTEM FAULT

Section	Page
9.1    FIRST STEP FOR DIAGNOSING A FAULT WITHIN THE DDEC SYSTEM .....	9- 3

---



## 9.1 FIRST STEP FOR DIAGNOSING A FAULT WITHIN THE DDEC SYSTEM

The following procedure is the starting point for diagnosing DDEC codes using the Diagnostic Data Reader (DDR).

### 9.1.1 Check Engine Light

Perform the following steps to check the Check Engine Light (CEL):

1. Turn the ignition on while at the same time observing the Check/Stop Engine light (engine not running).
  - [a] If the CEL comes on and stays on, refer to section 9.1.2.
  - [b] If the CEL comes on for up to five seconds, and then turns off, refer to section 9.1.3.
  - [c] If the CEL does come on, but the condition of light is erratic or intermittent, refer to section 10.4.
  - [d] If the CEL does not come on, refer to section 10 and choose the appropriate symptom.

### 9.1.2 Read Active Codes

Perform the following steps to read the active codes.

1. Turn ignition on. Plug DDR into DDL connector. See Figure 9-1.




Figure 9-1 Diagnostic Connector



2. Read active codes by selecting the DIAGNOSTIC CODE MENU (ACTIVE CODES) on the DDR.
  - [a] If active codes are displayed on the DDR, follow the appropriate diagnostic procedures for the codes received. Refer to the section number that is the same as the *Flash Code* number.
  - [b] If the DDR display is blank or random, refer to section 10.5.
  - [c] If DDR displays NO DATA or DDEC Info not available, refer to section 10.5.
  - [d] If the DDR display reads "No Active Codes", refer to section 10.4.

### 9.1.3 Read Inactive Codes

Perform the following steps to read inactive codes.

1. Plug DDR into the DDL connector.
2. Read inactive codes. (Select inactive codes on the DDR.)
  - [a] If DDR displays no inactive codes, the problem may be intermittent. Refer to section 10.1.
  - [b] If DDR display is blank or random, refer to section 10.5.
  - [c] If DDR displays NO DATA or DDEC Info not available, refer to section 10.5.
  - [d] If the DDR displays any inactive codes, clear the codes and refer to section 9.1.4.

### 9.1.4 Attempt to Make Codes Active

Perform the following steps to read the active codes.

1. Start and run the engine for eight minutes. Warm the engine. Coolant/oil temperature must be greater than 140 ° F (60 ° C).
2. If required, perform road test with an assistant.
  - [a] If CEL or SEL illuminate, read codes and refer to the section number that matches the flash code number logged.
  - [b] If CEL or SEL do not illuminate and no codes log, return to service.
  - [c] If CEL or SEL do not illuminate but symptom occurs, refer to section 10.1, and *Diagnosis by Symptom*.

---

## 10 INTERMITTENT FAULT

Section	Page
10.1 INTERMITTENT CODE OR A SYMPTOM AND NO CODES .....	10- 3
10.2 ENGINE CRANKS BUT WILL NOT START .....	10- 4
10.3 ERRATIC PERFORMANCE AND NO CODES .....	10-20
10.4 CHECK ENGINE LIGHT AND STOP ENGINE LIGHT FAULT .....	10-21
10.5 NO DATA TO DIAGNOSTIC DATA READER .....	10-24
10.6 DIAGNOSTIC REQUEST SWITCH INOPERATIVE .....	10-29
10.7 CRUISE CONTROL INOPERATIVE .....	10-31
10.8 FAN OPERATIONAL CONCERN (ON/OFF TYPE) .....	10-40
10.9 FAN OPERATIONAL CONCERN (VARIABLE SPEED TYPE) .....	10-46
10.10 ENGINE BRAKE INOPERATIVE .....	10-50
10.11 MISCELLANEOUS DIGITAL INPUT FAULT .....	10-55
10.12 MISCELLANEOUS DIGITAL OUTPUT FAULT .....	10-58
10.13 FIRE TRUCK PRESSURE GOVERNOR FAULT .....	10-61
10.14 OPTIMIZED IDLE FEATURE DOES NOT FUNCTION .....	10-72
10.15 TRANSMISSION INTERFACE FAULT .....	10-78

---



## 10.1 INTERMITTENT CODE OR A SYMPTOM AND NO CODES

The following procedure will diagnose an intermittent code or symptom.

### 10.1.1 Diagnosis by Symptom

Perform the following steps to diagnose an intermittent code or symptom.

#### NOTE:

Do not use any other procedures (except for the suggestions listed in this manual) when trying to solve an intermittent problem. Use of any other procedures for this type of problem can result in the replacement of non-defective parts.

Many intermittent problems are caused by faulty electrical connectors or wiring. Diagnosis must include a careful inspection of the indicated circuit wiring and connectors. For example, an intermittent code 35 (Oil Pressure Sensor High Voltage) would indicate a problem in the following areas associated with the Oil Pressure Sensor.

- ☐ Wires #530 (signal line), #416 (+5 volt line), or #452 (ground line)
- ☐ The Oil Pressure Sensor connector or ECM connector
- ☐ An intermittent problem in the Oil Pressure Sensor (least likely)

Use the following checklist:

1. Check for poor mating of the connector halves or terminals not fully seated in the connector body (backed out terminals).
2. Look for improperly formed or damaged terminals. All connector terminals in the problem circuit should be carefully inspected to determine proper contact tension. Use a mating terminal to test the contact tension.
3. Electrical system interference caused by a defective relay, ECM driven solenoid, or a switch causing an electrical surge. Look for problems with the charging system (alternator, etc.). In certain cases, the problem can be made to occur when the faulty component is operated as in the case of a relay.
4. Verify alternator grounds are clean and making good contact. Disconnect the alternator belt to test.
5. Wiggle wires and harnesses to try to make the problem active, or re-occur.

### 10.1.2 Verify Repairs

Perform the following steps to verify repairs.

1. Clear codes.
2. Confirm the CEL does not come on (except for the five second ignition ON bulb check).
3. Run the engine for one minute.
4. If the CEL stays ON, refer to section 9.1.2.

## 10.2 ENGINE CRANKS BUT WILL NOT START

The following procedures will diagnose engine cranks but will not start.

### 10.2.1 Check Engine Light

Perform the following steps to check the CEL:

1. Turn ignition on while observing the Check/Stop Engine Light.
  - [a] If the light comes on and stays on, refer to section 9.1.
  - [b] If the light comes on for up to five seconds, and then goes off, refer to section 10.2.2.
  - [c] If the lights are off, refer to section 10.2.14.

### 10.2.2 Fuel Check

Perform the following steps to check the fuel supply:

1. Disconnect the fuel return line.
2. Check for fuel flow while cranking the engine.
  - [a] If fuel flow is okay, refer to section 10.2.3.
  - [b] If fuel supply is not okay, refuel the vehicle. The system may need to be re-primed. Refer to the appropriate engine service manual.

### 10.2.3 White Smoke Check

Perform the following steps to check for white smoke:

1. Reconnect fuel return line.
2. Look for white smoke coming out of the exhaust stack while cranking the engine.
  - [a] If white smoke is present, refer to section 10.2.4.
  - [b] If white smoke is not present, refer to section 10.2.28.

## 10.2.4 Check Timing Reference Sensor Status

Perform the following steps to check the TRS status via a r/min readout:

1. Select engine speed and active codes on the DDR.
2. Crank the engine for ten seconds while observing DDR display. A battery voltage surge while cranking with electric starters may blank or reset the DDR.
  - [a] If the display reads greater than or equal to 60 r/min, refer to section 10.2.9.
  - [b] If the display reads less than 60 r/min or constantly reads 60 r/min, refer to section 10.2.5.
  - [c] If code 41 is displayed, refer to section 41.3.1.
  - [d] If code 42 is displayed, refer to section 42.3.1.

## 10.2.5 Check Timing Reference Sensor

Perform the following steps to check the TRS:

1. Turn vehicle ignition OFF.
2. Disconnect engine harness connector at the ECM.
3. Measure resistance between sockets T1 and T2 at the engine harness connector.
  - [a] If the resistance measurement is greater than 200  $\Omega$ , refer to section 41.3.3.
  - [b] If the resistance measurement is less than 100  $\Omega$ , refer to section 41.3.2.
  - [c] If the resistance measurement is between 100 and 200  $\Omega$ , refer to section 10.2.6.

### **10.2.6 Check Synchronous Reference Sensor / Timing Reference Sensor Mounting**

Perform the following steps to check the SRS/TRS mounting and the bracket:

1. Inspect SRS/TRS mounting.
  - [a] If the sensor and mount are secure, refer to section 10.2.7.
  - [b] If the sensor and mount are not secure, tighten the bolt or replace if necessary. Refer to section 10.2.27.

### **10.2.7 Check Pulse Wheel**

Perform the following steps to check the pulse wheel:

1. Inspect DDEC® pulse wheel for loose wheel or chipped or missing teeth.
  - [a] If the pulse wheel is damaged, repair or replace as necessary. Refer to section 10.2.27.
  - [b] If the pulse wheel is not damaged, refer to section 10.2.8.

### **10.2.8 Check ECM Connectors**

Perform the following steps to check the ECM connectors:

1. Turn vehicle ignition OFF.
2. Disconnect all connectors at the ECM.
3. Check terminals at all ECM connectors (both the ECM and harness side) for damaged, bent, corroded or unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them. Refer to section 10.2.27.
  - [b] If the terminals and connectors are not damaged, replace the ECM. Refer to section 10.2.27. (Try a test ECM first.)

## 10.2.9 Check for Good Synchronous Reference Sensor Signal

Perform the following steps to check for a good SRS signal:

1. Select engine data list on DDR.
2. Crank engine while observing DDR display of SRS received. Battery voltage surges while cranking with electric starters may blank or reset the DDR.
  - [a] If the SRS RECEIVED signal is YES, refer to section 10.2.11.
  - [b] If the SRS RECEIVED signal is NO, refer to section 10.2.10.

## 10.2.10 Check Synchronous Reference Sensor

Perform the following steps to check the SRS:

1. Turn vehicle ignition OFF.
2. Disconnect engine harness connector at the ECM.
3. Measure resistance between sockets S1 and S2 at the engine harness connector.
  - [a] If the resistance measurement is greater than 200  $\Omega$ , refer to section 41.3.3.
  - [b] If the resistance measurement is less than 100  $\Omega$ , refer to section 41.3.2.
  - [c] If the resistance measurement is between 100 and 200  $\Omega$ , refer to section 10.2.6.

## 10.2.11 Check for Open

Perform the following steps to check if the injector return wires are open:

1. Turn ignition OFF.
2. Disconnect the 5-way injector harness connector at the ECM.
3. Measure resistance between the injector return pin and all the power driver pins on both harness connectors.
  - [a] If the resistance measurement is greater than 5  $\Omega$  on any reading, an open exists in one of the injector power driver or return wires. Repair the open. Refer to section 10.2.27.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$  on any reading, refer to section 10.2.12.



### 10.2.12 Short to Ground

Perform the following steps to check if the injector lines are shorted to the ground:


1. Disconnect the 5-way injector harness connector at the ECM.
2. Measure resistance between socket D of the 5-way power harness connector to the following sockets on the injector harness connector: A, B, C, D, E, G, H, J, K and L.
  - [a] If the resistance measurement is greater than or equal to 10,000  $\Omega$  or open on all readings, refer to section 10.2.13.
  - [b] If the resistance measurement is less than 10,000  $\Omega$  on any reading, there is a short to ground on the wire where resistance was less than 10,000  $\Omega$ . Repair the short and refer to section 10.2.27.

### 10.2.13 Injector Drive Pulses

Perform the following steps to check the injector drive pulses:

1. Turn ignition OFF.
2. Reconnect all ECM connectors. See Figure 10-1.
3. Remove rocker covers.
4. Disconnect return wire #619 or #620 from one injector.
5. Place a 6-volt test light across the previously disconnected injector return side and a good ground.
6. Crank engine and note the test light to see if it lights (flashes).
7. Reconnect the return wire.
8. Repeat the above procedure with all other injectors until all have been tested or until one test fails.
  - [a] If all tests pass, the problem does not appear to be in the DDEC system.
  - [b] If all tests do not pass and the test light is flashing for one or more tests, check for proper parts (e.g. bull gear) then try a test ECM. Refer to section 10.2.27.

- [c] If all tests do not pass and the test light is not flashing for one or more tests, refer to section 10.2.8.



**Figure 10-1 5-Way ECM Power Harness Connector**

### 10.2.14 Check DDEC Fuses

Perform the following steps to check the DDEC fuses:

1. Check both ECM power fuses or circuit breakers.
  - [a] If both fuses are okay, refer to section 10.2.15.
  - [b] If either fuse is not okay, refer to section 10.2.25.

### 10.2.15 Battery Volts Check


Perform the following steps to check for battery volts at the 5-way connector:

**NOTE:**

A high resistance in these wires may prevent engine starting but measure correct voltage. Proper resistance based on wire length and size is listed in Table 46-2.

1. Turn ignition OFF.
2. Disconnect the 5-way power harness connector at the ECM. See Figure 10-2.
3. Measure voltage from socket A (red lead) of 5-way power harness connector to a good ground.

4. Measure voltage from socket C (red lead) of 5-way power harness connector to a good ground.
  - [a] If the voltage measurement is greater than 11.5 volts on all readings, refer to section 10.2.18.
  - [b] If the voltage measurement is less than 11.5 volts on any readings, refer to section 10.2.16.




**Figure 10-2 5-Way ECM Power Harness Connector**

### 10.2.16 ECM Power Line Check

Perform the following steps to check if the ECM power lines are open:

1. Measure voltage between battery side of one ECM fuse or circuit breaker (red lead) and a good ground (black lead).
2. Measure voltage at other ECM fuse or circuit breaker. Note that battery side does not contain #240 or #241 wires. See Figure 10-3.
  - [a] If the voltage measurement is less than 11.5 volts on any reading, refer to section 10.2.17.

- [b] If the voltage measurement is greater than 11.5 volts on all readings, an open exists in either power wire (#240 or #241). Repair the open; refer to section 10.2.27.



**Figure 10-3 Power Harness Diagram**

### 10.2.17 Check Battery

Perform the following steps to check the battery:


1. Connect all connectors.
2. Turn ignition ON.
3. Measure voltage at battery (+) terminal (red lead) to the battery (-) terminal (black lead).
  - [a] If the voltage reading is less than 11.5 volts, service the discharged battery. Refer to section 10.2.27.
  - [b] If the voltage reading is greater than or equal to 11.5 volts, an open or short to ground exists in the battery (+) line. Repair the open. Refer to section 10.2.27.

### 10.2.18 Check Volts at Ignition Wire

Perform the following steps to check for +12 or +24 volts at the ignition wire:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM. For vehicle harness schematic, see Figure 10-4.
3. Turn ignition ON.
4. Measure voltage between socket B3 on the vehicle harness connector (red lead) and a good ground (black lead).
  - [a] If the voltage measurement is greater than or equal to 11.5 volts, refer to section 10.2.19.

[b] If the voltage measurement is less than 11.5 volts, refer to section 10.2.20.



**Figure 10-4 ECM Vehicle Harness Connector**

### 10.2.19 Ground Wire Check

Perform the following steps to check for a good ground wire:

1. Measure voltage between socket B3 on the vehicle harness connector (red lead) and sockets D and E of the 5-way power harness connector. For 5-way ECM power harness schematic, see Figure 10-5.

[a] If the voltage measurement is greater than or equal to 11.5 volts, refer to section 10.2.8.

- [b] If the voltage measurement is less than 11.5 volts, the ECM ground wire (ck#150) is open or has a poor connection. Repair open; refer to section 10.2.27.




Figure 10-5 5-Way ECM Power Harness Connector

### 10.2.20 Check Ignition Fuse

Perform the following steps to check the ignition fuse:

1. Turn ignition OFF.
2. Check 5-amp ignition fuse or circuit breaker.

- [a] If both the fuse and circuit breaker are okay, refer to section 10.2.21.
- [b] If the fuse or circuit breaker are not okay, refer to section 10.2.22.

### 10.2.21 Check for Open

Perform the following steps to check if the ignition wire is open:

1. Measure voltage between battery side (hot side) of the 5-amp ignition fuse (red lead) and a good ground (black lead).
  - [a] If the voltage measurement is less than 11.5 volts, refer to section 10.2.24.
  - [b] If the voltage measurement is greater than or equal to 11.5 volts, the ignition line (circuit #439) is open. Repair the open; refer to section 10.2.27.

### 10.2.22 Check for Ground

Perform the following steps to check if the ignition wire is shorted to ground:


1. Replace blown fuse or reset open circuit breaker.
2. Turn ignition ON for ten seconds.
3. Run engine for one minute.
4. Turn ignition OFF.
5. Check 5-amp ignition fuse or circuit breaker again.
  - [a] If both the fuse and circuit breaker are okay, refer to section 10.2.23.
  - [b] If the fuse and circuit breaker are not okay, the ignition line (circuit #439) is shorted to ground. Repair the short; refer to section 10.2.27.



### 10.2.23 Check Fuse or Circuit Breaker

Perform the following steps to check if the ignition fuse or breaker is okay:

1. Reconnect all harness connectors at the ECM.
2. Start the engine.
3. Run engine for one minute.
4. Turn ignition OFF.
5. Check 5-amp ignition fuse or circuit breaker again. For 5-way ECM power harness schematic, see Figure 10-6.
  - [a] If both the fuse and circuit breaker are okay, no short is currently present. Be warned of an intermittent short that could shut down the engine or blow a fuse due to reverse voltage at the battery. Refer to section 10.2.27.
  - [b] If the fuse or circuit breaker are not okay, refer to section 10.2.8.



**Figure 10-6 5-Way ECM Power Harness Connector**

### 10.2.24 Check Battery

Perform the following steps to check the battery:

1. Disconnect the battery cables at the battery.
2. Measure voltage at the battery (+) terminal (red lead) to the battery (-) terminal (black lead).
  - [a] If the voltage measurement is less than 11.5 volts, service the discharged battery. Refer to section 10.2.27.
  - [b] If the voltage measurement is greater than or equal to 11.5 volts, an open or short to ground exists in unfused ignition line. Repair the open. Refer to section 10.2.27.

### 10.2.25 Check for Blown Fuses

Perform the following steps to check for blown fuses:

1. Turn ignition OFF.
2. Disconnect the 5-way power harness connector at the ECM.
3. Replace blown fuse(s) or reset the circuit breaker(s).
4. Wait ten seconds.
5. Check whether fuse(s) or circuit breaker(s) have blown or opened up again.
  - [a] If the fuse and circuit breaker are okay, refer to section 10.2.23.
  - [b] If the fuse or circuit breaker are not okay, refer to section 10.2.26.

### 10.2.26 Check for Short to Ground

Perform the following steps to check for a short to ground:

1. Disconnect the batteries.
2. Measure resistance between #240 and a good ground (black lead).
3. Measure resistance between #241 and a good ground (black lead).
  - [a] If the resistance measurement is greater than or equal to 10,000  $\Omega$  on all readings, refer to section 10.2.8.
  - [b] If the resistance measurement is less than 10,000  $\Omega$  on any readings, a short to ground exists. Repair the short. Refer to section 10.2.27.

### 10.2.27 Verify Repairs

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop the engine.
7. Read inactive codes.
  - [a] If the engine starts and no codes are displayed, troubleshooting is complete.
  - [b] If the engine does not start, refer to section 10.2.1.
  - [c] If the engine starts and codes display, refer to section 9.1.

## 10.2.28 Check Fuel Filters

Perform the following steps to check fuel filters:

1. Turn ignition OFF.
2. Check primary and secondary fuel filters to be sure they are not clogged and they are filled with clean fuel.
  - [a] If the fuel filters are clean, refer to section 10.2.4.
  - [b] If the fuel filters are not clean, replace the filters. Prime the system if required. Refer to section 10.2.27.

### NOTE:

For information concerning Fuel Filters, refer to section 29.4.11 in the appropriate service manual. For information concerning Fuel Filter Replacement, refer to section 18 in the appropriate service manual.

## 10.3 ERRATIC PERFORMANCE AND NO CODES

The following troubleshooting chart resolves erratic performance and no codes displayed. For troubleshooting procedures, refer to the appropriate engine service manual.

### 10.3.1 Erratic Performance and No Codes

Check the following symptoms to determine possible fault, listed in Table 10-1.

Symptom	Possible Fault
Cannot get full power.	Plugged fuel filters. Hose not connected to Turbo Boost Sensor. Verify injector calibration(s) are correct.
Cannot get full throttle.	Mis-calibrated Throttle Position Sensor.
Runs rough; misses and occasionally stalls.	Improper gapping of Timing Reference and Synchronous Reference Sensor. Fuel leaks. Loose battery power, ignition or ground wires. Injector failure. Vehicle speed sensor failure. Injector harness failure.
Engine idles high after warm-up or hangs.	Incorrect calibration of Throttle Position Sensor. TPS linkage or pedal problem. VSG signal wire shorted to voltage source.
Low road speed.	Determine road speed specifications for vehicle manufacturer data. If road speed is less than specified and all mechanical checks are correct, then cruise control calibration is suspected.
Vehicle surges or bucks.	VSS may be supplying incorrect data to the ECM.

**Table 10-1 Troubleshooting Erratic Performance and No Code**

## **10.4 CHECK ENGINE LIGHT AND STOP ENGINE LIGHT FAULT**

The following steps will troubleshoot a fault with the check engine or stop engine lights. These lights are used to alert the operator of engine faults; flash any trouble codes stored in the ECM; and illuminate for five seconds and then go out during a start sequence, as a bulb check.

### **10.4.1 Determine Fault**

Perform the following to determine fault:

1. If the CEL or SEL is always on, refer to section 10.4.2.
2. If the CEL or SEL never lights, refer to section 10.4.5.

### **10.4.2 Display ECM Light Status**

Perform the following steps to display light status:

1. While the light is lit, plug in the DDR (ignition ON).
2. Select switch light status.
3. View the displayed status for the problem light.
  - [a] If status reads OFF, refer to section 10.4.4.
  - [b] If status reads ON, refer to section 10.4.3.

### **10.4.3 Determine Reason for ECM Request**

Perform the following steps to determine the reason the ECM is requesting the light to be ON:

1. Verify the diagnostic request is not ON.
  - [a] If the diagnostic request is ON, refer to section 10.10.
  - [b] If the diagnostic request is not ON, refer to section 9.1, (troubleshoot code).

#### 10.4.4 Check for Grounded Wire

Perform the following steps to check for a grounded wire:

1. Turn ignition OFF.
2. Unplug VIH 30-pin connector.
3. Turn ignition ON.
  - [a] If the light stays on, drive (#509 or #419) wire is shorted to the ground. Repair or replace the wire. Refer to section 10.4.9.
  - [b] If the light goes off, clean the connectors of the VIH 30-pin and assemble again. Then, refer to section 10.4.9.

#### 10.4.5 Activate Light With Diagnostic Data Reader

Perform the following steps to activate the light with the DDR:

1. Turn ignition ON.
2. Plug in DDR.
3. Select Activate Outputs.
4. Activate affected light; watch status.
  - [a] If the light stays off. Refer to section 10.4.6.
  - [b] If the light illuminates, the problem no longer exists. Refer to *DDEC III Application and Installation* manual, 7SA800, to review the light operation.

#### 10.4.6 Check Bulb

Perform the following steps to check the bulb:

1. Turn ignition OFF.
2. Refer to OEM recommendations for checking bulb.
  - [a] If the bulb is bad, replace the bulb and refer to section 10.4.9.
  - [b] If the bulb is okay, refer to section 10.4.7.

### 10.4.7 Check for Voltage Supply

Perform the following steps to check the voltage supply:

1. Disconnect the power supply to the light.
2. Turn ignition ON.
3. Measure voltage between the removed connection and battery ground.
  - [a] If the voltage is correct based on the system of the vehicle (12/24V), refer to section 10.4.8.
  - [b] If the voltage is too low to expect the bulb to light, refer to the OEM recommendations to resolve the problem. Refer to section 10.4.9.

### 10.4.8 Check for Open Output Wire

Perform the following steps to check for an open output wire:

1. Measure the resistance between the ground side of the connector of the light and the battery ground.
  - [a] If the measured resistance is 45,000 to 48,000  $\Omega$ , clean the connections. Refer to section 10.4.9.
  - [b] If the measured resistance is less than 45,000  $\Omega$  or greater than 48,000  $\Omega$ , the wire is shorted to voltage, or is opened. Repair wire. Refer to section 10.4.9.

### 10.4.9 Verify Repairs

Perform the following steps to verify repairs.

1. Ensure all removed connections are installed.
2. Turn ignition ON.
  - [a] If the light comes on for five seconds, then goes out, troubleshooting is complete.
  - [b] If the light comes on and stays on, refer to section 10.4.1.
  - [c] If the light does not turn on, all troubleshooting is complete. Review this section and contact Detroit Diesel Technical Service.



## 10.5 NO DATA TO DIAGNOSTIC DATA READER

Before using this procedure, all basic mechanical checks and physical inspections should have been performed with no problem found. Also the diagnosis of the DDEC system in Section 9 referred you to this section.

### 10.5.1 Read Codes on the Check Engine Light

Perform the following steps to read the codes on the CEL or SEL:

1. Unplug the DDR.
2. Ignition should be ON; engine not running.
3. Enable diagnostic request switch.
4. Read codes flashing on the CEL and SEL.
  - [a] If codes are flashing out, refer to section 10.5.4.

#### NOTE:

If you wish to bypass diagnosis of a potential data line of the DDR problem for now, diagnose the active code by referring to the section that matches the code number.

- [b] If CEL and SEL are not flashing out codes, refer to section 10.5.2.

### 10.5.2 Check Diagnostic Request Circuit


Perform the following steps to check the diagnostic request circuit:

1. Ensure ignition is ON.
2. Plug in DDR.
3. Select Calibration Configuration.
4. Determine port assigned to Diagnostic Request on the ECM input switches.
5. Go to switch light status.
6. Depress and hold the diagnostic request switch.
7. Read status of diagnostic request.
  - [a] If the switch reads OFF, the diagnostic request circuit (#528) is open or the ground is poor or open. Repair the open wire or the bad ground. Refer to section 10.5.8.
  - [b] If the switch reads ON, refer to section 10.5.3.

### 10.5.3 Check ECM Connectors

Follow this procedure to check the ECM connectors:

1. Check the terminals at the vehicle harness and 5-way power harness connectors (both ECM and harness side) for damage: bent, corroded and unseated pins or sockets. See Figure 10-7.
  - [a] If terminals and connectors are okay, replace the ECM. Refer to section 10.5.8.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 10.5.8.




**Figure 10-7 ECM Vehicle Harness Connector**

### 10.5.4 Check for Open

Perform the following steps to check for an open:

1. Turn ignition OFF.
2. Place a jumper wire across pins A (#900) and B (#901) of the DDL connector. Unplug the vehicle harness connector and measure resistance between sockets C1 and C2.
3. Turn ignition ON, and again measure resistance between sockets C1 and C2. See Figure 10-8.
  - [a] If both readings are greater than  $5\ \Omega$ , one or both data wires (circuit #900 or #901) are open. Repair the open and refer to section 10.5.8.
  - [b] If either reading is less than  $5\ \Omega$ , refer to section 10.5.5.



**Figure 10-8 Diagnostic Connector**

### 10.5.5 Check for Short

Perform the following steps to check for a short:

1. Remove the jumper wire from the DDL connector.
2. Measure resistance between sockets C1 (#901) and C2 (#900) of the vehicle harness connector.
  - [a] If the resistance measurement is less than 5  $\Omega$ , two data wires (circuit #900 or #901) are shorted together. Repair the short and refer to section 10.5.8.
  - [b] If the measured resistance is greater than 5  $\Omega$ , refer to section 10.5.6.

### 10.5.6 Check for Short to Ignition and Ground

Perform the following steps to check for a short to ignition and ground:

1. Remove all jumpers for the DDL connector.
2. Measure resistance between sockets A (#900) and C (ignition switch), A (#900) and E (ground), B (#901) and E (ground), and B (#901) and C (ignition switch) of the DDL connector.
  - [a] If the measured resistance is less than 5  $\Omega$  on any reading, a short exists between the data wires and ignition or ground. Repair the short and refer to section 10.5.8.
  - [b] If the measured resistance is greater than 5  $\Omega$ , refer to section 10.5.7.

### 10.5.7 Check Diagnostic Data Reader on Another Engine

Follow this procedure to check the DDR on another engine:

1. Connect the DDR to another engine and read any parameter in the menu.
  - [a] If the procedure worked okay, refer to section 10.5.8.
  - [b] If the procedure did not work, the DDR is probably defective. Refer to the DDR instruction manual for repair.

### 10.5.8 Verify Repairs

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Turn ignition OFF.
6. Turn ignition ON.
7. Note status of CEL.
8. Start and run the engine for one minute.
9. Read inactive codes.
  - [a] If the DDR display reads NO DATA BEING RECEIVED FROM DATA LINK or DDEC SYSTEM NOT RESPONDING, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 10.5.1.
  - [b] If the engine starts and no codes are read on the DDR, repairs are complete.
  - [c] If the engine starts and code displays, refer to section 9.1.

## 10.6 DIAGNOSTIC REQUEST SWITCH INOPERATIVE

Before using this procedure, all basic mechanical checks and physical inspections should have been performed with no problem found. Also the diagnosis of the DDEC system in Section 9 referred you to this section.

### 10.6.1 Check Diagnostic Request Circuit

Perform the following steps to check the diagnostic request circuit:

1. Turn ignition ON; engine not running.
2. Plug in DDR.
3. Select Switch/Light Status.
4. Depress and hold diagnostic request switch.
5. Observe the Diagnostic Request Status on the DDR.
  - [a] If the display reads ON, refer to section 10.6.2.
  - [b] If the display reads OFF, the diagnostic request line (#528) is open, or is not being grounded when the switch is depressed. Check the #528 wire and ground for diagnostic request switch. Repair the problem; refer to section 10.6.4.
  - [c] If no diagnostic request on the DDR input list, the ECM is not configured for diagnostic request operation. Refer to the *DDEC Application and Installation* manual, 7SA800.

### 10.6.2 Check Stop Engine Light and Check Engine Light Bulbs

Perform the following steps to check the SEL and CEL bulbs:

1. Turn ignition OFF.
2. Remove CEL and SEL bulbs. Check to see if either is burned out or damaged.
  - [a] If the bulbs are okay, refer to section 10.6.3.
  - [b] If the bulbs are defective, replace the bulbs. Refer to section 10.6.4.

### 10.6.3 Check 12 / 24V Ignition Line

Perform the following steps to check the 12/24V ignition line:

1. Turn ignition ON.
2. Disconnect vehicle harness connector at ECM.
3. Measure voltage at cavity B3 (#439).
  - [a] If voltage measurement is less than 11.5V, the 5 amp fuse or circuit breaker is blown, and the ignition line could be open or shorted to ground.
  - [b] If the voltage measurement is greater than 11.5V, the circuit #419 or #509 is open. Repair the open. Refer to section 10.6.4.

### 10.6.4 Verify Repairs

Perform the following steps to verify repairs:

1. Reconnect all connectors.
2. Turn ignition ON.
3. Press diagnostic request switch.
  - [a] If codes flash, the system is working. Repairs are complete. If any other problems exist, refer to section 9.1.
  - [b] If the system does not function, all system diagnostics are complete. Review this section to find the error. Refer to section 10.6.1.

## 10.7 CRUISE CONTROL INOPERATIVE

Before using this procedure, all basic mechanical checks and physical inspections should have been performed with no problem found. Also the diagnosis of the DDEC system in Section 9 referred you to this section.

### 10.7.1 Determine Type of Cruise Control System

Perform the following to determine the type of cruise control system:

1. Check that this is a DDEC cruise control system.
2. Turn ignition ON.
3. Plug DDR into DDL connector.
4. Select calibration configuration (cruise control).
5. Is cruise control enabled?
  - [a] If cruise control is enabled, refer to section 10.7.3.
  - [b] If cruise is not enabled, refer to *DDEC III Installation and Application* manual, 7SA800, for requirements of installing cruise control.

### 10.7.2 Check ECM Connectors

Perform the following to check the ECM connectors:

1. Disconnect the vehicle harness connector at the ECM.
2. Check the terminals at the ECM vehicle harness connector (both ECM and harness side) for damaged, corroded, or unseated pin or sockets.
  - [a] If terminals and connectors are not damaged, reprogram the ECM.  
Refer to section 10.7.16.
  - [b] If the terminals or connectors are damaged, repair them. Refer to section 10.7.16.



### 10.7.3 Check Pin Assignments

Perform the following to check pin assignments:

1. Turn ignition ON.
2. Plug in the DDR.
3. Select calibration configuration (ECM Ins/Outs).
4. Write/print pin assignments.
  - [a] An example listed in Table 10-2 shows pins, wires and functions. Refer to section 10.7.4.

Pin	Wire	Function
J1	#541	set/coast on
F2	#544	cruise enable
G2	#543	svc brk rel
J2	#531	clutch rel
G3	#545	res/accel on

**Table 10-2 Pin Assignments**

- [b] If the functions are not assigned, reprogram the ECM. Refer to section 10.7.16.

### 10.7.4 Checking Out of Cruise Control Switch and Wiring

To speed up the checking out of cruise control switches, quick check tables have been developed. These tests are to be run with the ignition ON, and the engine not running. A DDR must be plugged into the connector. All three quick check tables must be gone through to completely check out the cruise control wiring and switches.

For Example: Listed in Table 10-3, step 2, you would do the following:

1. Ignition ON; engine not running; DDR plugged in.
2. Turn the cruise enable switch to ON.
3. Select switch/light status on the DDR.
4. Note the DDR display; if ON, check out brake and clutch switch as listed in Table 10-4.

Step	Cruise Enable Switch	Set / Coast Switch	Res / Accel Switch	DDR Readout Being Looked At	DDR Display	Okay	Go To
1.	Off	Off	Off	Cruise Enable	Off On	Yes No	Refer to step 2; Refer to section 10.7.5
2.	On	Off	Off	Cruise Enable	Off On	No Yes	Refer to section 10.7.6; Listed in Table 10-4, step 1

**Table 10-3 Cruise Control Quick Check Table I, Check Out Cruise Enable Switch and Wiring (Ignition ON Not Running)**

Step	Cruise Enable Switch	Brake Pedal	Clutch Pedal	DDR Readout Being Looked At	DDR Display	Okay	Go To
1.	On	Released	Released	Service Brake Release	On Off	Yes No	Refer to step 2 Refer to section 10.7.7
2.	On	Depressed	Released	Service Brake Release	On Off	No Yes	Refer to section 10.7.8 Refer to step 3
3.	On	Released	Released	Clutch Release	On Off	Yes No	Refer to step 4 Refer to section 10.7.9
4.	On	Released	Depressed	Clutch Release	On Off	No Yes	Refer to section 10.7.10; Listed in Table 10-5, step 1

**Table 10-4 Cruise Control Quick Check Table II, Check Out Brake and Clutch Switch and Wiring (Ignition ON Not Running)**

Step	Cruise Enable Switch	Set / Coast Switch	Res / Accel Switch	DDR Readout Being Looked At	DDR Display	Okay	Go To
1.	On	Off	Off	Set/Coast On	Off On	Yes No	Refer to step 2 Refer to section 10.7.11
2.	On	On	Off	Set/Coast On	Off On	No Yes	Refer to section 10.7.12 Refer to step 3
3.	On	Off	Off	Res/Accel On	Off On	Yes No	Refer to step 4 Refer to section 10.7.13
4.	On	Off	On	Res/Accel On	Off On	No Yes	Refer to section 10.7.14 Refer to section 10.7.15

**Table 10-5 Cruise Control Quick Check Table III, Check Out Set/Coast and Resume/Accel Switches and Wiring (Ignition ON Not Running)**

### 10.7.5 Check for Short at the Cruise Enable Circuit

Perform the following steps to check for a short at the cruise enable circuit:

1. Turn ignition ON.
2. Turn cruise engage switch to off.
3. Disconnect the vehicle harness connector at the ECM.
4. Measure resistance between the cruise enable cavity (i.e. F2) on the vehicle harness connector and a good ground.
  - [a] If the resistance measurement is less than or equal to 10,000  $\Omega$ , reconnect the vehicle harness. Turn the ignition on. Then run steps listed in Table 10-4; and listed in Table 10-5. If any DDR display received is not okay, refer to the indicated step. If all steps listed in Table 10-4 and listed in Table 10-5, pass, then the cruise engage wire is shorted to the ground. Repair the short, or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is greater than 10,000  $\Omega$ , refer to section 10.7.2.

### 10.7.6 Check for Open at the Cruise Enable Circuit

Perform the following steps to check for an open at the cruise enable circuit:

1. Turn ignition ON.
2. Disconnect the vehicle harness connector at the ECM.
3. Turn cruise enable switch to ON.
4. Measure resistance between the cruise enable cavity (i.e. F2) on the vehicle harness connector and a good ground.
  - [a] If the resistance measurement is greater than 5  $\Omega$ , or open, the cruise engage switch is bad, circuit #953 is open or the cruise enable wire is open. Repair the open or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 10.7.2.

### 10.7.7 Check for Open or Miswired Brake Switch

Perform the following steps to check for an open or miswired brake switch:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Ensure the service brake is not engaged.
4. Measure resistance between the service brake cavity (i.e. G2) on the vehicle harness connector and a good ground.
  - [a] If the resistance measurement is greater than 5  $\Omega$ , or open, the brake switch is miswired or faulty, circuit #953 is open or the ground is bad. Repair the open, rewire or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 10.7.2.

### 10.7.8 Check for Short at the Brake Switch or Circuit

Perform the following steps to check for a short at the brake switch or circuit:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Engage the service brake.
4. Measure resistance between the service brake cavity (i.e. G2) on the vehicle harness connector and a good ground.
  - [a] If the resistance measurement is less than or equal to 10,000  $\Omega$ , the brake switch is miswired or the service brake circuit is shorted to ground. Rewire, repair the short or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is greater than 10,000  $\Omega$ , or open, refer to section 10.7.2.

### 10.7.9 Check for Open or Miswired Clutch Switch

Perform the following steps to check for an open or miswired clutch switch:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Ensure the clutch is not engaged.
4. Measure resistance between the clutch cavity (i.e. J2) on the vehicle harness connector and a good ground.
  - [a] If the resistance measurement is greater than 5  $\Omega$ , or open, the clutch switch is miswired or faulty, circuit #953 is open, or there is a bad battery ground. Rewire, repair the short or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 10.7.2.

### 10.7.10 Check for Short at the Clutch Service/Circuit

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Engage the clutch.
4. Measure resistance between the clutch cavity (i.e. J2) on the vehicle harness connector and a good ground.
  - [a] If the resistance measurement is less than or equal to 100  $\Omega$ , the clutch switch is miswired or faulty, or the clutch circuit is shorted to ground. Rewire, repair the short or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is greater than 100  $\Omega$ , or open, refer to section 10.7.2.

### 10.7.11 Check for Short at the Set/Coast Circuit

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Measure resistance between the set/coast cavity (i.e. J1) and a good ground.
  - [a] If the resistance measurement is less than or equal to 100  $\Omega$ , the set/coast switch is shorted, or a short to ground exists in the set/coast circuit (i.e. #541). Repair the short or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is greater than 100  $\Omega$ , refer to section 10.7.2.

### 10.7.12 Check for Open at the Set/Coast Circuit

Perform the following steps to check for an open:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Find a means to press and hold the set/coast switch.
4. Measure resistance between the set/coast cavity (i.e. J1) and a good ground.
  - [a] If the resistance measurement is greater than 5  $\Omega$ , or open, the set/coast switch is open or miswired, circuit #953 is open, or there is a bad battery ground. Rewire, repair the short or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 10.7.2.

### 10.7.13 Check for Short at the Res/Accel Circuit

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Measure resistance between the Res/Accel cavity (i.e. G3) and a good ground.
  - [a] If the resistance measurement is less than or equal to 100  $\Omega$ , the Res/Accel switch is shorted, or a short to ground exists in the Res/Accel circuit (i.e. #541). Repair the short or replace the switch. Refer to section 10.7.16.
  - [b] If the resistance measurement is greater than 100  $\Omega$ , refer to section 10.7.2.

### 10.7.14 Check for Open at the Res/Accel Circuit

Perform the following steps to check for an open:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Find a means to press and hold the Res/Accel switch.
4. Measure resistance between the Res/Accel cavity (i.e. G3) and a good ground.
  - [a] If the resistance measurement is greater than 5  $\Omega$ , or open, the Res/Accel switch is open or miswired, circuit #953 is open or the battery ground is bad. Repair the short, replace the switch, or rewire. Refer to section 10.7.16.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 10.7.2.

### 10.7.15 Verify Problem Still Exists

Perform the following steps to verify the problem still exists:

1. If you were referred to this step, you have completed the switch checkout process without detecting a fault.
2. Take the vehicle for a road test and check the cruise control operation.
  - [a] If the cruise control operates correctly, the problem no longer exists. If any other problems exist, refer to section 9.1.
  - [b] If the cruise control does not operate correctly, check the vehicle speed sensor. Refer to section 54.1.

### 10.7.16 Verify Repairs

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Road test the vehicle.
  - [a] If the cruise control operates correctly, troubleshooting is complete.
  - [b] If the cruise control does not operate correctly, all system diagnostics are complete. Review this section from the start to find the error. Refer to section 10.7.1.



## 10.8 FAN OPERATIONAL CONCERN (ON/OFF TYPE)

This section covers only the DDEC controlled fan operation, (fan type single, dual or two-speed). If the function is assigned, see description of DDEC fan control logic, listed in Table 10-6.

Cavity	Wire#	Function	Output/Input
X#	#	Fan Control 1	Output - Required
X#	#	Aux. Fan Control	Input - Optional
X#	#	Fan Override	Input - Optional

**Table 10-6 DDEC Fan Control Logic Description**

### 10.8.1 Digital Fan Operation

Items used in digital fan operation include:

1. The ECM provides ground (output Fan Control 1) and should be wired such that when this cavity grounds, the fan should turn off. When the circuit goes open, the fan should turn on.
2. When Aux. Fan Control is configured (input), this wire must be connected to battery ground, or the fan will always be on. Typically, this is used with an air conditioning pressure switch. High pressure opens this circuit, and turns the fan on for a minimum time that can be set with the programming station on later ECM software versions.
3. Fan Override - Grounding this wire will turn the fan on. This would normally be an OEM supplied switch on the dash.

Other than these items, the ECMs fan control output opens, turning the fan on due to engine temperatures that are above the programmed limits. Once a fan output turns the fan on for whatever reason, all fan off temperatures must be met before the fan will turn off.

Temperatures for most highway applications are listed in Table 10-7.

Fan Control	Actual Fan Status	Coolant Temp	Oil Temp	Air Temp
Fan Control - 1	Fan ON	96°C / 204°F	110°C / 230°F	66°C / 150°F
Fan Control - 2	Fan ON	98°C / 208°F	113°C / 235°F	N/A
Fan Control	Fan OFF	92°C / 197°F	104°C / 219°F	49°C / 120°F

**Table 10-7 Highway Application Temperatures**

These temperature limits are only changeable in the base calibration.

## 10.8.2 Check Output Status

Perform the following steps to troubleshoot a fan operation problem:

1. Start engine.
2. Ensure the air conditioning of the vehicle is OFF.
3. Run engine for at least three minutes.
4. Plug in DDR.
5. Select switch / light status.
6. Check the status of the Fan Control #1 while noting the actual fan status as listed in Table 10-8.

	Status	Status	Status	Status	Status
Fan Control #1	ON/GND	OFF/OPN*	OFF/OPN	ON/GND	OFF/OPN
Actual Fan State	OFF	ON	ON	ON	OFF
	Refer to section 10.8.3	Refer to section 10.8.3	Refer to section 10.8.4	Refer to section 10.8.7	Refer to section 10.8.8

\* Hot engine

**Table 10-8 Troubleshooting Fan**

## 10.8.3 Fan Information

The steps that led to this procedure do not indicate a problem with the fan control logic in the ECM. The fan operation is normal if the steps that you checked led you to this section.

The fan status is correct according to what the ECM is requesting.

If you believe the fan state should be different, review the DDEC application and installation manual for information on fan control configuration.

### 10.8.4 Check Input Status

Read the status of the inputs used for fan operation listed in Table 10-9. (Note both together.)

	Status	Status	Status
Aux. Fan Control	OFF/OPN	ON/GRD	ON/GRD
Fan Override	OFF/OPN	ON/GRD	OFF/OPN
	Refer to section 10.8.6	Refer to section 10.8.9	Refer to section 10.8.3

**Table 10-9 Input Status**

### 10.8.5 Check Auxiliary Fan Control Request

Perform the following tests to check the auxiliary fan control switch:

1. Turn A/C OFF and ignition ON.
2. Is the auxiliary fan control status ON?
  - [a] If the auxiliary fan control is on, this should not request the fan on; this is normal.  
The fan may remain on for up to three minutes after auxiliary fan control is turned on.
  - [b] If the auxiliary fan control is off, check that a normally open pressure switch is not installed; then, refer to section 10.8.6.

## 10.8.6 Check for Input Open

Perform the following tests to check for an open:

1. Turn ignition OFF.
2. Disconnect vehicle 30-pin connector at the ECM.
3. Turn ignition ON.
4. Measure resistance between auxiliary fan control wire and a good ground.
  - [a] If the measured resistance is greater than 1,000  $\Omega$ , an open exists in the auxiliary fan control wire, or auxiliary fan control is configured and not wired, or the switch is bad. Repair open or replace the switch if an auxiliary fan control is used. If this feature is not to be used, disable the auxiliary fan control with the programming station. Refer to section 10.8.11.
  - [b] If the measured resistance is less than or equal to 1,000  $\Omega$ , refer to section 10.8.10.

Perform the following steps to troubleshoot fan always on. The steps that led to this procedure do not indicate a problem with the fan control logic in the ECM. The fan operation is normal if the steps that you checked led you to this section.

## 10.8.7 Check for Output Open

Perform the following steps to check for an output open:

1. With ignition off, locate OEM supplied wire used for Fan Control #1.
2. Determine where the wire terminates. (e.g. fan solenoid, relay, data module, etc.)
3. Disconnect the Fan Control #1 wire at the solenoid/relay.
4. Turn ignition ON.
5. Measure resistance between the fan control #1 wire and a good ground, battery (-).
  - [a] If the measured resistance is greater than 48,000  $\Omega$  or open, an open exists in the FC#1 wire. Repair the open. Refer to section 10.8.11.
  - [b] If the measured resistance is less than or equal to 48,000  $\Omega$ , refer to section 10.8.10.

### 10.8.8 Check for Output Short

Perform the following steps to check for an output short:

1. With ignition off, locate OEM supplied wire used for Fan Control #1.
2. Determine where the wire terminates. (e.g. fan solenoid, relay, data module, etc.)
3. Disconnect the Fan Control #1 wire at the solenoid/relay.
4. Measure resistance between the fan control #1 wire and a good ground, battery (-).
  - [a] If the measured resistance is greater than 1,000  $\Omega$  or open, refer to section 10.8.10.
  - [b] If the measured resistance is less than or equal to 1,000  $\Omega$ , the output wire is shorted to ground, keeping the fan off. Repair the short or replace the wire. Refer to section 10.8.11.

### 10.8.9 Check Override Request

Perform the following steps to check the fan override switch:

1. Is the fan override switch on?
  - [a] If the fan override is on, and the fan override is requesting fan on, this is normal.
  - [b] If the fan override is not on, the fan override wire is shorted to ground, repair the short or re-configure the input if this is an error in programming. Refer to section 10.8.11.

### 10.8.10 Check Connectors

Perform the following steps to check the connectors:

1. Check connectors for damaged, bent, or corroded terminals.
  - [a] If the pins and terminals are not damaged, the problem may be due to the solenoid, ECM, or OEM device that operates the fan. Contact the OEM for further information or instructions. The ECM and wiring between the ECM and device appear to be operating correctly and in good repair. The ECM is requesting the fan operation correctly and the checks indicate the ECM and wire between the ECM and OEM device is okay.
  - [b] If the pins or terminals are damaged, repair or replace them. Refer to section 10.8.11.

### 10.8.11 Verify Repairs

Perform the following steps to verify repairs:

1. Connect any removed connectors.
2. Start engine.
3. Operate engine under conditions that brought you to this section.
4. Check fan operation.
  - [a] If the fan operates correctly, troubleshooting is complete.
  - [b] If the fan does not operate correctly, review this section from the first step to find the error.

## 10.9 FAN OPERATIONAL CONCERN (VARIABLE SPEED TYPE)

The DDEC system via a PWM (Pulsewidth Modulation) signal will go to a high voltage (7-8 volts on a 12-volt system) on a cold engine for a low speed, and to a low voltage (0.8 - 1.0 volts on a 12-volt system) for a high speed.

Fan speed is ramped up as temperatures increase, as listed in Table 10-10. Calibrations can vary. The table is provided only as a guide.

Coolant Temperature	Speed
up to 197°F	Low speed
about 203°F	Medium speed
208°F and above	High speed

**Table 10-10 Fan Speed vs Temperature**

### 10.9.1 Verify Correct DDEC Configuration

Perform the following steps to verify the configuration:

1. Turn ignition ON.
2. Plug in DDR.
3. Select "View Calibration" (ECM Ins/Outs).
4. Review PWM functions to determine correct pin assignment for PWM fan.
  - [a] If the cavity is assigned to PWM Fan, refer to section 10.9.2.
  - [b] If the cavity is not programmed, reprogram the ECM and refer to section 10.9.7.

## 10.9.2 Check for Signal

Perform the following steps to check for signal:

1. Start and run the engine at idle.
2. Plug in DDR.
3. Review engine data list and watch the pulsewidth modulation number x wire = # of fan assignment (normally PWM#4).
4. Verify coolant, oil and air temperatures are cooler, less than 150 ° F. Verify the air conditioning input is grounded (On).
  - [a] If the PWM value is 80 to 90% and the fan is at Low Speed, refer to section 10.9.3.
  - [b] If the PWM value is 80 to 90% and the fan is at High Speed, refer to section 10.9.4.

## 10.9.3 Check Signal Engine Hot

Perform the following steps to check the signal status:

1. Start engine and warm up. Road test (until coolant temp is about 200 ° F).
2. View DDR data list display, Coolant Temp/PWM # (normally #4).
  - [a] If PWM % decreases as the temperature increases, all checks appear normal. If this is an intermittent high speed operation, check A/C Freon pressure switch or wiring for an intermittent open. Refer to section 10.9.7.
  - [b] If PWM % decreases as the temperature increases, but the fan speed stays low, refer to section 10.9.5.



#### 10.9.4 Check for Open

Perform the following steps to check for an open:

1. Turn ignition OFF.
2. Unplug PWM wire at the fan control valve.
3. Install a jumper between the PWM wire and the battery (-).
4. Unplug the engine harness connector.
5. Measure resistance between the PWM cavity and the battery (-).
  - [a] If the measured resistance is greater than 1,000  $\Omega$ , the wire is open. Repair the open and refer to section 10.9.7.
  - [b] If the measured resistance is less than 1,000  $\Omega$ , the valve or wiring (voltage supply) to the valve is defective. Replace.

#### 10.9.5 Check for Short

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Unplug the engine harness connector.
3. Measure resistance between the PWM cavity and several ground sources (battery, chassis, etc.).
  - [a] If the measured resistance is greater than 1,000  $\Omega$ , refer to section 10.9.6.
  - [b] If the measured resistance is less than 1,000  $\Omega$  at any time, the wiring is shorting. Replace the wire and refer to section 10.9.7.

### **10.9.6 Check Connectors**

Perform the following steps to check the connectors:

1. Check for damaged, bent or corroded connectors, pins, and terminals.
  - [a] If the connectors, pins, and terminals are not damaged, contact the OEM or fan valve supplier for instructions on further troubleshooting. If the ECM and wiring to the component appear to be okay, the problems could be with the control valve or battery and wiring.
  - [b] If the connectors, pins or terminals are damaged, repair or replace them and refer to section 10.9.7.

### **10.9.7 Verify Repairs**

Perform the following steps to verify repairs:

1. Connect all removed connectors, etc.
2. Start and run the engine from cold to hot, while watching the fan speed operation.
  - [a] If the operation is normal, troubleshooting is complete.
  - [b] If the operation is not normal, all system diagnostics are complete. Review this section to find the error. Refer to section 10.9.1.

## 10.10 ENGINE BRAKE INOPERATIVE

The following procedure will troubleshoot DDEC controlled Engine Brake Inoperative.

### 10.10.1 Engine Brake Inoperative

Perform the following steps to troubleshoot the inoperative engine brake:

1. Turn ignition ON.
2. Plug in DDR.
3. View Diagnostic Data List to see if the correct application is programmed into the ECM.
4. Next to Engine Brake, the display should read ON or OFF. If it reads N/A, the DDC mainframe must be changed and the ECM must be reprogrammed after the change is made.
5. If the ECM is correctly configured, go to the view calibration area with the DDR and check to ensure that the two required inputs (Engine Brake Low and Engine Brake Medium) are configured.
6. If the inputs are not configured, or incorrectly configured, this must be corrected using the DDEC reprogramming station.
7. If the inputs are configured correctly, print or write down the inputs and outputs for future reference. Refer to section 10.10.2. Refer to the appropriate Application and Installation manual for engine brake operation.

### 10.10.2 Check Switches

Perform the following steps to troubleshoot the switches:

1. Turn ignition ON.
2. Plug in DDR.
3. Select Switch Light status - Inputs.
4. View DDR display of Eng Brk Low and Eng Brk Med.

**NOTE:**

Set brake dash switch position on low.

- [a] If Eng Brake Low is ON and Eng Brake Med is OFF, refer to section 10.10.3.
  - [b] If Eng Brake Low is ON and Eng Brake Med is ON, medium and low inputs are shorted to each other. Repair. Refer to section 10.10.9.
  - [c] If Eng Brake Low is OFF and Eng Brake Med is ON, input wires are reversed. Correct and refer to section 10.10.9.
  - [d] If Eng Brake Low is OFF and Eng Brake Med is OFF, refer to section 10.10.4.
5. Turn brake enable dash switch on.

### 10.10.3 View Diagnostic Data Reader Display

Perform the following steps to troubleshoot the inoperative engine brake:

1. View DDR display.

**NOTE:**

Set brake dash switch position on medium.

- [a] If Eng Brake Low is OFF and Eng Brake Med is ON, refer to section 10.9.5.
- [b] If Eng Brake Low is ON and Eng Brake Med is ON, medium and low inputs are shorted to each other. Repair. Refer to section 10.10.9.
- [c] If Eng Brake Low is ON and Eng Brake Med is OFF, input wires are reversed. Correct and refer to section 10.10.9.
- [d] If Eng Brake Low is OFF and Eng Brake Med is OFF, refer to section 10.10.4.

### 10.10.4 Check for Open

Perform the following steps to check for an open:

1. Turn ignition OFF.
2. Turn engine brake switch to low.
3. Measure resistance between the engine brake low switch and a good ground (ECM side).
4. Set switch to Med. Measure resistance between medium input and a good ground.
  - [a] If the measured resistance is less than 10,000  $\Omega$ , either the switch is bad or the wire from the switch to the battery ground is bad. Replace the switch or repair the open.
  - [b] If the measured resistance is greater than 10,000  $\Omega$ , or open, an open exists in the input wire. Repair the open. Refer to section 10.10.9.

### 10.10.5 View Calibration - Engine Configuration

Perform the following steps to view calibration - engine configuration:

1. Go to View Cal-Eng Configuration. Check status of Eng Brk Serv Brk and Eng Brk mph. If Eng Brk Serv Brk indicates YES, or Eng Brk Min mph has number other than "0", check with the operator to ensure he or she understands how these functions operate.
  - [a] If the Eng Brk Serv Brk indicates YES, the application of service brake is required for engine brake operation.
  - [b] If the Eng Brk Min mph has a number other than "0", the brakes will not operate below this mph.

**NOTE:**

These two functions may work separately or together.

- [c] If the Eng Brk Svc Brk indicate No, and Eng Brk Min mph indicate 0, refer to section 10.10.6.

### 10.10.6 Check Engine Brake Operation

Perform the following steps listed in Table 10-11 to check out the brake and clutch switch, and the wiring.

**NOTE:**

If table below leads to section 10.11, troubleshoot clutch and brake inputs. Then check operation of engine brake. If engine brake is still inoperative, refer to section 10.10.7.

1. Turn ignition ON. Engine must not be running.
2. Plug in DDR. Select switch/light status.

Step	Brake Pedal	Clutch Pedal	DDR Readout Looked At	DDR Display	Status OK	Reference
1.	Released	Released	Service Brake (Release)	On Off	Yes No	refer to Step 2 refer to section 10.11
2.	Depressed	Released	Service Brake Release	On Off	No Yes	refer to section 10.11 refer to Step 3
3.	Released	Released	Clutch Release	On Off	Yes No	refer to Step 4 refer to section 10.11
4.	Released	Depressed	Clutch Release	On Off	No Yes	refer to section 10.11 refer to section 10.10.7

**Table 10-11 Engine Brake Operation**

### 10.10.7 Check Brake Solenoids

Perform the following steps to troubleshoot the brake solenoids:

1. Check engine brake solenoids. Refer to OEM guidelines.
  - [a] If solenoids are okay, refer to section 10.10.8.
  - [b] If solenoids are bad, repair or replace the solenoids. Refer to section 10.10.9.

### 10.10.8 Verify Conditions

Perform the following steps to verify conditions:

1. Verify proper conditions are being met to enable engine brake:
  - [a] TPS % = 0 %
  - [b] Pulse width = 0 (or less)
  - [c] Engine speed >850 r/min
  - [d] Clutch release (input) = ON (if configured)
  - [e] Engine brake disable (input) = OFF (Auto Trans)
2. Are the conditions listed in 1a through 1e met?
  - [a] If conditions are not met, correct the problem (i.e. TPS). Refer to section 10.10.9.
  - [b] If the conditions are met, reprogram the ECM. Contact the OEM for possible TPS repair. Then, refer to section 10.10.9.

### 10.10.9 Verify Repairs

Perform the following steps to verify repairs:

1. Reinstall all connectors.
2. Test drive vehicle to see if the problem is corrected.
  - [a] If engine brakes operate correctly, troubleshooting is complete.
  - [b] If engine brakes do not operate, all system diagnostic checks are complete. Review this section to find the error. Refer to section 10.10.1, or contact Detroit Diesel Technical Service for possible ECM replacement.

## 10.11 MISCELLANEOUS DIGITAL INPUT FAULT

The following procedure will cover miscellaneous input switch faults. All faults function in the same manner, allowing the same troubleshooting process to be used regardless of the function.

There are 12 digital input cavities, listed in Table 10-12, available on a DDEC ECM. Any available function can be assigned (programmed with the Programming Station) to any of the available cavities.

When a digital input wire is switched to battery ground (usually #953), it is a request to the ECM to activate the function assigned to that wire. Additional conditions may need to be met for the feature to activate. Refer to the appropriate Application and Installation Manual for these conditions.

Input Cavities	Input Cavities
E1 #451	G2 #543
F1 #542	H2 #524
G1 #528	J2 #531
H1 #523	K2 #583
J1 #541	G3 #545
F2 #544	K3 #979

**Table 10-12 Input Cavities**

Available functions are listed in Table 10-13.

Functions	Functions	Functions
None	Limiting Torque Curve	Trans Retarder Status
Engine Brake Low	Diagnostic Request	Dual Throttle (LSG)
Engine Brake Med	Alt Min VSG/Fast Idle	A/C Fan Status
Aux Shutdown #1	Service Brake Release	Aux CLS
Aux Shutdown #2	Clutch Released	Fan Control Override
Park Brake / ISD	Set Coast OFF DDEC II	VSG Station Change
Idle Validation	Set / Coast ON	VSG Station Complement
Pressure / RPM Mode	Resume/Accel OFF DDEC II	Air Load Switch
Throttle Inhibit	Resume / Accel ON	In Neutral Switch
RPM Sync (Marine)	Cruise Enable	In Gear Switch
RPM Freeze (Marine)	PGS System Enable	KD Brake
Rating Switch #1	SEO / DIAG Request	Gas Valve Diagnostic
Rating Switch #2	Engine Brake Disable	-


**Table 10-13 Available Input Functions**



### 10.11.1 Verify Switch Status

Follow these steps to verify the switch status.

1. Turn ignition ON.
2. Plug in DDR.
3. Select switch light status.
4. Operate the engine or vehicle that would allow the feature to activate (e.g. activate switch, set brake, etc.).
5. Observe the status when the feature is active (or supposed to be active). See Figure 10-9.
  - [a] The feature always reads OFF. Refer to section 10.11.2.
  - [b] The feature switches from OFF to ON. Refer to section 10.11.3.
  - [c] The feature always reads ON. This indicates the input wire is shorted to ground or the switch is faulty. Repair wire or replace switch. Refer to section 10.11.4.



**Figure 10-9 ECM Vehicle Harness Connector**

### 10.11.2 Check for Open

Perform the following steps to check for an open:

1. Turn ignition OFF.
2. Unplug the vehicle interface harness connector at the ECM.
3. Operate switch. Enable the feature.
4. Measure the resistance between the input cavity affected and the battery ground.
  - [a] If the measured resistance is greater than 10,000  $\Omega$ , the input wire or ground wire is open, or the switch is bad. Repair the open or replace the switch. Refer to section 10.11.4.
  - [b] If the measured resistance is less than 10,000  $\Omega$ , refer to section 10.11.3.

### 10.11.3 Review the Operation of the Feature

Perform the following steps to check the operation of the feature:

1. The step that led you here indicates the input, wire, and switch, are operating correctly. Review the intended operation of the feature to determine if any other conditions need to be met for the feature to operate. (e.g. appropriate Application and Installation manual for the engine). Refer to section 2.4, for a list of related troubleshooting publications.
2. To verify the repairs to the feature, refer to section 10.11.4.

### 10.11.4 Verify Repairs

Perform the following steps to verify repairs.

1. Hook up all connectors that were previously removed.
2. Operate the engine or vehicle.
3. Activate the feature.
  - [a] If the input feature operates correctly, troubleshooting is complete.
  - [b] If the input feature is not operating, contact Detroit Diesel Technical Service.

## 10.12 MISCELLANEOUS DIGITAL OUTPUT FAULT

This section is designed to diagnose an output fault (feature not functioning). Since all outputs operate in the same manner, this troubleshooting section can be used regardless of the function assigned.

### 10.12.1 DDEC ECM

The DDEC ECM has six available digital output cavities. Three are located at the engine harness connector and three at the vehicle harness connector. Output functions (features) are assigned (programmed with the programming station) to any available cavity. The ECM switches the cavity to battery (-) to allow the function to activate. Some output activation is dependent on other parameters being met. (e.g. minimum, r/min, etc.) Perform the following steps to check the DDR for codes. Available output cavities are listed in Table 10-14.

Additional outputs could be added at a later date. Available functions are listed in Table 10-15.

Output Cavities	Output Cavities
VIH	ESH
A1 #988	W3 #563
A2 #555	X3 #564
F3 #499	Y3 #565

**Table 10-14 Output Cavities**

Functions	Functions	Functions
No Function	Fan Control #2	Turbo Recirc Valve
Low DDEC Volt	Deceleration Light	Optimized Idle Active
RPM Sync Active	Engine Brake Active	Low Range Solenoid (ESS)
PGS Active Light	VSG Active Indication	High Range Solenoid (ESS)
Vehicle Power Down	Oil Pressure Low Light	Shift Solenoid (Top2)
Starter Lockout	Oil Temp High Light	Shift Lockout (Top2)
Ext Brake Enable	Coolant Temp High Light	Gas Throttle Actuator
Trans Retarder Enable	Air Comp Solenoid	Fuel Supply Solenoid
Coolant Level Low Light	Crankcase Pressure High	KD Brake Solenoid
Cruise Active Light	Coolant Pressure Low	-
Fan Control #1	Ether Start	-

**Table 10-15 Available Output Functions**

### 10.12.2 Activate Output

Perform the following steps to attempt activation to troubleshoot an output fault.

1. Turn ignition ON.
2. Plug in DDR. Select ACTIVATE OUTPUTS.
3. Activate output associated with the fault.

**NOTE:**

Service any other codes first.

- [a] If the feature operates (e.g. light illuminates or solenoid activates, etc.) review the Application and Installation manual for the operation of the designated feature. Operation is dependent on other parameters. Refer to section 10.12.6.
- [b] If the feature does not operate or cannot be activated, refer to section 10.12.3.

### 10.12.3 Check for Open

Perform the following steps to check for open:

1. Turn ignition OFF.
2. Locate device end of output wire (e.g. light) and disconnect wire.
3. Turn ignition ON.
4. Measure resistance between the disconnected wire and battery (-).
  - [a] If the measured resistance is less than 46,000-48,000  $\Omega$ , refer to section 10.12.4.
  - [b] If the measured resistance is greater than 48,000  $\Omega$ , the wire is open. Refer to section 10.12.6.

### 10.12.4 Check for Voltage

Perform the following steps to check the voltage:

1. Measure voltage between the disconnected wire and a good ground.
  - [a] If voltage measurement is less than 2 volts, refer to section 10.12.5.
  - [b] If voltage measurement is greater than 2 volts, the output is shorted to a voltage source. Replace the wire and refer to section 10.12.6.

### 10.12.5 Check for Resistance

Perform the following steps to check for resistance at the ECM:

1. Turn ignition OFF.
2. Disconnect 30-pin connector that houses the wire/function you are checking (e.g. X3-engine harness connector, A1-VIH).
3. Measure resistance between the pin on the ECM and the ECM case.
  - [a] If the measured resistance is 46,000 to 48,000  $\Omega$ , contact the OEM or the hardware of the supplier of the features. For further troubleshooting, all output wiring and ECM operation appear to be operating correctly.
  - [b] If greater than 48,000  $\Omega$ , try a test ECM. Refer to section 10.12.6.

### 10.12.6 Verify Repairs

Perform the following steps to verify repairs.

1. Connect all connectors.
2. Test the vehicle and attempt to operate the feature.
  - [a] If the feature works correctly, troubleshooting is complete.
  - [b] If the feature still does not work correctly, review this section to find the error. Refer to section 10.12.2.

## 10.13 FIRE TRUCK PRESSURE GOVERNOR FAULT

The following procedure will troubleshoot fire truck pressure governor fault.

### 10.13.1 Pressure Governor Operation

The Pressure Sensor Governor (PSG) System is a DDEC feature, programmed to allow the engine speed to change in order to maintain a steady water pump pressure (pressure mode) or hold a steady engine speed (RPM Mode).

### 10.13.2 Verify Correct Pressure Sensor Governor Configuration

Perform the following steps to verify the PSG configuration. Refer to the Application and Installation manual for the appropriate engine model to ensure correct inputs and outputs are configured. Required In / Outs are listed in Table 10-16.

1. Turn ignition ON.
2. Plug in DDR.
3. View H<sub>2</sub>O governor enabled (engine configuration).
4. View In / Outs. Verify correct configuration.
  - [a] If the system is enabled and the in/outs are correctly configured, refer to section 10.13.3.
  - [b] If the problem was found, correct the settings and retest. Refer to the *DDEC III Application And Installation* manual, 7SA800 and refer to section 10.13.10.3.

Inputs	Outputs
PGS Mode, (Press / RPM)	PGS Active
PGS Enable	Cruise Active
Res / Accel	-
Set / Coast	-

**Table 10-16 Required In / Outs**

### 10.13.3 Identify Problem

Use the following procedure to identify the problem with the PSG:

- ☐ Does not operate; refer to section 10.13.4.
- ☐ No pressure mode, refer to section 10.13.6.
- ☐ No increase function refer to section 10.13.7.
- ☐ No decrease function refer to section 10.13.8.
- ☐ EFC Fault Information refer to section 10.13.9.

### 10.13.4 Check System Ground

Perform the following steps to check the system ground:

1. Start engine.
2. Turn ON pump control switch.
3. Verify all interlocks are set (parking brake, transmission neutral, etc.).
4. Plug in DDR. Select Switch/Light status.
5. Observe the displays and PGS ENABLE.
  - [a] If PGS ENABLE reads OFF, the PGS ENABLE input (circuit #543) is not grounded. Check circuit #543 for an open between battery ground or a short to a voltage source. Repair fault and retest. Refer to section 10.13.5.
  - [b] If PGS ENABLE reads ON, refer to section 10.13.7.

### 10.13.5 Check Sensor Wiring


Perform the following steps to identify the problem:

1. Compare pressure sensor harness wiring to the diagram.
  - [a] If the wiring is correct, refer to section 10.13.9. If the EFC tests okay, refer to section 10.13.6.
  - [b] If the wiring is incorrect, correct the wiring and retest.

### 10.13.6 Verify Mode Selector Operation

Perform the following steps to identify the problem:

1. Start engine.
2. Turn ON pump control switch.
3. Verify all interlocks are set (parking brake, transmission neutral, etc.).
4. Plug in DDR. Select Switch/Light status.
5. Observe the displays and PGS MODE.
  - [a] If DDR displays ON when Pressure Mode is selected, the mode selector (circuit #523) is functioning properly. Check for possible intermittent open or short to voltage source. Check for faulty pressure transducer. Refer to section 10.13.5. See Figure 10-10.
  - [b] If the DDR displays OFF when Pressure Mode is selected, the mode selector wire (circuit #523) or switch is open or shorted to a voltage source. Repair the fault and retest. If the EFC tests okay, refer to section 10.13.9.



**Figure 10-10 Pressure Transducer and Harness Connector**



### 10.13.7 Check Resume / Accel Switch

Perform the following steps to identify the problem:

1. Start engine.
2. Turn ON pump control switch.
3. Verify all interlocks are set (parking brake, transmission neutral, etc.).
4. Plug in DDR. Select Switch/Light status.
5. Observe the displays and Res/Accel, while depressing the increase switch.
  - [a] If DDR displays OFF to ON when increase is depressed, check the EFC. Refer to section 10.13.9.
  - [b] If the DDR displays OFF when increase is depressed, circuit #541 is open or shorted to a voltage source. Repair the fault and retest.

### 10.13.8 Check Set / Coast Switch

Perform the following steps to identify the problem:

1. Start engine.
2. Turn ON pump control switch.
3. Verify all interlocks are set (parking brake, transmission neutral, etc.)
4. Plug in DDR. Select Switch/Light status.
5. Observe the displays and Set/Coast, while depressing the decrease switch.
  - [a] If DDR displays OFF to ON when Set/Coast decrease is depressed, check the EFC. Refer to section 10.13.9.
  - [b] If the DDR displays OFF when decrease is depressed, circuit #541 is open or shorted to a voltage source. Repair the fault and retest.

### 10.13.9 Electronic Fire Commander

The Detroit Diesel Electronic Fire Command™ (EFC) is designed to support Detroit Diesel engines in the fire fighting market. It combines a Pressure Sensor Governor (PSG) controller, a system monitor, and a display for vital engine operating parameters into one compact, durable package. It also provides complete control and monitoring of the DDEC engine control system on a fire truck when pumping.

#### 10.13.9.1 Pressure Sensor Governor Operating Modes

The EFC commands the Detroit Diesel PSG system to operate in one of two modes. The RPM Mode controls the engine speed to a constant number of revolutions per minute, and the Pressure Mode varies the engine speed to maintain a constant pump discharge pressure. The operating mode of the PSG can be changed from RPM Mode to Pressure Mode and back by pressing the MODE button. When the unit is first turned on, the RPM Mode is active. Pressing MODE switch engages the Pressure Mode and another press brings the system back to RPM Mode. The PSG system utilizes the engine speed or pump pressure that is current at the time the button is pressed.

In the Pressure Mode, the PSG system operates like cruise control for the water pump pressure, and maintains the pressure at a chosen setting. Engine speed is constantly adjusted to maintain the desired pump discharge pressure. A pressure sensor in the output side of the fire pump is used to measure and feed this pressure back to the DDEC Electronic Control Module (ECM).

The RPM Mode keeps the engine speed constant even when the load varies within the engine's operating capability. The pump output pressure may vary in this mode, but the engine speed does not. The driver/engineer uses the EFC to choose which of these two modes the PSG uses. The EFC also allows the driver/engineer to finely adjust the pressure setting or the engine speed setting to match prevailing conditions.

### 10.13.9.2 Setting the Revolutions Per Minute Mode

Perform the following steps to set the RPM Mode:

1. Start engine and ensure the EFC is ON.
2. Ensure the conditions are met for the Throttle Ready lamp to be ON. (These are usually interlocks necessary to allow increased throttle operation.)
3. The RPM Mode lamp should be lit, indicating the system is in RPM Mode.
4. Engine speed can be adjusted using the following buttons:
  - ☐ Press the PRESET button to command the engine to go to the preset speed.
  - ☐ Press the INC button to increase engine speed in 25 RPM increments each time the button is pressed.
  - ☐ Press and hold the INC button to increase the speed at a faster rate equivalent to 2 increments per second.
  - ☐ Press the DEC button to decrease engine speed in 25 RPM increments.
  - ☐ Press and hold the DEC button to decrease the speed at a faster rate equivalent to 2 increments per second.
  - ☐ Press the IDLE button to immediately return the engine to the normal idle speed.

### 10.13.9.3 Setting the Pressure Mode

Perform the following steps to set the Pressure Mode:

1. Start engine and adjust the system to run in the RPM Mode as described in the previous sections.
2. Ensure conditions are met for the PUMP ENGAGED and OKAY TO PUMP and THROTTLE READY lamps to be on. (This usually requires that required safety interlocks for engine speed increase and pump operation are met.)
3. Press the MODE button and the PRESSURE lamp will illuminate.
4. Pump discharge pressure can now be adjusted with the following buttons.
  - ☐ Press the PRESET button to command the engine to go to the preset pump pressure.
  - ☐ Press the INC button to increase discharge pressure in 4 PSI increments each time the button is pressed.
  - ☐ Press and hold the INC button to increase the pressure at a faster rate equivalent to 2 increments per second.
  - ☐ Press the DEC button to decrease discharge pressure in 4 PSI increments.
  - ☐ Press and hold the DEC button to decrease the pressure at a faster rate equivalent to 2 increments per second.
  - ☐ Press the IDLE button to return the engine immediately to the normal idle speed.

#### 10.13.9.4 Cavitation

If the water pump discharge pressure falls below 30 psi and the engine r/min rises a minimum of 400 r/min above the current setpoint for more than five seconds, the system considers cavitation to have occurred. It takes the following actions:

- ☐ The engine will return to idle.
- ☐ The current engine speed and discharge pressure setpoints will be cleared.
- ☐ The check engine light will illuminate and a cavitation code will be logged.

#### 10.13.9.5 Engine Parameter Display

Engine r/min, oil pressure, temperature, and system voltage are displayed continuously while the EFC is in operation. In addition, any diagnostic code accompanying a Check Engine or Stop Engine condition will be displayed on the Information Center message display. An audible alarm will also be activated with the code.

#### 10.13.10 Programming the Electronic Fire Commander

Programming the EFC is simply a matter of selecting items from a menu:

- ☐ To enter the programming menu, press and hold the MODE and MENU buttons at the same time until "Press Idle to Exit" is displayed on the information center, then release both buttons.
- ☐ Moving through the menu is accomplished by pressing the MENU button.
- ☐ Changing a selection in the menu is performed by using the INC and DEC switches.
- ☐ Exiting the programming menu is accomplished in one of two ways.
  - ☐ Press IDLE to exit the menu and save changes.
  - ☐ Press MODE to exit the menu without saving changes.

### 10.13.10.1 Programming Menu Options

As you scroll through the menu by repeatedly pressing the MENU button, the following items, listed in Table 10-17, will appear sequentially in the Information Center display.

Item	Explanation
RPM Preset Point	preset engine speed
Pressure Set (PSI)	preset PSI
Engine Hour meter	information only
Pump Hour meter	information only
Engine degrees	oil or coolant
Pump Pressure (PSI)	pressure reading, if active
DDEC Software Version	ECM revision level
EFC Software Version	EFC revision level
Fire Commander I/O Test	test switches and outputs
Press Test Lights	tests display panel
Set Time Clock	set clock
Units of Measure	English/Metric
Welcome Message	enable/disable
Codes Currently Active	information
Connector Data	displays connection information
Save? [Idle Y]	exit and save options

**Table 10-17 Information Center Menu**

### 10.13.10.2 Additional Information

#### Engine r/mi

- ☐ The Information Center displays DDEC ECM diagnostic codes and limited engine information as well as PGS status.
- ☐ The Information Center display can be used as an aid to troubleshooting the Pressure Governor System and the Electronic Fire Commander.
- ☐ The Fire Commander I/O Test checks the outputs as well as the switches. It automatically runs through a test and displays the results for your information in troubleshooting.
- ☐ The connector data displays the cavities of inputs and outputs necessary for correct system operation.
- ☐ The interlock lamps show which interlock circuits have been closed and if that part of the system is ready for operation.

### 10.13.10.3 Troubleshooting the Electronic Fire Commander

This section lists some of the common troubles encountered during the installation and check out of the Electronic Fire Commander. These conditions are listed and the suggested actions follow each one. The Electronic Fire Commander wiring is listed in Table 10-18, listed in Table 10-19, listed in Table 10-20.

1. Condition: The EFC will not light up.
  - ☐ Check if the necessary switches are turned on.
  - ☐ Check if there is a 12 VDC between pins #1 and #2 at the EFC 4-pin connector.
2. Condition: The throttle will not increase in RPM Mode.
  - ☐ Check if the THROTTLE READY lamp is on. The EFC will not respond in RPM mode unless the OEM safety interlock requirements that enable the throttle are met.
  - ☐ Press the PRESET and then the INC switches. Does the EFC indicate it is increasing RPM on the data display?
  - ☐ Check the switch and outputs in the Menu I/O test.
  - ☐ Re-initialize the EFC. (Remove power to the EFC; wait ten seconds and then power the unit and try again.)

**NOTE:**

The EFC performs a "self-test" when it is powered up. This is indicated on the EFC by a momentary lighting of all the display segments.

3. Condition: The throttle will not increase in Pressure Mode.
  - ☐ Check that all three lamps: PUMP ENGAGED, OKAY TO PUMP, and THROTTLE READY are on.
  - ☐ Press the INC and then the PRESET buttons to increase pump pressure.
  - ☐ Check for a pump discharge pressure reading in the Menu.
  - ☐ Re-initialize the EFC.
4. Condition: The Engine Data Display is showing all zeroes.
  - ☐ Check that the connections at pins #3 and #4 of the EFC 4-pin connector are secure.
  - ☐ Check there is continuity on the 900 and 901 circuits from the ECM connector to the EFC connector.
5. Condition: The THROTTLE READY lamp will not turn on.
  - ☐ Check that the parking brake is on.
  - ☐ Check that the transmission is in neutral, or the hand throttle (PTO) is engaged.
  - ☐ Check for 12 VDC at pin #2 of the EFC 12-pin connector.

6. Condition: The PUMP ENGAGED and OKAY TO PUMP lamps do not turn on.
  - ☐ Check that all OEM safety requirements for pump operation are fulfilled.
  - ☐ Is the parking brake on?
  - ☐ Is the transmission in the proper range for pump operation?
  - ☐ Is the hand throttle (PTO) engaged?
  - ☐ Is there an OK to PUMP indication in the cab?
  - ☐ Check for 12 VDC at pin #10 of the EFC 12-pin connector.
7. Condition: The mode will not change from RPM to Pressure.
  - ☐ Check: Are the PUMP ENGAGED and OKAY TO PUMP lamps on?
  - ☐ Does the MODE switch pass in the menu I/O test?
8. Condition: The PRESET switch doesn't work.
  - ☐ Check that the proper lamps are on for the mode you want to operate.
  - ☐ Is there a valid preset programmed into the menu? If not, refer to section 10.13.10 and complete the steps given there.

☐ Does the PRESET switch pass the menu I/O test?

Connector 1:	Deutsch DT06-4S		
Cavity	Circuit Description	DDC#	EFC Input/Output
1	DDEC Accessory Power	439	(+) System Power
2	DDEC Accessory Ground	953	(-) System Ground
3	DDEC 1708 Data Link (+)	900	J1587 Serial Link
4	DDEC 1708 Data Link (-)	901	J1587 Serial Link

**Table 10-18 Electronic Fire Commander Wiring**

Connector 2:	DT06-12S		
Cavity	Circuit Description	DDC#	EFC Input/Output
1	DDEC PGS Mode Select	523	Output (ground) to DDEC
2	OEM Interlock from OEM	-	Input (+12 VDC)
3	Cavity plug	-	No connection
4	DDEC PGS Mode	499	Input (ground) from DDEC
5	DDEC PGS Enable	-	Output (ground) to DDEC
6	DDEC PGS Increase	-	Output (ground) to DDEC
7	DDEC PGS Decrease	-	Output (ground) to DDEC
8	DDEC PGS Active	-	Input (ground) from DDEC
9	Alarm	-	Output (ground) to DDEC
10	PTO Engaged	-	Input (+12 VDC) from OEM
11	Cavity Plug	-	No connection
12	Low fuel	-	Input (ground) from DDEC

**Table 10-19 Electronic Fire Commander Wiring**

	Pressure Sensor Connector:		
Circuit	Cavity	Wire Color	Description
916	B	Red/Black	Sensor Supply 5 VDC
749	C	Yellow	Fire Pump Pressure
952	A	Black	Sensor Return

**Table 10-20 Electronic Fire Commander Wiring**



## 10.14 OPTIMIZED IDLE FEATURE DOES NOT FUNCTION

The following procedure will troubleshoot Optimized Idle not functioning.



### CAUTION:

**To avoid injury from accidental engine startup, replace a defective ECM with an ECM programmed with identical inputs and outputs.**

### NOTE:

If a replacement ECM is needed, replace the ECM with an ECM programmed with Optimized Idle.



### CAUTION:

**To avoid injury from an accidental startup of an engine equipped with the Optimized Idle<sup>®</sup> system, remove the starter relay from the relay holder.**

### 10.14.1 Check Diagnostic Data Reader for Codes

Perform the following steps to check the DDR for codes.

1. Plug DDR into connector.
2. Turn ignition ON.
3. Check the active and inactive codes for any Optimized Idle codes.
4. Turn ignition OFF.

### NOTE:

Service any code first.

- [a] If an Optimized Idle code 62, 63, or 74 is logged, go to the appropriate flash code section, based on Optimized Idle code logged.
- [b] If an Optimized Idle code 62, 63 or 74 is not logged, refer to section 10.14.2.

### 10.14.2 Heater and Air Conditioning Fans Do Not Function

Perform the following steps to troubleshoot the heater and A/C fans.

1. Check the heater and A/C blower fuse.
2. Turn ignition ON.
3. Plug in DDR.
4. Check the vehicle power down relay switch. Select switch light status (VEH PWR DOWN).
  - [a] If the output status reads ON, check the relay and relay connections for proper operation. Refer to section 10.14.3.
  - [b] If the output status does not read ON, install a test ECM. Refer to section 10.14.11.

### 10.14.3 Check Optimized Idle Active Light

The Optimized Idle active light should flash when all of the following occur:

1. Engine idling.
2. The transmission is in NEUTRAL and high-range, if equipped.
3. The hood is closed and the park brake is set.
4. The cruise switch is turned ON.
  - [a] If the active light is not flashing, refer to section 10.14.4.
  - [b] If the light is flashing, after the engine shuts down, turn the thermostat on. When the light flashes, if the alarm turns ON and the engine starts, the system is OK.
  - [c] If the light is flashing, after the engine shuts down, turn the thermostat on. When the light flashes, if the alarm does not turn ON and the engine does not start, refer to section 10.14.10.

### 10.14.4 Check Idle Condition

Perform the following steps to troubleshoot Optimized Idle:

1. Check idle condition.
2. Verify the engine is at idle and not running on VSG. Optimized idle will not function if the engine is running on VSG, unless the idle timer is enabled on VSG.
  - [a] If the engine is not at idle, turn off the ISD on the VSG. Refer to section 10.14.11.
  - [b] If the engine is at idle, refer to section 10.14.5.

### **10.14.5 Check Idle Shutdown Enabled**

Perform the following steps to troubleshoot Optimized Idle:

1. Check for idle shutdown enabled.
2. Using the DDR, view the calibration.
  - [a] If idle shutdown is not enabled, enable the idle shutdown and set a shutdown time. Refer to section 10.14.11.
  - [b] If the idle shutdown is enabled, refer to section 10.14.6.

### **10.14.6 Check Input Status**

Perform the following steps to troubleshoot Optimized Idle:


1. Check for input status.
2. Using the DDR, check the park brake input status with the hood closed, the transmission in NEUTRAL (and high-range if equipped) and the park brake set.
  - [a] If the park brake status is ON, refer to section 10.14.9.
  - [b] If the park brake status is not ON, refer to section 10.14.7.

### **10.14.7 Check Hood Switch**

Perform the following steps to troubleshoot the hood switch:

1. Check hood switch.
2. Measure the resistance across the hood switch contacts with the hood closed. See Figure 10-11.
  - [a] If the resistance measures less than 100  $\Omega$  , refer to section 10.14.8.

- [b] If the resistance measures greater than 100  $\Omega$ , replace or adjust the hood switch.  
Refer to section 10.14.11.



28315

**Figure 10-11 Optimized Idle Schematic**

### 10.14.8 Check Park Brake Switch

Perform the following steps to troubleshoot the park brake switch and other OEM interlock devices.

1. Check the park brake switch and other OEM interlock devices (e.g. high-range switch).
2. Measure resistance across the park brake switch contacts with the park brake set.
  - [a] If the measured resistance is less than 100  $\Omega$ , the 953 ground wire is open somewhere between the ECM and the battery. Repair the open. Refer to section 10.14.11.
  - [b] If the measured resistance is more than 100  $\Omega$ , replace the park brake switch or other OEM interlock devices. Refer to section 10.14.11.

### 10.14.9 Check the Thermostat

Perform the following steps to check the thermostat operation:

1. Turn ignition ON.
2. Plug in the DDR.
3. Select switch light status OPIDL T-STAT.
  - [a] If the display reads ON with the thermostat enabled and the alarm is turned ON and the reader shows the switch status for the starter as ON after the alarm turns OFF, check the relay and starter solenoid connections. Refer to section 10.14.11.
  - [b] If the display reads ON with the thermostat enabled and the alarm is turned ON and the reader does not show the switch status for the starter as ON after the alarm turns OFF, refer to section 10.14.10.
  - [c] If the display reads ON with the thermostat enabled and the alarm OFF, replace the alarm. Refer to section 10.14.11.
  - [d] If the display does not read ON with the thermostat enabled, the thermostat input wire #958 is open between the thermostat and the ECM. Repair the open. Refer to section 10.14.11.

### 10.14.10 Oil Temperature Sensor Connection Check

Perform the following steps to troubleshoot the OTS connection:

1. Check the OTS connection.
  - [a] If the OTS connector is plugged into the oil temperature sensor, reprogram the ECM. Refer to section 10.14.11.
  - [b] If the OTS connector is not plugged into the OTS, plug in the OTS connector. Refer to section 10.14.11.

### 10.14.11 Verify Repairs

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Close the hood; set the park brake; put the transmission in NEUTRAL and the high-range, if equipped.
4. Start the engine.
5. Turn the cruise master switch to the ON position. If it was on before the vehicle started, turn the switch to OFF and then to ON.
6. Wait for the engine to shut down. After the idle timer expires, the engine will either shutdown or continue to run to charge the battery or keep the oil temperature between 60°F (16°C) and 104°F (40°C).
7. Turn the thermostat on, if installed. Change the set point and heating/cooling mode until the thermostat requires the engine to start. The icons will flash. If the thermostat is not installed, wait for the lube oil temperature to fall below 60°F (16°C).
8. The alarm will sound and the engine will start. Vehicle power (blower fans) will turn on approximately 30 seconds after the engine starts, due to the thermostat.
  - [a] If Optimized Idle operates properly, troubleshooting is complete.
  - [b] If Optimized Idle does not operate properly, troubleshooting is complete. Review this section from the first step to find the error. Refer to section 10.14.1.

## 10.15 TRANSMISSION INTERFACE FAULT

Numerous transmissions utilize the DDEC ECM to receive signals that are used to determine shift points, and/or other information.

### 10.15.1 Transmission Fault

Transmissions that currently utilize data links:

- ☐ J1587 - Allison World Transmissions
- ☐ J1939 Eaton, Allison
- ☐ J1922 Ceemat
- ☐ Advanced Interface
  - ☐ ESS <sup>TM</sup>, Rockwell - Refer to ESS Troubleshooting Manual
  - ☐ Top2, Eaton - Refer to MISC Output Troubleshooting
- ☐ PWM Signal Type - DDEC provides a PWM signal that is used by the transmission or its components

### 10.15.2 Verify Transmission Type

Perform the following steps to check the transmission type.

1. Turn ignition ON.
2. Plug in DDR.
3. Check transmission origination.
  - [a] If a manual transmission, Allison hydraulic, Allison Electronic, Voith, ZF, refer to section 10.15.3.
  - [b] If a J 1939/autoshift, Allison WT, Rockwell RXX-X, refer to the troubleshooting guide of the transmission manufacturer to troubleshoot the fault.
  - [c] If the transmission type does not match the transmission correctly, reprogram and refer to section 10.15.4.

### 10.15.3 Review PWM #1 Signal

Perform the following steps to check the DDR for codes.

1. Perform road test with assistant.
2. Plug in DDR.
3. Watch PWM #1 signal.
  - [a] If the PWM varies with the load changes, Allison Electric, Voith or ZF, the signal is normal. Review the wiring or transmission.
  - [b] If the PWM signal is 0% or 100% when the signal is for Allison Hydraulic with load changes, the program is normal. Review the transmission, wiring or relay. Refer to section 10.15.4.

### 10.15.4 Verify Repairs

Perform the following steps to verify repairs. Start with the Menu Selection. An assistant is needed for the following procedure.

1. Perform road test.
  - [a] If the problem is resolved, troubleshooting is complete.
  - [b] If the problem still exists, contact the OEM or transmission supplier. The steps that led you here do not indicate a problem with the PWM #2 output or output wire. Verify the correct configuration. Refer to the *DDEC Application and Installation* manual, 7SA800, for the appropriate engine.





---

## 11 FLASH CODE 11 - VSG LOW

Section	Page
11.1 DESCRIPTION OF FLASH CODE 11 .....	11- 3
11.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 11 .....	11- 3
11.3 TROUBLESHOOTING FLASH CODE 11 .....	11- 4



## 11.1 DESCRIPTION OF FLASH CODE 11

Flash Code 11 indicates that the Variable Speed Governor (VSG) input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage. This diagnostic condition is typically:

- ☐ Open sensor signal circuit (No VSG throttle control installed.)
- ☐ Open sensor +5 volt supply circuit
- ☐ Sensor signal is shorted to the sensor return circuit or to ground
- ☐ Sensor +5 volt supply is shorted to sensor return circuit or to ground (This condition will result in numerous sensor codes.)

## 11.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 11

The SAE J 1587 equivalent code for Flash Code 11 is p 187 4, Variable Speed Governor (VSG) input low.

## 11.3 TROUBLESHOOTING FLASH CODE 11

The following procedure will troubleshoot Flash Code 11.

### 11.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in DDR.
3. Read active codes.
  - [a] If code 187/4 is logged and there are no VSG controls used, call DDC with the engine serial number to determine if re-calibration is necessary.
  - [b] If code 187/4 was logged and there are VSG controls used primarily, refer to section 11.3.2.
  - [c] If codes 100/4 and 91/4 were logged, refer to section 91.2.

### 11.3.2 Sensor Wiring Check

Perform the following steps to check the sensor and wiring:


1. Turn ignition OFF.
2. Disconnect VSG throttle sensor connector.
3. Install a jumper wire between sockets B (#510 signal) and C (5V-#916) of the VSG harness connector. See Figure 11-1.

#### NOTE:

Cavities of throttle controls may vary depending on the OEM.

4. Turn ignition ON.
5. Enable VSG throttle. Refer to OEM guidelines.
6. Read DDR for active codes.
  - [a] If active code 187/3 and any other codes are logged, refer to section 11.3.3.

[b] If active code 187/4 and any other codes are logged, refer to section 11.3.6.



**Figure 11-1 Variable Speed Governor Circuit**

### 11.3.3 Check Hand Throttle Sensor Adjustment

Perform the following steps to check the hand throttle sensor:

1. Remove jumper and reconnect hand throttle sensor.
2. Turn ignition ON.
3. Plug in DDR.
4. Select VSG COUNTS on the DDR.
5. Enable VSG. Set to idle position.
6. Read counts.
  - [a] If the count value set at idle (minimum throttle) is greater than 48 counts, refer to section 11.3.5.
  - [b] If the count value set at idle (minimum throttle) is less than 48 counts, refer to section 11.3.4.

### 11.3.4 Adjust Hand Throttle Sensor


Perform the following steps to adjust the hand throttle sensor:

1. Turn ignition OFF.
2. If a variable hand throttle sensor is installed, adjust idle position (low-speed) stops on the hand throttle sensor.
3. If fixed resistors are installed, replace with new resistors. (Minimum counts **MUST** be greater than 48.)
4. Turn ignition ON.
5. Read VSG counts with throttle at low-speed position.
  - [a] If the idle count reading is greater than 48 counts, refer to section 11.3.12.
  - [b] If the idle count reading is less than 48 counts, refer to section 11.3.5.

### 11.3.5 Check Hand Throttle Sensor Connectors

Perform the following steps to check the hand throttle sensor connectors.

1. Turn ignition OFF.
2. Inspect the terminals at the hand throttle sensor connectors (sensor side and harness side) for bent, corroded and unseated pins or sockets. See Figure 11-2.
  - [a] If the terminals and connectors are not damaged, replace hand throttle sensor. Refer to section 11.3.12.
  - [b] If the terminals and connectors are damaged, repair as necessary. Refer to section 11.3.12.




**Figure 11-2 Variable Speed Governor Circuit**



### 11.3.6 Check for +5 volts

Perform the following steps to check for +5 volts:

1. Turn ignition ON.
2. Enable VSG. Refer to OEM guidelines.
3. Measure voltage on the hand throttle sensor harness connector, socket C (5V #916, red lead) to socket A (return #952, black lead). See Figure 11-3.
  - [a] If the voltage reading is between 4 to 6 volts, refer to section 11.3.7.
  - [b] If the voltage reading is greater than 6 volts, refer to section 12.1.
  - [c] If the voltage reading is less than 4 volts, refer to section 11.3.10.




**Figure 11-3 Variable Speed Governor Circuit**

### 11.3.7 Check for Short

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Enable VSG. Refer to OEM guidelines.
4. Measure resistance between sockets A (return #952) and B (signal #525) on the hand throttle sensor harness connector. For VSG circuit, see Figure 11-4.
  - [a] If the resistance is greater than 1,000  $\Omega$  or open, refer to section 11.3.8.
  - [b] If the resistance is less than or equal to 1,000  $\Omega$ , the signal line #525 is shorted to the return line. Repair the short. Refer to section 11.3.12.



**Figure 11-4 Variable Speed Governor Circuit**

### 11.3.8 Check for Open Signal


Perform the following steps to check for open signal:

1. Install a jumper wire between sockets A and B of the hand throttle sensor harness connector. See Figure 11-4.
2. Enable VSG. Refer to OEM guidelines.
3. Measure resistance between sockets D1 (#510) and C3 (#952) on the vehicle harness connector.
  - [a] If the resistance is less than or equal to 5  $\Omega$ , refer to section 11.3.9.
  - [b] If the resistance is greater than 5  $\Omega$  or open and the signal line (#510) or return line (#952) is open, repair the open. Refer to section 11.3.12.

### 11.3.9 Check ECM Connectors

Perform the following steps to check for signal open:

1. Check terminals at the ECM vehicle harness connector (both the ECM and harness side) for bent, corroded, and unseated pins or sockets. See Figure 11-5.
  - [a] If the terminals and connectors are damaged, repair the terminals, connectors, or both. Refer to section 11.3.12.
  - [b] If the terminals and connectors are not damaged, contact DDC Technical Service. Refer to section 11.3.12.




**Figure 11-5 Electronic Control Module Vehicle Harness Connector**

### 11.3.10 Check for Short to 5 Volt

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Disconnect the connector at the hand throttle sensor.
4. Measure resistance between sockets A and C on the hand throttle sensor harness connector. See Figure 11-6.
  - [a] If the resistance measurement is greater than 1,000  $\Omega$ , refer to section 11.3.11.
  - [b] If the resistance measurement is less than or equal to 1,000  $\Omega$ , the vehicle +5 volt line (#916) is shorted to the return line (#952). Repair short. Refer to section 11.3.12.



**Figure 11-6 Variable Speed Governor Circuit**

### 11.3.11 Check for Open +5 Volt Line

Perform the following steps to check for an open +5 volt line.

1. Install a jumper wire between sockets A and C of the hand throttle sensor harness connector. See Figure 11-6.
2. Measure resistance between sockets A3 (#916) and C3 (#952) on the vehicle connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 11.3.9.
  - [b] If the resistance measurement is greater than 5  $\Omega$ , or open, the vehicle +5 volt line (#916) is open. Repair open. Refer to section 11.3.12.

### 11.3.12 Verify Repair

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check for logged codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 187/4 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 187/4 is logged, and other codes are logged, systems diagnostics are complete. Please review this section from the first step to find the error. Refer to section 11.3.1.

---

## 12 FLASH CODE 12 - VSG HIGH

Section	Page
12.1 DESCRIPTION OF FLASH CODE 12 .....	12- 3
12.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 12 .....	12- 3
12.3 TROUBLESHOOTING FLASH CODE 12 .....	12- 4



## 12.1 DESCRIPTION OF FLASH CODE 12

Flash Code 12 indicates that the Variable Speed Governor (VSG) input to the ECM has exceeded 95% (normally > 4.75 volts) of the sensor supply voltage. This diagnostic condition is typically:

- ☐ Open sensor return circuit
- ☐ Sensor signal circuit is shorted to the sensor +5 volt supply
- ☐ Throttle sensor not adjusted properly at full throttle

## 12.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 12

The SAE J1587 equivalent code for Flash Code 12 is p 187 3, Variable Speed Governor (VSG) input high.




## 12.3 TROUBLESHOOTING FLASH CODE 12

The following procedure will troubleshoot Flash Code 12.

### 12.3.1 Multiple Code Check

Perform the following steps to check for multiple codes:

1. Turn ignition ON. (For VSG circuit, see Figure 12-1.)
2. Plug in DDR.
  - [a] If active code 187/3 and any other codes except 91/3 or 100/3 are logged, refer to section 12.3.2.
  - [b] If active code 187/3 and codes 91/3 or 100/3 are logged, refer to section 91.2.



**Figure 12-1** Variable Speed Governor Circuit

### 12.3.2 Sensor Check

Perform the following steps to check the sensor:

1. Turn ignition OFF.
2. Unplug the VSG throttle connector. (For VSG circuit, see Figure 12-1.)
3. Turn ignition ON.
4. Read active codes.
  - [a] If active code 187/4 is logged, and code 187/3 only occurs when the throttle is moved at or near full throttle (when connected), refer to section 12.3.3.
  - [b] If active code 187/3 is logged, and the code appears when the throttle is not at or near full throttle (when connected), refer to section 12.3.4.

### 12.3.3 Check Calibration


Perform these additional steps to check the calibration of the sensor:

1. Plug in the VSG throttle connector.
2. Turn ignition ON.
3. Plug in DDR.
4. Display VSG counts.
5. Dial throttle to Full Throttle.
  - [a] If the VSG counts are greater than 968, adjust the maximum throttle travel. If not adjustable, replace the throttle control.
  - [b] If the VSG counts are less than 968, refer to section 12.3.4.

### 12.3.4 Return Circuit Check

Perform these steps to check the return circuit:

1. Place the transmission in neutral.
  2. Turn ignition OFF.
  3. Install a jumper wire between pin A (return #952) and pin B (signal #510/525) of the VSG throttle harness connector.
  4. Disconnect the vehicle harness connector at the ECM.
  5. Enable VSG control. (This may require the ignition be turned on.)
  6. Measure resistance between sockets C3 (#952) and D1 (#510) on the vehicle harness connector. See Figure 12-2.
- [a] If the resistance is less than or equal to 5  $\Omega$ , refer to section 12.3.5.
- [b] If the resistance is greater than 5  $\Omega$ , the return line (#952) is open, repair the open. Refer to section 12.3.8.



**Figure 12-2 Typical Variable Speed Governor Circuit**

### 12.3.5 Variable Speed Governor Throttle Connector Check


**Perform these steps to check the VSG throttle connectors:**

1. **Inspect terminals at the VSG connectors (sensor side and harness side) for bent, corroded and unseated pins or sockets.**
  - [a] **If the VSG connector terminals are damaged, repair terminals and/or connectors. Refer to section 12.3.8.**
  - [b] **If the VSG connector terminals are in good condition with no signs of damage, refer to section 12.3.6.**

### 12.3.6 Check for Short to Battery (+)

**Perform these steps to check for short to battery (+).**

1. Turn ignition OFF.
2. Unplug VSG connector.
3. Turn ignition ON.
4. Measure voltage between B (signal #525/#510) and battery ground. See Figure 12-3.
  - [a] If measured voltage is less than or equal to 0.2 volts, refer to section 12.3.7.
  - [b] If measured voltage is greater than 0.2 volts, signal wire is shorted to 12/24 volt source. Repair or replace #510/#525 circuit. Refer to section 12.3.8.




### Figure 12-3 Variable Speed Governor Circuit

### 12.3.7 Check for Short

To check for short, perform the following:

1. Turn ignition OFF.
2. Unplug vehicle 30-pin connector and the VSG connector.
3. Turn ignition ON.
4. Enable VSG. Refer to OEM guidelines.
5. Measure resistance between A3 (#916) and D1 (#510). See Figure 12-4.
  - [a] If resistance is greater than 5  $\Omega$ , check ECM connector. Refer to section 12.3.8.
  - [b] If resistance is less than 5  $\Omega$ , wire #916 (5-volt supply) is shorted to #510/#525 (signal). Repair short or replace wire. Refer to section 12.3.8 to verify repairs.



**Figure 12-4 Variable Speed Governor Circuit**

### 12.3.8 Verify Repairs

Perform the following steps to verify repairs.

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Set parking brake, transmission in Neutral.
4. Turn ignition ON.
5. Clear codes.
6. Start and run the engine for one minute.
7. Stop engine.
8. Check DDR for codes.
  - [a] If no codes are displayed, no further troubleshooting is required.
  - [b] If code 187/3 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 187/3 is logged, and other codes are logged, refer to section 12.3.1.




---

## 13 FLASH CODE 13 - CLS LOW

Section	Page
13.1 DESCRIPTION OF FLASH CODE 13 .....	13- 3
13.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 13 .....	13- 3
13.3 TROUBLESHOOTING FLASH CODE 13 .....	13- 4





**Figure 13-1      Coolant Level Sensor**

### 13.1 DESCRIPTION OF FLASH CODE 13

Flash Code 13 indicates that the Coolant Level Sensor (CLS) input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage. See Figure 13-1. This diagnostic condition is typically:

- ☐ Sensor signal is shorted to the sensor return circuit or to ground
- ☐ Deteriorated coolant

### 13.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 13

The SAE J1587 equivalent code for Flash Code 13 is p 111 4, coolant level circuit low.

## **13.3 TROUBLESHOOTING FLASH CODE 13**

The following procedure will troubleshoot Flash Code 13.

### **13.3.1 Sensor Check**

Perform the following steps to check the sensor.


1. Turn vehicle ignition OFF.
2. Disconnect Coolant Level Sensor (CLS).
3. Turn ignition ON.
4. Start engine.
5. Read logged codes.
6. Stop engine.
  - [a] If code P111/3 is logged, refer to section 13.3.2.
  - [b] If code P111/4 is logged, refer to section 13.3.3.

### **13.3.2 Check Coolant Level Sensor Connector**

Perform the following steps to check the CLS connector.

1. Inspect terminals at the CLS connector for bent, corroded and unseated pins or sockets. Ensure wires are not reversed at the CLS. See Figure 13-2.
  - [a] If terminals and connectors are damaged, repair both. Refer to section 13.3.4.

- [b] If terminals and connectors are not damaged, replace the CLS. Refer to section 13.3.4.



**Figure 13-2 Coolant Level Sensor and Circuits**

### 13.3.3 Check for Short

Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Measure resistance between sockets A and B on the CLS harness connector. Also measure resistance between socket A and battery ground; and socket A and chassis ground. See Figure 13-2.
  - [a] If the resistance is greater than 10,000  $\Omega$  or open, refer to section 13.3.2.
  - [b] If the resistance is less than or equal to 10,000  $\Omega$ , the signal wire (#115) is shorted to the ground (#953), or to chassis ground. Repair short; refer to section 13.3.4.

### 13.3.4 Verify Repairs

Perform the following steps to verify repairs.

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear DDR codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are displayed, troubleshooting is complete.
  - [b] If code 111/4 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 111/4 is logged, refer to section 13.3.5.

### 13.3.5 Code 111/4 Logged


Perform the following steps to troubleshoot Code 111/4.

1. Remove CLS.
2. Plug opening.
3. Locate sensor probe in clean water.
4. Start and run the engine for one minute.
5. Check DDR for codes.
  - [a] If code 111/4 is logged, all system diagnostics are complete. Review this section to find the error. Refer to section 13.3.1.
  - [b] If code 111/4 is not logged, reprogram the ECM and replace the coolant with new. Repeat the test. Refer to section 13.3.4.

---

## 14 FLASH CODE 14 - TEMP SENSOR HIGH

Section	Page
14.1 DESCRIPTION OF FLASH CODE 14 .....	14- 3
14.2 SAE J1587 EQUIVALENT CODES FOR FLASH CODE 14 .....	14- 3
14.3 TROUBLESHOOTING FLASH CODE 14 .....	14- 4



**Figure 14-1      Coolant Temperature Sensor (Oil Temperature Sensor similar)**

## 14.1 DESCRIPTION OF FLASH CODE 14

Flash Code 14 indicates that the engine Coolant Temperature Sensor (CTS) or Oil Temperature Sensor (OTS), See Figure 14-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

### NOTE:

This code will only be logged during warm engine operation.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor return circuit

## 14.2 SAE J1587 EQUIVALENT CODES FOR FLASH CODE 14

The SAE J1587 equivalent codes for Flash Code 14 are:

- ☐ p 110 3 - coolant temperature circuit high
- ☐ p 175 3 - oil temperature circuit high



## **14.3 TROUBLESHOOTING FLASH CODE 14**

The following procedure will troubleshoot Flash Code 14.

### **14.3.1 Code Check**

Perform the following steps to check for codes.

1. Turn vehicle ignition ON.
2. Plug in diagnostic data reader (DDR) and determine which code is logged.
  - [a] If codes PID 110-FMI 3 is logged, refer to section 14.3.2.
  - [b] If codes PID 175-FMI 3 is logged, refer to section 14.3.3.

### **14.3.2 Coolant Temperature Sensor Check**

Perform the following steps to check the coolant temperature sensor (CTS).

1. Turn vehicle ignition OFF.
2. Disconnect CTS and install a jumper between the CTS connector sockets A and B.  
See Figure 14-2.
3. Turn vehicle ignition ON.
4. Read active codes.
  - [a] If code 110/4 or any other codes except 110/3 are logged, refer to section 14.3.8.

- [b] If code 110/3 is logged and any codes except code 110/4 are logged, refer to section 14.3.4.




Figure 14-2 Temperature Sensor Circuits

### 14.3.3 Oil Temperature Sensor Check

Perform the following steps to check the oil temperature sensor (OTS).

1. Turn vehicle ignition OFF.
2. Disconnect OTS and install a jumper between OTS connector sockets A and B.  
See Figure 14-3.
3. Turn ignition ON.
4. Read active codes.
  - [a] If code 175/4 is logged, refer to section 14.3.9.
  - [b] If code 175/3 is logged and any codes except code 175/4 are logged, refer to section 14.3.5.





Figure 14-3 Temperature Sensor Circuits

### 14.3.4 Check for Signal Short to +5 Volt Line

Perform the following steps to check for a short to the +5 volt line.

1. Turn ignition OFF.
2. Remove jumper wire.
3. Disconnect the engine harness connector at the ECM.
4. Measure resistance between sockets P3 #133 and W1 #416 on the engine harness connector. See Figure 14-4.
  - [a] If the resistance measurement is greater than 5  $\Omega$  or open, refer to section 14.3.6.
  - [b] If the resistance measurement is less than or equal to 5  $\Omega$ , the signal line (#133) is shorted to the engine +5 volt line (#416). Repair the short and refer to section 14.3.11.



**Figure 14-4 ECM Engine Harness Connector**

### 14.3.5 Check for Signal Short to +5 Volt Line

Perform the following steps to check for a short to the +5 volt line.

1. Turn vehicle ignition OFF.
2. Remove jumper wire.
3. Disconnect the engine harness connector at the ECM.
4. Measure resistance between sockets R2 #120 and W1 #416 on the engine harness connector. See Figure 14-4.
  - [a] If the resistance measurement is greater than or equal to 5  $\Omega$ , refer to section 14.3.7.
  - [b] If the resistance measurement is less than 5  $\Omega$ , the signal line (#120) is shorted to the engine +5 volt line (#416). Repair the short and refer to section 14.3.11.

### 14.3.6 Check Coolant Temperature Sensor Connectors

Perform the following steps to check the CTS connectors.

1. Check terminals at the CTS connector (both sensor and harness side) for damage; bent, corroded and unseated pins or sockets. See Figure 14-5.
  - [a] If terminals and connectors are in good condition, replace the CTS. Refer to section 14.3.11.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 14.3.11.




Figure 14-5 Temperature Sensor Circuits

### 14.3.7 Check Oil Temperature Sensor Connectors

Perform the following steps to check the OTS connectors.

1. Check terminals at the OTS connector (both sensor and harness side) for damage: bent, corroded and unseated pins or sockets. See Figure 14-6.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 14.3.11.
  - [b] If terminals and connectors are not damaged, replace the OTS. Refer to section 14.3.11.





Figure 14-6 Temperature Sensor Circuits

### 14.3.8 Open Line Check

Perform the following steps to check for an open line.

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM. Leave the jumper wire between A and B of the Temperature Sensor Connector.
3. Measure resistance between sockets P3 (#133) and Y2 (#452) on the engine harness connector. See Figure 14-7.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 14.3.10.
  - [b] If the resistance measurement is greater than 5  $\Omega$  or open, the signal line (#133) or return line (#452) is open. Repair the open. Refer to section 14.3.11.



**Figure 14-7 ECM Engine Harness Connector**



### 14.3.9 Open Line Check


Perform the following steps to check for an open line.

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM. Leave the jumper wire between A and B of the Temperature Sensor Connector.
3. Measure resistance between sockets R2 (#120) and Y2 (#452) on the engine harness connector. See Figure 14-7.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 14.3.10.
  - [b] If the resistance measurement is greater than  $5\ \Omega$  or open, the signal line (#120) or return line (#452) is open. Repair the open. Refer to section 14.3.11.

### 14.3.10 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connector (both ECM and harness side) for damage: bent, corroded and unseated pins or sockets. See Figure 14-8.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 14.3.11.
  - [b] If terminals and connectors are not damaged, replace the CTS/OTS.



**Figure 14-8 ECM Engine Harness Connector**

### 14.3.11 Verify Repairs

Perform the following steps to verify repairs.

1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn vehicle ignition ON.
4. Clear codes.
5. Start and run the engine for eight minutes.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 110/3 or 175/3 and any other codes are logged, all system diagnostics are complete. Review this section to find the error. Refer to section 14.3.1.
  - [c] If any codes except code 110/3 or 175/3 are logged, refer to section 9.1.




---

## 15 FLASH CODE 15 - TEMP SENSOR LOW

Section	Page
15.1 DESCRIPTION OF FLASH CODE 15 .....	15- 3
15.2 SAE J1587 EQUIVALENT CODES FOR FLASH CODE 15 .....	15- 3
15.3 TROUBLESHOOTING FLASH CODE 15 .....	15- 4

---



**Figure 15-1      Coolant Temperature Sensor (Oil Temperature Sensor similar)**

## 15.1 DESCRIPTION OF FLASH CODE 15

Flash Code 15 indicates that the Coolant Temperature Sensor (CTS), or Oil Temperature Sensor (OTS), see Figure 15-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Sensor signal is shorted to the sensor return circuit or to ground

## 15.2 SAE J1587 EQUIVALENT CODES FOR FLASH CODE 15

The SAE J1587 equivalent codes for Flash Code 15 are:

- ☐ p 110 4 - coolant temperature circuit low
- ☐ p 175 4 - oil temperature circuit low

## 15.3 TROUBLESHOOTING FLASH CODE 15

The following procedure will troubleshoot Flash Code 15.

### 15.3.1 Code Check

Perform the following steps to check for codes.

1. Turn vehicle ignition ON.
2. Plug in diagnostic data reader (DDR) and determine which code is logged.
  - [a] If codes PID 110-FMI 4 are logged, refer to section 15.3.2.
  - [b] If codes PID 175-FMI 4 are logged, refer to section 15.3.3.

### 15.3.2 Coolant Temperature Sensor Check

Perform the following steps to check the coolant temperature sensor (CTS).

1. Turn vehicle ignition OFF.
2. Disconnect (unplug) CTS connector.
3. Start and run the engine for eight minutes.
4. Read active codes with engine still running.
  - [a] If code 110/4 or any other codes are logged, refer to section 15.3.4.
  - [b] If any codes except code 110/4 are logged, refer to section 15.3.6.

### 15.3.3 Oil Temperature Sensor Check

Perform the following steps to check the oil temperature sensor (OTS).

1. Turn vehicle ignition OFF.
2. Disconnect OTS connector. See Figure 15-2.
3. Start and run the engine for eight minutes.
4. Read active codes with engine running.
  - [a] If code 175/4 is logged, refer to section 15.3.7.
  - [b] If any codes except code 175/4 are logged, refer to section 15.3.5.




Figure 15-2 Temperature Sensor Circuits



### 15.3.4 Check Coolant Temperature Sensor Connectors

Perform the following steps to check the CTS connectors.

1. Check terminals at the CTS connector (both sensor and harness side) for damage; bent, corroded and unseated pins or sockets. See Figure 15-3.
  - [a] If terminals and connectors are in good condition, replace the CTS. Refer to section 15.3.10.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 15.3.10.




Figure 15-3 Temperature Sensor Circuits

### 15.3.5 Check Oil Temperature Sensor Connectors

Perform the following steps to check the OTS connectors.

1. Check terminals at the OTS connector (both sensor and harness side) for damage: bent, corroded and unseated pins or sockets. See Figure 15-4.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 15.3.10.
  - [b] If terminals and connectors are not damaged, replace the OTS. Refer to section 15.3.10.





Figure 15-4 Temperature Sensor Circuits

### 15.3.6 Check for Short

Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Measure resistance between sockets P3 (#133) and Y2 (#452) on the engine harness connector. See Figure 15-5.
4. Measure resistance between socket P3 and a good ground.
  - [a] If the resistance measurement between sockets P3 and Y2, or P3 and battery ground, is less than or equal to  $5\ \Omega$ , the signal line (#133) is shorted to the return line (#452) or battery ground. Repair the short. Refer to section 15.3.10.
  - [b] If the resistance measurement between sockets P3 and Y2 is greater than  $5\ \Omega$  or open, and the resistance measurement between sockets P3 and a good ground is greater than or equal to  $5\ \Omega$  or open, refer to section 15.3.8.



**Figure 15-5 ECM Engine Harness Connector**

### 15.3.7 Check for Short

Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Measure resistance between sockets R2, (#120) and Y2 (#452) on the engine harness connector. See Figure 15-6.
4. Measure resistance between socket R2 and a good ground.
  - [a] If the resistance measurement between sockets R2 and Y2, or R2 and battery (-) is less than or equal to  $5\ \Omega$ , the signal line (#120) is shorted to the return line (#452) or battery ground. Repair the short. Refer to section 15.3.10.
  - [b] If the resistance measurement between socket R2 and Y2 is greater than  $5\ \Omega$  or open, and the resistance measurement between socket R2 and a good ground is greater than or equal to  $5\ \Omega$  or open, refer to section 15.3.9.





Figure 15-6 ECM Engine Harness Connector

### 15.3.8 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connector (both ECM and harness side) for damage: bent, corroded and unseated pins or sockets. Check terminals P3 and Y2 of the ECM connector. See Figure 15-7.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 15.3.10.
  - [b] If terminals and connectors are not damaged, reprogram the ECM. Refer to section 15.3.10.




22771

**Figure 15-7 ECM Engine Harness Connector**

### 15.3.9 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connector (both sensor and harness side) for damage: bent, corroded and unseated pins or sockets. Check terminals R2 and Y2 of the ECM connector. See Figure 15-8.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 15.3.10.
  - [b] If terminals and connectors are not damaged, reprogram the ECM. Contact Detroit Diesel Technical Service Group. Refer to section 15.3.10.



**Figure 15-8 ECM Engine Harness Connector**

### 15.3.10 Verify Repairs

Perform the following steps to verify repairs.


1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn vehicle ignition ON.
4. Clear codes
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 110 or 175/4 and any other codes are logged, all system diagnostics are complete. Review this section to find the error. Refer to section 15.3.1.
  - [c] If any codes except code 110 or 175/4 are logged, refer to section 9.1.

---

# 16 FLASH CODE 16 - CLS HIGH

Section	Page
16.1 DESCRIPTION OF FLASH CODE 16 .....	16- 3
16.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 16 .....	16- 3
16.3 TROUBLESHOOTING FLASH CODE 16 .....	16- 4





**Figure 16-1      Coolant Level Sensor**

## 16.1 DESCRIPTION OF FLASH CODE 16

Flash Code 16 indicates that the engine Coolant Level Sensor (CLS), see Figure 16-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor ground circuit

## 16.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 16

The SAE J1587 equivalent code for Flash Code 16 is p 111 3, coolant level circuit high.

## 16.3 TROUBLESHOOTING FLASH CODE 16

The following procedure will troubleshoot Flash Code 16.

### 16.3.1 Sensor Check

Perform the following steps to check the sensor.

1. Turn ignition OFF.
2. Disconnect Coolant Level Sensor (CLS) connector and install a jumper between sockets A and B of the CLS harness connector.
3. Attempt to start and run engine at idle.
4. Read DDR for active codes.
  - [a] If active code 111/3 and any other codes except code 111/4 are logged, refer to section 16.3.2.
  - [b] If active code 111/4 and any other codes are logged, refer to section 16.3.4.
5. Stop engine.

### 16.3.2 Signal Circuit Check

Perform the following steps to check the signal circuit.

1. Turn ignition OFF.
2. Disconnect the CLS.
3. Disconnect the vehicle harness connector.
4. Measure resistance between socket H3 (#115) on the vehicle harness connector and A (#115 signal) of the CLS connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 16.3.3.
  - [b] If the resistance measurement is greater than 5  $\Omega$ , or the signal line #115 is open, repair the open. Refer to section 16.3.7.

### 16.3.3 Ground Circuit Check


Perform the following steps to check the ground circuit.

1. Measure resistance between cavity B (battery ground) of the CLS connector and battery ground.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 16.3.4.
  - [b] If the resistance measurement is greater than 5  $\Omega$ , or open, the ground circuit is open. Repair and refer to section 16.3.7.

### 16.3.4 Signal Short to Ignition Check

Perform the following steps to check for a signal short to ignition.

1. Disconnect the vehicle harness connector at the ECM.
2. Remove the jumper wire at the CLS harness connector.
3. Turn ignition ON.
4. Measure voltage at cavity A (#115 signal) of the CLS connector and battery ground. See Figure 16-2.
  - [a] If the voltage measurement is less than or equal to 6 volts, refer to section 16.3.5.
  - [b] If the voltage measurement is greater than 6 volts, the CLS signal line (#115) is shorted to the 12/24 volt DC line. Repair the short or replace the #115 wire. Refer to section 16.3.7.




**Figure 16-2 Coolant Level Sensor and Circuits**

### 16.3.5 ECM Connectors Check

Perform the following steps to check the ECM connectors.

1. Inspect terminals at the vehicle harness connector (both the sensor and harness side) for bent, corroded and unseated pins or sockets. Check terminal and pin H3 at the ECM and all terminals and pins in the CLS connector. See Figure 16-3.
  - [a] If terminals and connectors are not damaged, replace the CLS. Refer to section 16.3.7. If this is a repeated failure of the CLS, refer to section 16.3.6.
  - [b] If terminals and connectors are damaged, repair both. Refer to section 16.3.7.



**Figure 16-3 Vehicle Harness Connector**

### **16.3.6 Alternator Ground Check**

Perform the following steps to check the alternator ground.

1. Connect all connectors.
2. Remove alternator belt or disable alternator from charging.
3. Start and run the engine.
4. Read logged codes.
  - [a] If no codes are logged, repair the alternator ground circuit. Refer to section 16.3.7.
  - [b] If codes are logged, replace CLS. Refer to section 16.3.7.

### **16.3.7 Verify Repairs**

Perform the following steps to verify the repairs.

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear DDR codes.
5. Start and run the engine for one minute.
6. Stop the engine.
7. Check DDR for codes.
  - [a] If no codes are displayed, troubleshooting is complete.
  - [b] If code 111/3 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 111/3 is logged, and other codes are logged, refer to section 16.3.1, and perform tasks.



---

# 17 FLASH CODE 17 - THROTTLE VALVE HIGH

Section	Page
17.1 DESCRIPTION OF FLASH CODE 17 .....	17- 3
17.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 17 .....	17- 3
17.3 TROUBLESHOOTING FLASH CODE 17 .....	17- 4





## **17.1 DESCRIPTION OF FLASH CODE 17**

Flash Code 17 is currently used for gas fueled engines only. This code indicates that the Throttle Plate Input Voltage has exceeded 95% of the sensor supply voltage (normally >4.75 volts). Typically, the problem is an open sensor return, a short to the sensor supply or throttle body power is low.

## **17.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 17**

The SAE J1587 equivalent code for Flash Code 17 is p 051/3, throttle plate input voltage high.

## 17.3 TROUBLESHOOTING FLASH CODE 17

The following procedure will troubleshoot Flash Code 17.

### 17.3.1 Check Actuator

Perform the following steps to check the actuator.

1. Unplug throttle actuator connector.
2. Turn ignition ON.
3. Plug in DDR.
  - [a] If code p 051/3 is logged, refer to section 17.3.3.
  - [b] If code p 051/4 is logged, refer to section 17.3.5.

### 17.3.2 Check Connectors

Perform the following steps to check the connectors.


1. Turn ignition OFF.
2. Check connectors, ECM side and throttle actuator side, for damaged, bent or broken pins.
  - [a] If the connectors are not damaged, replace the actuator. Refer to section 17.3.6.
  - [b] If the connectors are damaged, bent or have broken pins, repair or replace the connectors or pins; refer to section 17.3.6.

### 17.3.3 Check Sensor

Perform the following steps to check the sensor.

1. Turn ignition OFF.
2. Unplug the engine sensor harness.
3. Measure resistance between W1 and R1. See Figure 17-1.
  - [a] If the resistance measurement is less than or equal to 1,000  $\Omega$ , the wires are shorted to each other. Repair the short or replace the engine sensor harness. Refer to section 17.3.6.

[b] If the resistance measurement is greater than 1,000  $\Omega$ , refer to section 17.3.4.



**Figure 17-1 Gas Engine Sensor Harness**

### 17.3.4 Check for Voltage

Perform the following steps to check for voltage.

1. Reconnect the engine sensor harness.
2. Measure voltage between cavity R1 and battery (-), ground.
  - [a] If the voltage measurement is greater than 4.5 volts, the wire is shorted to the voltage supply. Replace the #907 wire, or replace the harness. Refer to section 17.3.6.
  - [b] If the voltage is less than 4.5 volts, refer to section 17.3.5.

### 17.3.5 Check for Open

Perform the following steps to check for open.

1. Turn ignition OFF. Disconnect engine sensor harness.
2. Place a jumper wire between cavity F and D of the throttle actuator connector.
3. Measure resistance between R1 (#907) and Y2 (#452).
  - [a] If the measured resistance is greater than 1,000  $\Omega$ , the return line (#452) is open. Repair the open and refer to section 17.3.6.
  - [b] If the measured resistance is less than 1,000  $\Omega$ , refer to section 17.3.2.

### 17.3.6 Verify Repairs

Perform the following steps to verify repairs.

1. Plug in all connectors.
2. Clear the codes.
3. Start and run the engine.
4. Operate at idle and rated speed.
5. Turn ignition OFF.
6. Plug in DDR and read the codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If any codes are logged, review this section to find the error. Then, contact Detroit Diesel Technical Services.

---

## 18 FLASH CODE 18 - THROTTLE VALVE LOW

Section	Page
18.1 DESCRIPTION OF FLASH CODE 18 .....	18- 3
18.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 18 .....	18- 3
18.3 TROUBLESHOOTING FLASH CODE 18 .....	18- 4



## **18.1 DESCRIPTION OF FLASH CODE 18**

Flash Code 18 is currently used for gas fueled engines only. This code indicates that the Throttle Valve Plate Input Voltage has dropped below the 5% sensor supply voltage (normally < 0.25 volts). Typically, the problem is an open signal or an open sensor supply.

## **18.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 18**

The SAE J1587 equivalent code for Flash Code 18 is p 051/4, throttle plate input voltage low.



## 18.3 TROUBLESHOOTING FLASH CODE 18

The following procedure will troubleshoot Flash Code 18.

### 18.3.1 Check Actuator

Perform the following steps to check the actuator.

1. Unplug throttle actuator harness connector.
2. Install a jumper wire between cavity F and C.
3. Turn ignition ON.
4. Plug in DDR. Read the codes.
  - [a] If code p 051/3 and any other codes are logged, refer to section 18.3.2.
  - [b] If code p 051/4 is logged, refer to section 18.3.3.

### 18.3.2 Check Connectors

Perform the following steps to check the connectors.


1. Turn ignition OFF.
2. Remove jumper wire.
3. Check connectors, both ECM and throttle actuator side, for bent, broken, or loose connections.
  - [a] If the connectors are not damaged, replace the actuator and refer to section 18.3.7.
  - [b] If the connectors are damaged, bent or have broken pins, repair or replace them. Refer to section 18.3.7.

### 18.3.3 Check for Open

Perform the following steps to check for open.

1. Turn ignition OFF.
2. Move jumper wire from cavity F and C to cavity F and D.
3. Remove engine harness connector.
4. Measure resistance between Y2 (#452) and R1 (#907). See Figure 18-1.
  - [a] If the measured resistance is greater than  $1,000\ \Omega$ , wire #907 is open. Repair the open or replace the harness and refer to section 18.3.7.

[b] If the measured resistance is less than  $1,000\ \Omega$ , refer to section 18.3.4.



**Figure 18-1 Gas Engine Sensor Harness**

### 18.3.4 Check for Short to Return

Perform the following steps to check for a short to the return line.

1. Remove jumper.
2. Measure resistance between Y2 (#452) and R1 (#907), and Y2 (#452) and W1 (#416).
  - [a] If either measured resistance is less than 1,000  $\Omega$ , those wires are shorted to each other. Replace the harness and refer to section 18.3.7.
  - [b] If both measured resistance are greater than 1,000  $\Omega$ , refer to section 18.3.5.

### 18.3.5 Check for Short to Battery (-)

Perform the following steps to check for a short to the battery (-).

1. Measure resistance between R1 (#907) and battery ground, and W1 (#416) and battery ground.
  - [a] If either measured resistance is less than 1,000  $\Omega$ , then that wire is shorted to the battery (-). Replace the harness and refer to section 18.3.7.
  - [b] If the measured resistance is greater than 1,000  $\Omega$ , refer to section 18.3.6.

### **18.3.6 Check for 5 Volt Open**

Perform the following steps to check for a 5 volt open.

1. Plug in the 30-pin connector for the engine sensor harness.
2. Turn ignition ON.
3. Measure voltage between cavity D (#452) and C (#416) of the actuator connector.
  - [a] If the measurement is less than 4.5 volts, wire #416 is open. Repair the open or replace the harness. Refer to section 18.3.7.
  - [b] If the measurement is between 4.5 and 5.5 volts, refer to section 18.3.2.

### **18.3.7 Verify Repairs**

Perform the following steps to verify repairs.

1. Plug all connectors in.
2. Start and run the engine.
3. Plug in the DDR and read the codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code p 051/4 is logged, please review this section from the first step to find the error. Refer to section 18.3.1. Then, contact Detroit Diesel Technical Services.



---

## 19 FLASH CODE 19

Section	Page
19.1 DESCRIPTION OF FLASH CODE 19 .....	19- 3



## 19.1 DESCRIPTION OF FLASH CODE 19

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.





---

## 20 FLASH CODE 20

Section	Page
20.1 DESCRIPTION OF FLASH CODE 20 .....	20- 3



## 20.1 DESCRIPTION OF FLASH CODE 20

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.


No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

## 21 FLASH CODE 21 - TPS HIGH

Section	Page
21.1 DESCRIPTION OF FLASH CODE 21 .....	21- 3
21.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 21 .....	21- 3
21.3 TROUBLESHOOTING FLASH CODE 21 .....	21- 4



**Figure 21-1      Throttle Position Sensor**

## 21.1 DESCRIPTION OF FLASH CODE 21

Flash Code 21 indicates that the Throttle Position Sensor (TPS), see Figure 21-1, input to the ECM has exceeded 95% (normally  $>4.75$  volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor return circuit
- ☐ Sensor signal circuit is shorted to the sensor +5 volt supply

## 21.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 21

The SAE J1587 equivalent code for Flash Code 21 is p 091 3, TPS circuit high.

### 21.2.1 General Throttle Information (Limiting Speed Governor)

The correct TPS counts for DDEC III engines at idle should be 64 - 205 counts.

1. Typical DDEC III foot pedals today, at idle, provide 102 - 205 counts.
2. DDEC II foot pedals can be used on DDEC III engines. The counts from the DDEC II style pedal may go as low as 64 counts at idle, but this is still acceptable.
3. The DDEC system will log a TPS low volt code (PID 091, FMI 4, Flash Code 22) if the TPS counts go below 48.
4. The DDEC system will log a TPS high volt code (PID 091, FMI 3, Flash Code 21) if the TPS counts go above 968 counts.
5. In order to go from 0% to 100% throttle, the counts have to increase 546 above the idle count, or 100 counts, whichever is greater.
6. If an idle validation switch (IVS) is configured, to go from 0% to 100% throttle, the counts have to increase 546 above the counts at which the IVS opens or 100 counts, whichever is greater.
7. If 0% throttle is attained with the foot off the pedal, and if 100% throttle is attained with the pedal to the floor, then the pedal should not be considered a factor for low power complaints.



## **21.3 TROUBLESHOOTING FLASH CODE 21**

The following procedure will troubleshoot Flash Code 21.

### **21.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn ignition ON.
2. Plug in DDR.
3. Read active codes.
  - [a] If active code 91/3 and no other active codes are logged, refer to section 21.3.2.
  - [b] If any or all of the following codes are logged, 91/3, 91/4, 187/3, 100/3, refer to section 91.2.
  - [c] If any codes except 91/3 are logged, refer to section 21.3.3.

### **21.3.2 Sensor Check**


Perform the following steps to check the sensor.

1. Turn ignition OFF.
2. Unplug the TPS connector.
3. Turn ignition ON.
4. Read for active codes.
  - [a] If active code 91/3 and any other codes are logged, refer to section 21.3.7.
  - [b] If code 91/4 is logged, refer to section 21.3.3.

### 21.3.3 Return Circuit Check

Perform the following steps to check the return circuit.

1. Turn ignition OFF.
2. Install a jumper wire between pin A (return #952) and pin B (signal #417) of the TPS harness connector.
3. Disconnect the vehicle harness connector at the ECM.
4. Measure resistance between sockets C3 and D2 on the vehicle harness connector. For Throttle Position Sensor schematic, See figure 21-2.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 21.3.4.
  - [b] If the resistance measurement is greater than  $5\ \Omega$ , and the return line #952 is open, repair the open and refer to section 21.3.10.



**Figure 21-2 Throttle Position Sensor**

### **21.3.4 Check Throttle Position Sensor Adjustment**

Perform the following steps to check for TPS adjustment.

1. Reconnect vehicle harness connector and plug in the TPS.
2. Hook up DDR to the DDL connector and select Throttle Sensor Display.
3. Measure Throttle Counts at both no throttle and full throttle. Take several readings.
  - [a] If TPS counts are ever greater than 968 counts, refer to section 21.3.5.
  - [b] If TPS counts stay less than 968 counts, refer to section 21.3.6.

### **21.3.5 Throttle Position Sensor Adjustment**


Perform the following steps to attempt TPS adjustment.

1. Check for pedal or linkage interferences.
2. Loosen the TPS screws and attempt to adjust for the correct throttle reading (64 - 205 counts). Do not attempt to adjust by bending the pedal mechanism.
3. Recheck counts at idle and at full throttle.
  - [a] If the throttle counts are not correct, refer to section 21.3.6.
  - [b] If the throttle counts are now correct, refer to section 21.3.10.

### 21.3.6 Check Throttle Position Sensor Connectors

Perform the following steps to check the TPS connectors.

1. Check terminals at the TPS connector (both sensor and harness side) for bent, corroded and unseated pins or sockets. See Figure 21-3.
  - [a] If the terminals or connectors are damaged, repair both and refer to section 21.3.10.
  - [b] If the terminals or connectors are not damaged, replace the TPS; refer to section 21.3.10.




**Figure 21-3 Throttle Position Sensor**

### 21.3.7 Check for Short

Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM. Unplug the TPS connector.
3. Read resistance between sockets D2 and A3 on the vehicle harness connector. For ECM vehicle harness connector, see Figure 21-4.
  - [a] If the resistance is greater than 100  $\Omega$  or open, refer to section 21.3.8.
  - [b] If the resistance is less than or equal to 100  $\Omega$ , the signal line (#417) is shorted to the vehicle +5 volt line (#916). Repair the short and refer to section 21.3.10.




**Figure 21-4 ECM Vehicle Harness Connector**

### 21.3.8 Check for Short to Battery

Perform the following steps to check for a short to the battery.

1. Remove both fuses to the ECM.
2. Disconnect the 5-way power harness and vehicle harness connectors at the ECM.
3. Measure resistance between socket D2 on the vehicle harness connector and the 5-way power connector sockets A and C. See Figure 21-5.
  - [a] If the resistance is greater than 100  $\Omega$ , refer to section 21.3.9.
  - [b] If the resistance is less than or equal to 100  $\Omega$ , a short exists between sockets where less than 100  $\Omega$  resistance was read. Repair short and reinsert fuses. Refer to section 21.3.10.




**Figure 21-5 5-Way ECM Power Connector**

### 21.3.9 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM harness connector (both ECM and harness side) for bent, corroded and unseated pins or sockets. See Figure 21-6.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 21.3.10.
  - [b] If terminals and connectors are not damaged, refer to section 21.3.1, to review this section. If review leads back here, install a test ECM or contact Detroit Diesel Technical Service.



**Figure 21-6 ECM Vehicle Harness Connector**

### 21.3.10 Verify Repairs

Perform the following steps to verify repairs.

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear DDR codes.
5. Start and run the engine for one minute. Check idle position and full throttle.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are displayed, troubleshooting is complete.
  - [b] If code 91/3 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 91/3 is logged, and other codes are logged, all system diagnostics are complete. If a problem still exists, review this section from the first step to troubleshoot the error, refer to section 21.3.1.






---

## 22 FLASH CODE 22 - TPS LOW

Section	Page
22.1 DESCRIPTION OF FLASH CODE 22 .....	22- 3
22.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 22 .....	22- 3
22.3 TROUBLESHOOTING FLASH CODE 22 .....	22- 4



**Figure 22-1 Throttle Position Sensor**

## 22.1 DESCRIPTION OF FLASH CODE 22

Flash Code 22 indicates that the Throttle Position Sensor (TPS), see Figure 22-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor +5 volt supply circuit
- ☐ Sensor signal is shorted to sensor return circuit or to ground

## 22.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 22

The SAE J1587 equivalent code for Flash Code 22 is p 091 4, Throttle Position Sensor (TPS) circuit low.

### 22.2.1 General Throttle Information (Limiting Speed Governor)

The correct TPS counts for DDEC III engines at idle should be 64 - 205 counts.

1. Typical DDEC III foot pedals today, at idle, provide 102 - 205 counts.
2. DDEC II foot pedals can be used on DDEC III engines. The counts from the DDEC II style pedal may go as low as 64 counts at idle, but this is still acceptable.
3. The DDEC system will log a TPS low volt code (PID 091, FMI 4, Flash Code 22) if the TPS counts go below 48.
4. The DDEC system will log a TPS high volt code (PID 091, FMI 3, Flash Code 21) if the TPS counts go above 968 counts.
5. In order to go from 0% to 100% throttle, the counts have to increase 546 above the idle count, or 100 counts, whichever is greater.
6. If an idle validation switch (IVS) is configured, to go from 0% to 100% throttle, the counts have to increase 546 above the counts at which the IVS opens or 100 counts, whichever is greater.
7. If 0% throttle is attained with the foot off the pedal, and if 100% throttle is attained with the pedal to the floor, then the pedal should not be considered a factor for low power complaints.

## **22.3 TROUBLESHOOTING FLASH CODE 22**

The following procedure will troubleshoot Flash Code 22.

### **22.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn ignition ON.
2. Plug in DDR.
3. Read active codes.
  - [a] If active code 91/4 and no other active codes are logged, refer to section 22.3.2.
  - [b] If code 91/4 and any or all of the following codes are logged, 91/3, 187/4, or 100/4, refer to section 91.2.
  - [c] If codes other than the above are logged, refer to section 9.1.

### **22.3.2 Check for Device**


Perform the following steps to check for device.

1. If there is a throttle (LSG) wired to use the 417 (LSG) circuit, refer to section 22.3.3.
2. If there is no throttle (LSG) wired to use the 417 (LSG) circuit, contact Detroit Diesel Technical Service, for possible change to the calibration.
  - [a] If required, reprogram the ECM after the mainframe is changed and refer to section 22.3.15.

### 22.3.3 Sensor Check

Perform the following steps to check the sensor:

1. Turn ignition OFF.
2. Disconnect the TPS connector.
3. Install a jumper wire between sockets B (signal #417) and C (5V supply #916); see Figure 22-2.
4. Turn ignition ON.
5. Read active codes.
  - [a] If code 91/4 and any other codes are logged, refer to section 22.3.7.
  - [b] If code 91/3 and any other codes are logged, refer to section 22.3.4.



**Figure 22-2 Throttle Position Sensor**

### **22.3.4 Check Throttle Position Sensor Adjustment**

Perform the following steps to check the TPS adjustment:

1. Remove jumper and reconnect TPS.
2. Hook DDR to the DDL connector and select TPS - Counts.
3. Read Throttle Counts at both no throttle and full throttle positions. Take several readings.
  - [a] If at any time counts go lower than 49 counts, refer to section 22.3.5.
  - [b] If counts never go lower than 49 counts, refer to section 22.3.6.

### **22.3.5 Attempt Throttle Position Sensor Adjustment**

Perform the following steps to attempt a TPS adjustment:

1. Check for pedal or linkage interferences.
2. Loosen the TPS screws and attempt to adjust for the correct throttle reading (normal range - 64-205 counts). Do not attempt to adjust by bending the pedal mechanism.
3. Recheck counts at idle and at full throttle.
  - [a] If the throttle count has been corrected, refer to section 22.3.15.
  - [b] If the problem could not be corrected, refer to section 22.3.6.

### 22.3.6 Check Throttle Position Sensor Connectors

Perform the following steps to check the TPS connectors:

1. Check terminals at the TPS connector (both sensor and harness side) for bent, corroded, and unseated pins or sockets.
  - [a] If the terminals or the connectors are damaged, repair them. Refer to section 22.3.15.
  - [b] If the terminals and connectors are not damaged, replace the TPS and refer to section 22.3.15.

### 22.3.7 Check for +5 Volts

Perform the following steps to check for +5 volts:


1. Remove jumper wire.
2. Turn ignition ON.
3. Measure voltage on TPS harness connector, socket C (5V supply #916) (red lead) to socket A (return #952) (black lead).
  - [a] If measured voltage is greater than 6 volts, refer to section 22.3.13.
  - [b] If measured voltage is less than 4 volts, refer to section 22.3.11.
  - [c] If measured voltage is between 4 and 6 volts, refer to section 22.3.8.



### 22.3.8 Check for Short

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Measure resistance between sockets A (return #952) and B (signal #417) at the TPS harness connector. See Figure 22-3.
4. Measure resistance between socket B (signal #417) and a good ground (battery ground and chassis ground).
  - [a] If resistance measurement is less than or equal to  $100\ \Omega$ , the signal line #417 is shorted to the return line #952 or battery ground. Repair short. Refer to section 22.3.15.
  - [b] If resistance measurement on both readings is greater than  $100\ \Omega$  or open, refer to section 22.3.9.



**Figure 22-3 Throttle Position Sensor**

### 22.3.9 Check for Signal Open

Perform the following steps to check for signal open:

1. Install a jumper wire between sockets A (return #952) and B (signal #417) of the TPS harness connector.
2. Measure resistance between sockets D2 and C3 on the vehicle connector.
  - [a] If the resistance is less than or equal to 5  $\Omega$ , refer to section 22.3.10.
  - [b] If the resistance is greater than 5  $\Omega$  or open, the signal line (#417) or return line (#952) are open, repair the open. Refer to section 22.3.15.

### 22.3.10 Check ECM Connectors

Perform the following steps to check the ECM connectors:

1. Check terminals at the ECM harness connector (both ECM and harness side) for bent, corroded, and unseated pins or sockets. See Figure 22-4.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 22.3.15.
  - [b] If terminals and connectors are not damaged, call Detroit Diesel Technical Service for assistance.





Figure 22-4 ECM Vehicle Harness Connector

### 22.3.11 Check for Short

Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Measure resistance between sockets A (return #952) and C (5V #916) on the TPS harness connector. See Figure 22-5.
  - [a] If resistance between sockets A and C is greater than 1,000  $\Omega$  or open, refer to section 22.3.12.
  - [b] If resistance between sockets A and C is less than or equal to 1,000  $\Omega$  or open, the 5V wire (#916) is shorted to the return (#952). Repair the short and refer to section 22.3.15.




**Figure 22-5 ECM Vehicle Harness Connector**

### 22.3.12 Check for Open +5 Volt Line

Perform the following steps to check for an open +5 volt line:

1. Install a jumper wire between sockets A (return #952) and C (5V #916) on the TPS harness connector.
2. Measure resistance between sockets A3 and C3 on the vehicle harness connector.  
See Figure 22-6.
  - [a] If resistance between sockets A3 and C3 is less than or equal to  $5\ \Omega$  or open, refer to section 22.3.10.
  - [b] If resistance between sockets A3 and C3 is greater than or equal to  $5\ \Omega$  or open, the vehicle +5 volt line (#916) is open. Repair the open. Refer to section 22.3.15.




**Figure 22-6 Throttle Position Sensor**

### 22.3.13 Check for Short to Battery +

Perform the following steps to check for a short to the battery +:

1. Turn ignition OFF.
2. Remove both fuses to ECM.
3. Disconnect the 5-way power connector at the ECM.
4. Measure resistance between socket D2 on the vehicle harness connector and the 5-way power connector sockets A and C. See Figure 22-7.
  - [a] If measured resistance is greater than  $100\ \Omega$  or open, refer to section 22.3.14.
  - [b] If measured resistance is less than or equal to  $100\ \Omega$ , a short exists between sockets where resistance was measured. Repair short and reinsert fuses; refer to section 22.3.15.



**Figure 22-7 ECM Vehicle Harness Connector**

### 22.3.14 Check for Outside DDEC Battery +

Perform the following steps to check for outside DDEC battery +:

1. Turn ignition OFF.
2. Remove ECM 5-pin power connector.
3. Remove ECM vehicle harness connector.
4. Turn ignition ON.
5. Measure voltage A3 (red lead) to battery ground.
6. Measure voltage C3 (red lead) to battery ground.
  - [a] If measured voltage is less than 0.2 volts, refer to section 22.3.10.
  - [b] If measured voltage is greater than 0.2 volts, outside power is spliced/shorted into either line #952 or line #916. Remove the splice/short. Refer to section 22.3.15.

### 22.3.15 Verify Repairs

Perform the following steps to verify repairs:


1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes with DDR.
5. Start and run the engine for one minute at all throttle positions.
6. Stop engine.
7. Read active codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 91/4 and any other codes are logged, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 22.3.1.
  - [c] If code 91/4 is not logged, but other codes are logged, refer to section 9.1.

---

# 23 FLASH CODE 23 - FUEL TEMP SENSOR HIGH

Section	Page
23.1 DESCRIPTION OF FLASH CODE 23 .....	23- 3
23.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 23 .....	23- 3
23.3 TROUBLESHOOTING FLASH CODE 23 .....	23- 4





**Figure 23-1 Fuel Temperature Sensor**

## 23.1 DESCRIPTION OF FLASH CODE 23

Flash Code 23 indicates that the engine Fuel Temperature Sensor (FTS), see Figure 23-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

### NOTE:

This code will only be logged during warm engine operation.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor circuit return
- ☐ Sensor signal circuit is shorted to the sensor +5 volt supply

## 23.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 23

The SAE J1587 equivalent code for Flash Code 23 is p 174 3, fuel temperature circuit high.


## 23.3 TROUBLESHOOTING FLASH CODE 23

The following procedure will troubleshoot Flash Code 23.

### 23.3.1 Sensor Check

Perform the following steps to check the sensor:

1. Turn ignition OFF.
2. Disconnect the FTS connector.
3. Install a jumper wire between sockets A and B of the FTS harness connector, see Figure 23-2.
4. Turn ignition ON.
5. Read active codes.
  - [a] If code 174/4 and any other codes except code 174/3 are logged, refer to section 23.3.2.
  - [b] If any code except 174/4 is logged, refer to section 23.3.4.




**Figure 23-2 Fuel Temperature Sensor**

### 23.3.2 Check for Short to +5 Volt Line

Perform the following steps to check for a short to the +5 volt line.

1. Turn ignition OFF.
2. Remove jumper wire.
3. Disconnect the engine harness connector at the ECM.
4. Measure resistance between sockets R3 and W1 on the engine harness connector.  
See Figure 23-3.
  - [a] If the measured resistance is greater than 100  $\Omega$  or open, refer to section 23.3.3.
  - [b] If the measured resistance is less than or equal to 100  $\Omega$ , the signal line #472 is shorted to the engine +5 volt line #416. Repair the short; refer to section 23.3.6.




**Figure 23-3 ECM Engine Harness Connector**

### 23.3.3 Check Fuel Temperature Sensor Connectors

Perform the following steps to check the FTS connectors:

1. Check terminals at the FTS harness connector (both sensor and harness side) for bent, corroded, and unseated pins or sockets. See Figure 23-4.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 23.3.6.
  - [b] If terminals and connectors are not damaged, replace the FTS. Refer to section 23.3.6.




**Figure 23-4 Fuel Temperature Sensor**

### 23.3.4 Open Line Check

Perform the following steps to check for an open line.

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM. The jumper wire is still in place at the FTS connector.
3. Measure resistance between sockets R3 and Y2 on the engine harness connector. See Figure 23-5.
  - [a] If the measured resistance is greater than 5  $\Omega$  or open, the signal line #472 or return line #452 is open. Repair the open; refer to section 23.3.6.
  - [b] If the measured resistance is less than or equal to 5  $\Omega$ , refer to section 23.3.5.




**Figure 23-5 ECM Engine Harness Connector**

### 23.3.5 Check ECM Connectors

Perform the following steps to check the ECM connectors:

1. Check terminals at the ECM harness connector (both ECM and harness side) for bent, corroded, and unseated pins or sockets. See Figure 23-6.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 23.3.6.
  - [b] If terminals and connectors are not damaged, install a test ECM. Refer to section 23.3.6.



**Figure 23-6 ECM Engine Harness Connector**

### 23.3.6 Verify Repairs

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes with DDR.
5. Start and run the engine for eight minutes.
6. Stop engine.
7. Read codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 174/3 and any other codes are logged, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 23.3.1.
  - [c] If code 173/4 is not logged, but other codes are logged, refer to section 9.1.






---

## 24 FLASH CODE 24 - FUEL TEMP SENSOR LOW

Section	Page
24.1 DESCRIPTION OF FLASH CODE 24 .....	24- 3
24.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 24 .....	24- 3
24.3 TROUBLESHOOTING FLASH CODE 24 .....	24- 4



**Figure 24-1      Fuel Temperature Sensor**

## **24.1 DESCRIPTION OF FLASH CODE 24**

Flash Code 24 indicates that the engine Fuel Temperature Sensor (FTS), see Figure 24-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Sensor signal circuit is shorted to sensor return circuit or to ground

## **24.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 24**

The SAE J1587 equivalent code for Flash Code 24 is p 174 4, fuel temperature circuit low.

## 24.3 TROUBLESHOOTING FLASH CODE 24

The following procedure will troubleshoot Flash Code 24.

### 24.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.

1. Turn ignition ON.
2. Plug in DDR.
3. Read active codes.
  - [a] If active code 174/4 and no other active codes are logged, refer to section 24.3.2.
  - [b] If any or all of the following codes are logged, 110/3, 175/3, 174/3, or 102/3, refer to section 91.2.
  - [c] If codes other than the above are logged, refer to section 24.3.2.

### 24.3.2 Sensor Check


Perform the following steps to check the sensor:

1. Turn ignition OFF.
2. Disconnect the FTS connector.
3. Start and run engine for eight minutes.
4. Read active codes with engine still running.
  - [a] If code 174/4 and any other codes are logged, refer to section 24.3.4.
  - [b] If code 174/3 and any other codes except 174/4 are logged, refer to section 24.3.3.

### 24.3.3 Check Fuel Temperature Sensor Connectors

Perform the following steps to check the FTS connectors:

1. Check terminals at the FTS connector (both sensor and harness side) for bent, corroded, and unseated pins or sockets. See Figure 24-2.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 24.3.6.
  - [b] If terminals and connectors are not damaged, replace the FTS. Refer to section 24.3.6.




**Figure 24-2 Fuel Temperature Sensor**

### 24.3.4 Check for Short

Perform the following steps to check for a short:

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Measure resistance between sockets R3 and Y2 on the engine harness connector.  
See Figure 24-3.
4. Measure resistance between socket R3 and a good ground (battery ground and chassis ground).
  - [a] If resistance between sockets R3 and Y2, or R3 and battery ground, is less than or equal to  $10,000\ \Omega$ , the signal line (#472) is shorted to the return line (#452) or battery ground. Repair short. Refer to section 24.3.6.
  - [b] If resistance between sockets R3 and Y2 is greater than  $10,000\ \Omega$  or open, and resistance between socket B and a good ground is greater than  $10,000\ \Omega$  or open, refer to section 24.3.5.




**Figure 24-3 Engine Harness Connector**

### 24.3.5 Check ECM Connectors

Perform the following steps to check the ECM connectors:

1. Check terminals at the ECM harness connector (both ECM and harness side) for bent, corroded, and unseated pins or sockets. See Figure 24-4.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 24.3.6.
  - [b] If terminals and connectors are not damaged, contact Detroit Diesel Technical Service. Refer to section 24.3.6.



**Figure 24-4 ECM Engine Harness Connector**



### 24.3.6 Verify Repairs

Perform the following steps to verify repairs:

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes with DDR.
5. Start and run the engine for eight minutes.
6. Stop engine.
7. Read active codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 174/4 and any other codes are logged, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 24.3.1.
  - [c] If code 174/4 is not logged, but other codes are logged, refer to section 9.1.

**25 FLASH CODE 25**

Section	Page
25.1 DESCRIPTION OF FLASH CODE 25 .....	25- 3



## **25.1 DESCRIPTION OF FLASH CODE 25**

Code 25 will be flashed to indicate that the DDEC system has no active or inactive codes. No troubleshooting is required.

If using the DDR, the description will read:

No Active Codes or No Inactive Codes



---

# 26 FLASH CODE 26 - AUXILIARY INPUT ACTIVE

Section	Page
26.1 DESCRIPTION OF FLASH CODE 26 .....	26- 3
26.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 26 .....	26- 3
26.3 TROUBLESHOOTING FLASH CODE 26 .....	26- 4



## **26.1 DESCRIPTION OF FLASH CODE 26**

Flash Code 26 indicates that the Auxiliary Engine Shutdown #1 switch input to the ECM is active. The active switch input represents a low (grounded) external input circuit to the ECM.

Indicates that the Auxiliary Engine Shutdown #2 switch input to the ECM is active. The active switch input represents a low (grounded) external input circuit to the ECM.

## **26.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 26**

The SAE J1587 equivalent codes for Flash Code 26 are:

- ☐ s 025 11 - auxiliary shutdown #1 active
- ☐ s 061 11 - auxiliary shutdown #2 active



## 26.3 TROUBLESHOOTING FLASH CODE 26

The following procedure will troubleshoot Flash Code 26.

### 26.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.

1. Turn ignition ON. Start and run the engine.
2. Plug in DDR.
3. Read active codes.
  - [a] If codes s 25-11 or s 61-11 are logged, refer to section 26.3.2.
  - [b] If codes s 25-11 and s 61-11 are not logged, refer to section 9.1.

### 26.3.2 Check Calibration Configuration

Perform the following steps to check the calibration configuration:

1. Select ECM input/output configuration.
2. Determine cavity and wire number that is causing code to be logged.
3. Select switch/light status.
4. Determine status of that wire/cavity.
  - [a] If the switch reads OFF, refer to section 26.3.3.
  - [b] If the switch reads ON, the OEM supplied switch/relay is grounding the wire or a short to ground exists. Determine OEM supplied device or repair the short. Refer to section 26.3.4.
  - [c] If no OEM device is used, remove the wire from the connector and plug, or use programming station to disable the function.

### **26.3.3 Confirm Switch Status**

Perform the following steps to confirm switch status:

1. Start and run the engine for one minute.
2. Again, read switch status.
  - [a] If the switch reads OFF, the condition no longer exists. Contact the OEM to learn which item is wired to this cavity. Refer to section 26.3.4.
  - [b] If the switch reads ON, the OEM supplied device is grounding this wire. Contact the OEM for repair procedure. Refer to section 26.3.4.

### **26.3.4 Verify Repairs**

Perform the following steps to verify repairs:


1. Turn ignition ON.
2. Clear codes with DDR.
3. Note status of CEL/SEL.
4. If CEL/SEL not on, start and run the engine for one minute.
5. Read active and inactive codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If codes 25 or 61-11 and any other codes are logged, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 26.3.1.
  - [c] If codes 25 or 61-11 are not logged, but other codes are logged, refer to section 9.1.



---

## 27 FLASH CODE 27 - AIR TEMP SENSOR HIGH

Section	Page
27.1 DESCRIPTION OF FLASH CODE 27 .....	27- 3
27.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 27 .....	27- 3
27.3 TROUBLESHOOTING FLASH CODE 27 .....	27- 4



**Figure 27-1      Air Temperature Sensor**

## 27.1 DESCRIPTION OF FLASH CODE 27

Flash Code 27 indicates that the engine Air Temperature Sensor (ATS), see Figure 27-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

### NOTE:

This code will only be logged during warm engine operation.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor return circuit

## 27.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 27

The SAE J1587 equivalent code for Flash Code 27 is p 172 3, air temperature circuit high.


## 27.3 TROUBLESHOOTING FLASH CODE 27

The following procedure will troubleshoot Flash Code 27.

### 27.3.1 Sensor Check

Perform the following steps to check the sensor.

1. Turn vehicle ignition OFF.
2. Disconnect ATS connector.
3. Install a jumper wire between sockets A and B of the ATS harness connector.  
See Figure 27-2.
4. Turn ignition ON.
5. Start and run engine for one minute (ensure oil temp is greater than 140 ° F).
6. Read active codes.
  - [a] If code 172/4 or any other codes except 172/3 are logged, refer to section 27.3.2.
  - [b] If any codes except code 172/4 are logged, refer to section 27.3.4.




**Figure 27-2 Air Temperature Sensor**

### 27.3.2 Check for Short to +5 Volt Line

Perform the following steps to check for a short to the +5 volt line.

1. Turn ignition/engine OFF.
  2. Remove jumper wire.
  3. Disconnect the engine harness connector at the ECM.
  4. Measure resistance between sockets N2 and W1 on the engine harness connector.  
See Figure 27-3.
- [a] If the resistance measurement is less than or equal to  $10\ \Omega$ , the signal line #132 is shorted to the engine +5 volt line (#416). Repair the short and refer to section 27.3.6.
- [b] If the resistance measurement between sockets N2 and W1 is greater than  $10\ \Omega$  or open, refer to section 27.3.3.




**Figure 27-3 ECM Engine Harness Connector**



### 27.3.3 Check Air Temperature Sensor Connectors

Perform the following steps to check the ATS connectors.

1. Check terminals at the ATS connector (both sensor and harness side) for damage; bent, corroded and unseated pins or sockets. See Figure 27-4.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 27.3.6.
  - [b] If terminals and connectors are not damaged, replace the ATS. Refer to section 27.3.6.




**Figure 27-4 Air Temperature Sensor**

### 27.3.4 Open Line Check

Perform the following steps to check for an open line.

1. Turn ignition OFF.
2. Disconnect the engine harness connector at the ECM. (Jumper still in place.)
3. Measure resistance between sockets N2 and Y2 on the engine harness connector. See Figure 27-5.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 27.3.5.
  - [b] If the resistance measurement between sockets N2 and W1 is greater than 5  $\Omega$  or open, the signal line #132 or return line #452 is open. Repair the open. Refer to section 27.3.6.



**Figure 27-5 ECM Engine Harness Connector**

### 27.3.5 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connector (both ECM and harness side) for damage: bent, corroded and unseated pins or sockets. See Figure 27-6.
  - [a] If terminals or connectors are damaged, repair them. Refer to section 27.3.6.
  - [b] If terminals and connectors are not damaged, contact Detroit Diesel Technical Service. Refer to section 27.3.6.




Figure 27-6 ECM Engine Harness Connector

### 27.3.6 Verify Repairs

Perform the following steps to verify repairs.


1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn vehicle ignition ON.
4. Clear codes.
5. Start and run the engine for eight minutes.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 172/3 and any other codes are logged, all system diagnostics are complete. Review this section to find the error. Refer to section 27.3.1.
  - [c] If any codes except code 172/3 are logged, refer to section 9.1.



---

## 28 FLASH CODE 28 - AIR TEMP SENSOR LOW

Section	Page
28.1 DESCRIPTION OF FLASH CODE 28 .....	28- 3
28.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 28 .....	28- 3
28.3 TROUBLESHOOTING FLASH CODE 28 .....	28- 4



**Figure 28-1      Air Temperature Sensor**

## 28.1 DESCRIPTION OF FLASH CODE 28

Flash Code 28 indicates that the engine Air Temperature Sensor (ATS), see Figure 28-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Sensor signal circuit is shorted to sensor return
- ☐ Sensor signal circuit is shorted to ground

## 28.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 28

The SAE J1587 equivalent code for Flash Code 28 is p 172 4, air temperature circuit low.



## 28.3 TROUBLESHOOTING FLASH CODE 28

The following procedure will troubleshoot Flash Code 28.

### 28.3.1 Multiple Code Check


Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in DDR.
3. Read active codes.
  - [a] If code 172/4 was logged and there are no other codes logged, refer to section 28.3.2.
  - [b] If code 172/4 and any of the following codes 110/3, 175/3, 174/3, 72/3 or 102/3 were logged, refer to section 90.1.
  - [c] If code 172/4 and any code except the following were logged 110/3, 175/3, 174/3, 72/3 or 102/3, refer to section 28.3.2.

### 28.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn vehicle ignition OFF.
2. Disconnect the ATS connector. See Figure 28-2.



**Figure 28-2 Engine Harness to Air Temperature Sensor Connector**

3. Start engine and run until Check Engine light comes on, or for eight minutes.
4. With engine still running, read active codes.
  - [a] If code 172/4 and any other codes were logged, refer to section 28.3.4.
  - [b] If 172/3 and any other codes except 172/4 were logged, refer to section 28.3.3.

### 28.3.3 Check Air Temperature Sensor Connectors


Perform the following steps to check the ATS connector.

1. Check terminals at the ATS connector (both sensor and harness side) for damage; bent, corroded and unseated pins or sockets.
  - [a] If terminals and connectors are not damaged, replace ATS. Refer to section 28.3.6.
  - [b] If terminals and connectors are damaged, repair/replace wires and refer to section 28.3.6.

### 28.3.4 Check for Short

Perform the following steps to check for a short.

1. Turn the ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Measure resistance between sockets N2 and Y2 on the engine harness connector.  
See Figure 28-3.
4. Measure resistance between socket N2 and a good ground.
  - [a] If the resistance measurement between sockets N2 and Y2 and between socket N2 and a good ground is greater than  $10\ \Omega$  or open, refer to section 28.3.5.
  - [b] If the resistance measurement between sockets N2 and Y2, or N2 and battery negative, is less than or equal to  $10\ \Omega$ , the signal line #132 is shorted to the return line #452 or battery ground. Repair short. Refer to section 28.3.6.



**Figure 28-3 ECM Engine Harness Connector**

### 28.3.5 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM harness connector (both ECM and harness side) for damage; bent, corroded and unseated pins or sockets, especially N2 and Y2 of the ECM connector.
  - [a] If terminals or connectors are not damaged, contact Detroit Diesel Technical Services and refer to section 28.3.6.
  - [b] If terminals and connectors are damaged, repair them. Refer to section 28.3.6

### 28.3.6 Verify Repairs

Perform the following steps to verify repairs.

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for eight minutes.
6. Stop engine.
7. Read inactive codes.
  - [a] If no codes are displayed, troubleshooting is complete.
  - [b] If code 172/4 is logged with any other codes, all system diagnostics are complete. Review this section from the first step to find the error.
  - [c] If code 172/4 is not logged, but other codes are logged, refer to section 9.1.



---

# 29 FLASH CODE 29

Section	Page
29.1 DESCRIPTION OF FLASH CODE 29 .....	29- 3



## **29.1 DESCRIPTION OF FLASH CODE 29**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.





---

## 30 FLASH CODE 30

Section	Page
30.1 DESCRIPTION OF FLASH CODE 30 .....	30- 3



### **30.1 DESCRIPTION OF FLASH CODE 30**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

## 31 FLASH CODE 31 - ENGINE BRAKE FAULT CODE

Section	Page
31.1 DESCRIPTION OF FLASH CODE 31 .....	31- 3
31.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 31 .....	31- 3
31.3 TROUBLESHOOTING FLASH CODE 31 .....	31- 4



### **31.1 DESCRIPTION OF FLASH CODE 31**

Flash Code 31 indicates the engine brake low or medium circuit has an open or is shorted to battery ground.

This diagnostic condition is typically:

- ☐ Output circuit open
- ☐ Output wire is shorted to ground

### **31.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 31**

The SAE J1587 equivalent code for Flash Code 31 is s 051 3/4 or s 052 3/4.



## **31.3 TROUBLESHOOTING FLASH CODE 31**

The following procedure will troubleshoot Flash Code 31.

### **31.3.1 Check Configuration**

Perform the following steps to check configuration.

1. If the unit has engine brakes, refer to section 31.3.2.
2. If the unit does not have engine brakes, the ECM is configured for engine brakes and shouldn't be. Contact DDC with the engine serial number to have the data changed. Reprogram the ECM after the change. Refer to section 31.3.10.

### **31.3.2 Determine Failure Mode**

Perform the following steps to determine failure mode.

1. Turn vehicle ignition ON.
2. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL) connector.
3. Read SAE code (051 or 052).
  - [a] If the reading is FMI=3, there is an open. Refer to section 31.3.3.
  - [b] If the reading is FMI=4, there is a short to ground. Refer to section 31.3.7.

### **31.3.3 Determine Engine Type**

Perform the following steps to determine engine type.

1. Is this a Series 55 engine?
  - [a] If yes, reprogram the ECM. Then, refer to section 31.3.10.
  - [b] If no, refer to section 31.3.4.

### 31.3.4 Check for Open

Perform the following steps to check for open.

1. Turn vehicle ignition OFF.
2. Disconnect 2-pin connector pigtail from engine brake harness.
3. Disconnect 30-pin engine harness connector.
4. Install a jumper wire between pins #561 and #562, ECM side of pigtail .
5. Measure resistance between S3 (#561) and T3 (#562) of the engine harness connector.
  - [a] If measured resistance is less than 50  $\Omega$  , refer to section 31.3.5.
  - [b] If measured resistance is greater than 50  $\Omega$  , one or both wires are open. Repair open. Refer to section 31.3.10.

### 31.3.5 Check for Open (Inside Valve Cover)

Perform the following steps to check for open in the inside valve cover.

1. Reconnect the engine harness connector. See Figure 31-1.
2. Relocate the jumper to pins A and B of the brake harness connector (brake side).
3. Remove rocker cover.
4. Disconnect the two #621 leads and the one #622 lead from the brake solenoids.

5. Measure resistance between both #621 wires and #622 wire.

- [a] If measured resistance is greater than 50  $\Omega$  or open, an open exists in one of the wires where the check was made. Repair open or replace the injector harness. Refer to section 31.3.10.
- [b] If measured resistance is less than 50  $\Omega$ , refer to section 31.3.6.




Figure 31-1 Engine Brake Harness Schematic

### 31.3.6 Check for Cylinder Block Ground

Perform the following steps to check for cylinder block ground.

1. If the cylinder block is connected to the battery ground, refer to section 31.3.9.
2. If the cylinder block is not connected to the battery ground, install a ground strap from the cylinder block to the battery negative (-). Refer to section 31.3.10.

### 31.3.7 Check for Short

Perform the following steps to check for a short.

1. Turn vehicle ignition OFF.
2. Unplug the engine harness connector.
3. Measure resistance between S3 (#561) and a battery ground, and S3 (#561) and the engine block. Repeat this check between T3 (#562) and battery ground, and T3 (#562) and the engine block.
  - [a] If resistance for all measurements is greater than 5  $\Omega$  or open, refer to section 31.3.8.
  - [b] If any measured resistance is less than 5  $\Omega$ , the wire where the measurement was read is shorted to ground or to the engine. Repair short or replace the wire. Refer to section 31.3.10.

### 31.3.8 Check for Short

Perform the following steps to check for a short between wires.

1. Measure resistance between S3 (#561) and T3 (#562).
  - [a] If measured resistance is less than 10  $\Omega$ , the S3 and T3 wires are shorted to each other. Repair short. Refer to section 31.3.10.
  - [b] If measured resistance is greater than 10  $\Omega$ , refer to section 31.3.9.

### **31.3.9 Check Brake Solenoids**

Perform the following steps to check for brake solenoids.

1. Check brake solenoids. Refer to OEM guidelines.
  - [a] If the solenoids are in good condition, contact Detroit Diesel Technical Service. Refer to section 31.3.10.
  - [b] If the solenoids are damaged, repair or replace them. Refer to section 31.3.10.

### **31.3.10 Verify Repairs**

Perform the following steps to verify repairs.

1. Connect any connectors removed for troubleshooting.
2. Start and run the engine. (Operate the engine brake.)
  - [a] If no lights come on, and no codes are logged, the repairs are complete. No further troubleshooting is required.
  - [b] If Check Engine Light displays with codes s 051 3/4 or 052 3/4, review this section to find the error. Refer to section 31.3.1.

---

## **32 FLASH CODE 32 - CEL / SEL FAULT**

<b>Section</b>	<b>Page</b>
32.1 DESCRIPTION OF FLASH CODE 32 .....	32- 3
32.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 32 .....	32- 3
32.3 TROUBLESHOOTING FLASH CODE 32 .....	32- 4



### 32.1 DESCRIPTION OF FLASH CODE 32

Flash Code 32 indicates that the wire for the SEL or CEL is open or shorted to Battery +.

This diagnostic condition is typically:

- ☐ Open/broken output wire
- ☐ Shorted output wire

### 32.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 32

The SAE J1587 equivalent code for Flash Code 32 is:

- ☐ s 238/3 SEL short to battery
- ☐ s 238/4 SEL open circuit
- ☐ s 239/3 CEL short to battery
- ☐ s 239/4 CEL open circuit



## **32.3 TROUBLESHOOTING FLASH CODE 32**

The following procedure will troubleshoot Flash Code 32.

### **32.3.1 Determine Failure Mode Identifier (3 or 4)**


Perform the following steps to determine FMI.

1. Turn ignition ON.
2. Plug in diagnostic data reader (DDR) into the diagnostic data link (DDL).
3. Read codes.
  - [a] If code 238/4 or 239/4 is logged, reprogram the ECM. Refer to section 32.3.3.
  - [b] If code 238/3 or 239/3 is logged, refer to section 32.3.2.

### 32.3.2 Check for Short to Battery

Perform the following steps to determine failure.

1. Turn vehicle ignition OFF.
2. Disconnect vehicle harness connector.
3. Turn ignition ON.
4. Remove CEL bulb and SEL bulb.
5. Measure voltage between B2 (#509) and a good ground. See Figure 32-1.



**Figure 32-1 ECM Vehicle Harness Connector**

6. Measure voltage between B1 and a good ground.
  - [a] If either measurement was greater than 0.5 volts, the wire that had the reading is shorted to some voltage source. Replace the wire(s). Refer to section 32.3.3.
  - [b] If no measurement was greater than 0.5 volts, contact Detroit Diesel Technical Service.

### 32.3.3 Verify Repairs


Perform the following steps to verify repairs.

1. Connect all connectors.
2. Start and run the engine.
3. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL). Read codes.
  - [a] If active code 32 is logged, review this section to find the error. Refer to section 32.1.
  - [b] If code 32 is not logged, troubleshooting is complete.

---

## 33 FLASH CODE 33 - TBS HIGH

Section	Page
33.1 DESCRIPTION OF FLASH CODE 33 .....	33- 3
33.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 33 .....	33- 3
33.3 TROUBLESHOOTING FLASH CODE 33 .....	33- 4



**Figure 33-1 Turbo Boost Sensor**

### 33.1 DESCRIPTION OF FLASH CODE 33

Flash Code 33 indicates that the engine Turbo Boost Sensor (TBS), see Figure 33-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor return circuit
- ☐ Sensor signal circuit is shorted to the sensor +5 volt supply

### 33.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 33

The SAE J1587 equivalent code for Flash Code 33 is p 102 3.

### 33.3 TROUBLESHOOTING FLASH CODE 33

The following procedure will troubleshoot Flash Code 33.

#### 33.3.1 Multiple Code Check


Perform the following steps to check for multiple codes.

1. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL).
2. Turn vehicle ignition switch ON.
3. Read active codes.
  - [a] If code 102/3 and no other codes were logged, refer to section 33.3.2.
  - [b] If any of the following codes are also present: 72/3 or 4, 73/3 or 4, 94/3 or 4, 100/3 or 4, 101/3 or 4, 110/3 or 4, 174/3 or 4, 175/3 or 4, refer to section 90.1.

### 33.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn vehicle ignition OFF.
2. Disconnect the TBS connector. See Figure 33-2.
3. Start and run the engine at idle.
4. Read active codes logged.
  - [a] If active code 102/3 and any other codes are logged, refer to section 33.3.5.
  - [b] If active code 102/4 and any other codes except 102/3 are logged, refer to section 33.3.3.




**Figure 33-2 Turbo Boost Sensor**




### 33.3.3 Return Circuit Check

Perform the following steps to check the return circuit.

1. Turn ignition switch OFF.
2. Install a jumper wire between pin A and pin B of the TBS harness connector.  
See Figure 33-3.
3. Disconnect the engine harness connector at the ECM. See Figure 33-4.
4. Measure resistance between sockets P1 and Y2 on the engine harness connector.
  - [a] If resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 33.3.4.
  - [b] If resistance measurement is greater than  $5\ \Omega$ , the return line #452 is open. Repair the open. Refer to section 33.3.8.



**Figure 33-3 Turbo Boost Sensor**



**Figure 33-4 ECM Engine Harness Connector**

### 33.3.4 Check Turbo Boost Sensor Connectors

Perform the following steps to check the TBS connectors.

1. Check terminals at the TBS connector (both sensor and harness side) for damage: bent, corroded, and unseated pins or sockets. See Figure 33-5.
  - [a] If the terminals and connectors are damaged, repair them. Refer to section 33.3.8.
  - [b] If the terminals and connectors are not damaged, replace the TBS. Refer to section 33.3.8.





Figure 33-5 Turbo Boost Sensor

### 33.3.5 Check for Short to +5 Volt Line

Perform the following steps to check for a short to the +5 volt line:

1. Turn vehicle ignition OFF.
2. Disconnect engine harness connector from the ECM.
3. Measure resistance between sockets P1 and W1 on the engine harness connector.  
See Figure 33-6.
  - [a] If measured resistance is less than or equal to 10,000  $\Omega$ , the signal line #432 is shorted to the engine +5 volt line #416. Repair short. Refer to section 33.3.8.
  - [b] If measured resistance is greater than 10,000  $\Omega$ , or open, refer to section 33.3.6.




**Figure 33-6 ECM Engine Harness Connector**

### 33.3.6 Check for Short to Battery

Perform the following steps to check for a short to the battery (+):

1. Remove both fuses to the ECM.
2. Disconnect the vehicle harness and 5-way power connector harness at the ECM.  
See Figure 33-7.
3. Measure resistance between sockets P1 of the engine harness connector and B3 on the vehicle harness connector.
4. Measure resistance between socket P1 on the engine harness connector and the 5-way power harness connector sockets A and C.
  - [a] If the resistance measurement is less than or equal to 100  $\Omega$ , a short exists between sockets where the measurement was taken. Repair short and reinsert fuses, or reset breakers. Refer to section 33.3.8.
  - [b] If the resistance measurement is greater than 100  $\Omega$ , or open, refer to section 33.3.7.



**Figure 33-7 5-Way ECM Power Connector**

### **33.3.7 Check ECM Connectors**

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connector (both the ECM and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If terminals and connectors are damaged, repair both. Refer to section 33.3.8.
  - [b] If terminals and connectors are not damaged, reprogram the ECM. Refer to section 33.3.8.

### **33.3.8 Verify Repairs**

Perform the following steps to verify repairs.

1. Turn ignition switch OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 102/3 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 102/3 is logged, and other codes are logged, refer to section 33.3.1.




---

## 34 FLASH CODE 34 - TBS LOW

Section	Page
34.1 DESCRIPTION OF FLASH CODE 34 .....	34- 3
34.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 34 .....	34- 3
34.3 TROUBLESHOOTING FLASH CODE 34 .....	34- 4





31242

**Figure 34-1 Turbo Boost Sensor**

### 34.1 DESCRIPTION OF FLASH CODE 34

Flash Code 34 indicates that the engine Turbo Boost Sensor (TBS), see Figure 34-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor +5 volt supply circuit
- ☐ Sensor signal is shorted to sensor return circuit or to ground
- ☐ Sensor +5 volt supply is shorted to the sensor return circuit or ground

### 34.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 34

The SAE J1587 equivalent code for Flash Code 34 is p 102 4.

## 34.3 TROUBLESHOOTING FLASH CODE 34

The following procedure will troubleshoot Flash Code 34.

### 34.3.1 Multiple Code Check


Perform the following steps to check for multiple codes.

1. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL) connector.
2. Turn vehicle ignition switch ON.
3. Read active codes.
  - [a] If code 102/4 was logged and there are no other logged codes, refer to section 34.3.2.
  - [b] If code 102/4 and any of the following codes 72/3 or 4, 73/3 or 4, 94/3 or 4, 100/3 or 4, 101/3 or 4, 110/3 or 4, 174/3 or 4, 175/3 or 4, were logged, refer to section 90.1.
  - [c] If code 102/4 was logged and none of the following codes 72/3 or 4, 73/3 or 4, 94/3 or 4, 100/3 or 4, 101/3 or 4, 110/3 or 4, 174/3 or 4, 175/3 or 4, were logged, refer to section 34.3.2.

### 34.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn vehicle ignition OFF.
2. Disconnect TBS connector.
3. Install a jumper wire between sockets B and C of the TBS harness connector.  
See Figure 34-2.
4. Turn ignition ON.
5. Start engine and run until either the Check Engine Light is on, or until the engine has been running at least one minute at greater than 1000 r/min.
6. Read logged codes.
  - [a] If active code 102/4 and any other codes are logged, refer to section 34.3.4.
  - [b] If active code 102/3 and any other codes except 102/4 are logged, refer to section 34.3.3.



**Figure 34-2 Turbo Boost Sensor Schematic**

### 34.3.3 Check Turbo Boost Sensor Connectors

Perform the following steps to check the TBS connector.

1. Check terminals at the TBS connectors (both the TBS and harness side) for damage: bent, corroded and unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them. Refer to section 34.3.11.
  - [b] If the terminals and connectors are not damaged, replace the TBS. Refer to section 34.3.11.

### 34.3.4 Check for +5 Volt


Perform the following steps to check for +5 volt.

1. Remove jumper.
2. Turn ignition ON.
3. Measure voltage on TBS harness connector, pin C (red lead) to pin A (black lead).
  - [a] If the voltage measurement is greater than 6 volts, refer to section 34.3.10.
  - [b] If the voltage measurement is between 4 and 6 volts, refer to section 34.3.5.
  - [c] If the voltage measurement is less than 4 volts, refer to section 34.3.8.

### 34.3.5 Check for Signal Open

Perform the following steps to check for signal open.

1. Turn vehicle ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Install a jumper wire between pins A and B of the TBS harness connector. See Figure 34-3.
4. Measure resistance between sockets P1 and Y2 on the engine harness connector.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 34.3.6.
  - [b] If the resistance measurement is greater than  $5\ \Omega$ , or open, and the signal line (#432) is open, repair the open. Refer to section 34.3.11.



**Figure 34-3 Turbo Boost Sensor Schematic**

### 34.3.6 Check for Short

Perform the following steps to check for short.

1. Remove jumper.
2. Measure resistance between pins A and B on the TBS harness connector.
  - [a] If measured resistance between pins A and B is greater than 100  $\Omega$ , or open, go to step 3
  - [b] If measured resistance between pins A and B is less than 100  $\Omega$ , the signal line (#432) is shorted to the return line (#452). Repair the short. Refer to section 34.3.11.
3. Also measure resistance between socket B and a good ground.
  - [a] If measured resistance between socket B and a good ground is greater than 100  $\Omega$ , or open, refer to section 34.3.7.
  - [b] If measured resistance between socket B and a good ground is less than 100  $\Omega$ , the signal line (#432) is shorted to the battery ground. Repair the short and refer to section 34.3.11.

### 34.3.7 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM harness connector (both ECM and harness side) for damage: bent, corroded, and unseated pins or sockets. See Figure 34-4.
  - [a] If terminals and connectors are damaged, repair them and refer to section 34.3.11.
  - [b] If terminals and connectors are not damaged, install a test ECM.  
Refer to section 34.3.11.





Figure 34-4 Engine Harness Connector to Turbo Boost Sensor



### 34.3.8 Check for Open +5 Volt Line

Perform the following steps to check for open +5 volt line.

1. Turn vehicle ignition OFF.
2. Disconnect the engine harness connectors at the ECM.
3. Install a jumper wire between pins A and C of the TBS harness connector. See Figure 34-5.
4. Read resistance between sockets W1 and Y2 on the engine harness connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 34.3.9.
  - [b] If the resistance measurement is greater than 5  $\Omega$ , or open, the vehicle +5 volt line (#416) is open. Repair open. Refer to section 34.3.11.



**Figure 34-5 5-Way ECM Power Connector**

### 34.3.9 Check for Short

Perform the following steps to check for short.

1. Remove jumper.
2. Measure resistance between pins A and C on the TBS harness connector. See Figure 34-6.
  - [a] If measured resistance between pins A and C is greater than 100  $\Omega$ , or open, go to step 3
  - [b] If measured resistance between pins A and C is less than 100  $\Omega$ , the 5 volt supply (#416) is shorted to the return line (#452). Repair the short. Refer to section 34.3.11.
3. Also measure resistance between socket C and a good ground.
  - [a] If measured resistance between socket C and a good ground is greater than 100  $\Omega$ , or open, refer to section 34.3.7.
  - [b] If measured resistance between socket C and a good ground is less than 100  $\Omega$ , the 5 volt supply (#416) is shorted to the battery ground. Repair the short and refer to section 34.3.11.





Figure 34-6 Turbo Boost Sensor Schematic

### 34.3.10 Check for Short to Battery +

Perform the following steps to check for short to battery +.

1. Turn vehicle ignition OFF.
2. Remove both fuses to the ECM.
3. Disconnect the engine harness, vehicle harness, and 5-way power connectors at the ECM.
4. Measure resistance between socket W1 on the engine harness connector and socket B3 of the vehicle harness connector, and between W1 and the 5-way power harness sockets A and C. See Figure 34-7.
  - [a] If measured resistance is less than or equal to 100  $\Omega$ , a short exists between sockets where less than 100  $\Omega$  was measured. Repair short and reinsert fuses. Refer to section 34.3.11.
  - [b] If the resistance measurement is greater than 100  $\Omega$ , or open, refer to section 34.3.7.



**Figure 34-7 ECM Vehicle Harness Connector**

### **34.3.11 Verify Repairs**

Perform the following steps to verify repairs.

1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, no further troubleshooting is required.
  - [b] If code 102/4 and any other codes are logged, all system diagnostics are complete.  
Please review this section from the first step to find the error. Refer to section 34.3.1.
  - [c] If code 102/4 is not logged and any other codes are logged, refer to section 9.1.




---

## 35 FLASH CODE 35 - OPS HIGH

Section	Page
35.1 DESCRIPTION OF FLASH CODE 35 .....	35- 3
35.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 35 .....	35- 3
35.3 TROUBLESHOOTING FLASH CODE 35 .....	35- 4

---



31244

**Figure 35-1      Oil Pressure Sensor**

### 35.1 DESCRIPTION OF FLASH CODE 35

Flash Code 35 indicates that the engine Oil Pressure Sensor (OPS), see Figure 35-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor return circuit
- ☐ Sensor signal circuit is shorted to the sensor +5 volt supply
- ☐ Failed/damaged sensor

### 35.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 35

The SAE J1587 equivalent code for Flash Code 35 is p 100 3, oil pressure circuit high.

**NOTE:**

Code 35 is logged if oil pressure is high, engine is warm, and engine is at idle.



## 35.3 TROUBLESHOOTING FLASH CODE 35

The following procedure will troubleshoot Flash Code 35.

### 35.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL).
3. Read active codes.
  - [a] If code 100/3 and no other codes were logged, refer to section 35.3.2.
  - [b] If code 100/3 and any of the following codes were logged: 73/3 or 4, 94/3 or 4, 100/4, 101/3 or 4, 102/3 or 4, 110/3 or 4, 174/3 or 4, 175/3 or 4, refer to section 90.1.

### 35.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn ignition switch OFF.
2. Disconnect OPS connector.
3. Turn ignition ON.
4. Start and run the engine.
5. Select engine temperature (COOLANT TEMP or OIL TEMP) on the DDR.
6. Warm up engine until engine temperature reading is greater than 60°C (140°F).
7. After warm-up, let engine run at idle.
8. Read active codes.
  - [a] If active code 100/3 and any other codes were logged, refer to section 35.3.5.
  - [b] If code 100/4 and any other codes except 100/3 were logged, refer to section 35.3.3.

### 35.3.3 Return Circuit Check

Perform the following steps to check the return circuit.

1. Turn vehicle ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Install a jumper wire between pin A and pin B of the OPS harness connector. See Figure 35-2.
4. Measure resistance between sockets P2 and Y2 on the engine harness connector.
  - [a] If resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 35.3.4.
  - [b] If resistance measurement is greater than  $5\ \Omega$ , the return line (#452) is open. Repair the open and refer to section 35.3.8.




Figure 35-2 Engine Harness Connector to Oil Pressure Sensor

### 35.3.4 Check Oil Pressure Sensor Connectors


Perform the following steps to check the OPS connectors.

1. Check terminals at the OPS connectors (both the sensor and harness side) for damage: bent, corroded and unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them and refer to section 35.3.8.
  - [b] If the terminals and connectors are not damaged, replace the OPS.  
Refer to section 35.3.8.

### 35.3.5 Check for Signal Short to 5 Volt

Perform the following steps to check for signal open.

1. Turn vehicle ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Measure resistance between sockets P2 and W1 on the engine harness connector.  
See Figure 35-3.
  - [a] If the resistance measurement is less than or equal to  $100\ \Omega$ , the signal line (#530) is shorted to the engine +5 volt line (#416). Repair the short and refer to section 35.3.8.
  - [b] If the resistance measurement is greater than  $100\ \Omega$ , or open, refer to section 35.3.6.




**Figure 35-3 ECM Engine Harness Connector**

### 35.3.6 Check for Short to Battery (+)

Perform the following steps to check for a short to battery (+).

1. Remove both fuses to the ECM.
2. Disconnect the vehicle harness and 5-way power connectors at the ECM. See Figure 35-4.
3. Measure resistance between socket P2 on the engine harness connector and socket B3 of the vehicle harness connector, and between P2 and the 5-way power harness sockets A and C.
  - [a] If resistance measurement is greater than 100  $\Omega$ , or open, refer to section 35.3.7.
  - [b] If resistance measurement is less than or equal to 100  $\Omega$ , a short exists between sockets where less than 100  $\Omega$  resistance was read. Repair short and reinsert fuses. Refer to section 35.3.8.



**Figure 35-4 ECM Vehicle Harness Connector**

### 35.3.7 Check ECM Connector

Perform the following steps to check the ECM connector:

1. Inspect the terminals at the ECM connector (ECM and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If the terminals and connector are damaged, repair both and refer to section 35.3.8.
  - [b] If the terminals and connector are not damaged, refer to section 35.3.4.

### 35.3.8 Verify Repairs

Perform the following steps to verify repairs:


1. Turn ignition switch OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check codes with DDR.
  - [a] If no codes are logged, no further troubleshooting is required.
  - [b] If code 100/3 is not logged, but other codes are logged, refer to section 9.1.
  - [c] If code 100/3 is logged, all system diagnostics are complete. Contact Detroit Diesel Technical Service.

---

## 36 FLASH CODE 36 - OPS LOW

Section	Page
36.1 DESCRIPTION OF FLASH CODE 36 .....	36- 3
36.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 36 .....	36- 3
36.3 TROUBLESHOOTING FLASH CODE 36 .....	36- 4

---



**Figure 36-1      Oil Pressure Sensor**

### 36.1 DESCRIPTION OF FLASH CODE 36

Flash Code 36 indicates that the engine Oil Pressure Sensor (OPS), see Figure 36-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor +5 volt supply circuit
- ☐ Sensor signal is shorted to sensor return circuit or to ground
- ☐ Sensor +5 volt supply is shorted to the sensor return circuit

### 36.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 36

The SAE J1587 equivalent code for Flash Code 36 is p 100 4, oil pressure circuit low.



## 36.3 TROUBLESHOOTING FLASH CODE 36

The following procedure will troubleshoot Flash Code 36.

### 36.3.1 Multiple Code Check


Perform the following steps to check for multiple codes.

1. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL).
2. Turn vehicle ignition switch ON.
3. Read active codes.
  - [a] If code 100/4 and no other codes were logged, refer to section 36.3.2.
  - [b] If code 100/4 was logged and none of the following codes were logged: 110/3 or 4, 174/3 or 4, 175/3 or 4, 101/3 or 4, 102/3 or 4, 73/3 or 4, 94/3 or 4, 100/3, refer to section 36.3.2.
  - [c] If code 100/4 and any of the following codes were logged: 110/3 or 4, 174/3 or 4, 175/3 or 4, 101/3 or 4, 102/3 or 4, 73/3 or 4, 94/3 or 4, 100/3, refer to section 90.1.

### 36.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn ignition switch OFF.
2. Disconnect OPS connector and install a jumper wire between sockets B and C of the OPS harness connector. See Figure 36-2.
3. Turn ignition ON.
4. Read active codes.
5. If active codes 100/3 or 4 were logged, proceed with the following:
  - [a] If active code 100/4 and any other codes were logged, refer to section 36.3.4.
  - [b] If code 100/3 and any other codes except 100/4 were logged, refer to section 36.3.3.
6. If active codes 100/3 or 4 were not logged, warm up engine until either codes are logged or the engine temperature (COOLANT TEMP or OIL TEMP or DDR) has been greater than 60°C (140°F) for one minute.
  - [a] If active code 100/4 and any other codes were logged, refer to section 36.3.4.
  - [b] If code 100/3 and any other codes except 100/4 were logged, refer to section 36.3.3.



**Figure 36-2 Engine Harness Connector to Oil Pressure Sensor**

### 36.3.3 Check Oil Pressure Sensor Connectors

Perform the following steps to check the OPS connectors.

1. Turn ignition OFF.
2. Check terminals at the OPS connectors (both the sensor and harness side) for damage: bent, corroded and unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them and refer to section 36.3.12.
  - [b] If the terminals and connectors are not damaged, replace the OPS.  
Refer to section 36.3.12.

### 36.3.4 Check for +5 Volts


Perform the following steps to check for +5 volts.

1. Turn vehicle ignition OFF.
2. Remove jumper wire.
3. Turn ignition ON.
4. Measure voltage on OPS harness connector, socket C (red lead) to socket A (black lead).
  - [a] If the voltage measurement is less than 4 volts, refer to section 36.3.8.
  - [b] If the voltage measurement is greater than 6 volts, refer to section 36.3.10.
  - [c] If the voltage measurement is between 4 and 6 volts, refer to section 36.3.5.

### 36.3.5 Check for Signal Open

Perform the following steps to check for signal open.

1. Turn the ignition OFF.
2. Disconnect the engine harness connector at the ECM. See Figure 36-3.
3. Install a jumper wire between sockets A and B of the OPS harness connector.
4. Measure resistance between sockets P2 and Y2 on the engine harness connectors.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 36.3.11.
  - [b] If the resistance measurement is greater than  $5\ \Omega$  or open, the signal line (#530) is open. Repair the open and refer to section 36.3.12.



**Figure 36-3 Engine Harness Connector to Oil Pressure Sensor**

### 36.3.6 Check for Short

Perform the following steps to check for a short.

1. Remove jumper wire.
2. Measure resistance between socket P2 and a good ground. Also measure resistance between P2 and Y2.
  - [a] If both resistance measurements are greater than 100  $\Omega$  or open, replace OPS. Refer to section 36.3.12.
  - [b] If either resistance measurement is less than 100  $\Omega$ , the signal line (#530) is shorted to the return line (#452) or battery ground. Repair short and refer to section 36.3.12.

### 36.3.7 Check ECM Connectors

Perform the following steps to check ECM connectors.

1. Check terminals at the ECM harness connector (both ECM and harness side) for damage: bent, corroded and unseated pins or sockets. Check W1, P2 and Y2 terminals and pins at ECM.
  - [a] If the terminals and connectors are damaged, repair them and refer to section 36.3.12.
  - [b] If the terminals and connectors are not damaged, reprogram the ECM. Refer to section 36.3.12.

### 36.3.8 Check for Open +5 Volt Line

Perform the following steps to check for open +5 volt line.

1. Turn ignition OFF.
2. Disconnect the engine harness connectors at the ECM.
3. Install a jumper wire between pins A and C of the OPS connector.
4. Measure resistance between sockets W1 and Y2 on the engine harness connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 36.3.9.
  - [b] If the resistance measurement is greater than 5  $\Omega$  or open, the engine +5 volt line (#416) is open. Repair the open and refer to section 36.3.12.

### 36.3.9 Check for Short

Perform the following steps to check for a short.

1. Remove jumper wire.
2. Measure resistance between sockets A and C on the OPS harness connector. Also measure resistance between socket C and a good ground.
  - [a] If either resistance measurement is less than or equal to 100  $\Omega$ , the engine +5 volt line (#416) is shorted to the return line (#452) or battery ground. Repair the short and refer to section 36.3.12.
  - [b] If the resistance measurement is greater than 100  $\Omega$  or open, replace OPS and refer to section 36.3.12.

### 36.3.10 Check for Short to Battery +

Perform the following steps to check for a short to battery.

1. Remove both fuses to the ECM.
2. Disconnect the vehicle harness and 5-way power connectors at the ECM. See Figure 36-4.
3. Measure resistance between socket W1 on the engine harness connector and socket B3 of the vehicle harness connector, and between W1 and the 5-way power harness sockets A and C.
  - [a] If resistance measurement is greater than 100  $\Omega$ , or open, replace OPS. Refer to section 36.3.12.
  - [b] If resistance measurement is less than or equal to 100  $\Omega$ , a short exists between sockets where less than 100  $\Omega$  resistance was read. Repair short and reinsert fuses. Refer to section 36.3.12.




Figure 36-4 ECM Vehicle Harness Connector

### 36.3.11 Check for Short to Ground

Perform the following steps to check for a short to ground.

1. Turn vehicle ignition OFF.
  2. Remove jumper wire.
  3. Measure resistance between sockets P2 and Y2 on the engine harness connector.  
See Figure 36-5.
- [a] If resistance measurement is greater than 100  $\Omega$ , or open, refer to section 36.3.6.
- [b] If resistance measurement is less than or equal to 100  $\Omega$ , the signal line (#530) and return line (#452) are shorted together. Repair the short. Refer to section 36.3.12.




Figure 36-5 Engine Harness Connector to Oil Pressure Sensor



### 36.3.12 Verify Repairs

Perform the following steps to verify repairs.


1. Turn ignition switch OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 100/4 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 100/4 is logged, and other codes are logged, all system diagnostics are complete. Please review this section from the first step to find the error. Refer to section 36.3.1.

---

## 37 FLASH CODE 37 - FPS HIGH

Section	Page
37.1 DESCRIPTION OF FLASH CODE 37 .....	37- 3
37.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 37 .....	37- 3
37.3 TROUBLESHOOTING FLASH CODE 37 .....	37- 4

---



**Figure 37-1      Fuel Pressure Sensor**

### 37.1 DESCRIPTION OF FLASH CODE 37

Flash Code 37 indicates that the engine Fuel Pressure Sensor (FPS), see Figure 37-1, input to the ECM has exceeded 95% (normally >4.75 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor return circuit
- ☐ Sensor signal circuit is shorted to the sensor +5 volt supply

**NOTE:**

Require fuel pressure >60 psi.

### 37.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 37

The SAE J1587 equivalent code for Flash Code 37 is p 094 3.

### 37.3 TROUBLESHOOTING FLASH CODE 37

The following procedure will troubleshoot Flash Code 37.

#### 37.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.


1. Turn ignition ON.
2. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL).
3. Read active codes.
  - [a] If active code 94/3 was logged, and no other codes were logged, refer to section 37.3.2.
  - [b] If active code 94/3 and any or all of the following codes were logged, 110/3 or 4, 174/3 or 4, 175/3 or 4, 101/3 or 4, 102/3 or 4, 100/3 or 4, 94/4, 73/3 or 4, refer to section 90.1.

#### 37.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn ignition switch OFF.
2. Disconnect FPS connector. See Figure 37-2.
3. Turn ignition ON.
4. Start and run engine.
5. Select Engine Temperature (COOLANT TEMP & OIL) on DDR.
6. Warm up engine until engine temperature reading is greater than 60°C (140°F).
7. Leave engine running at idle after warm-up. Run for five minutes.
8. Read active codes.
  - [a] If active code 94/3 and any other codes were logged, refer to section 37.3.5.

- [b] If active code 94/4 and any other codes except 94/3 were logged, refer to section 37.3.3.



**Figure 37-2 Engine Harness Connector to Fuel Pressure Sensor**

### 37.3.3 Return Circuit Check

Perform the following steps to check the return circuit.

1. Turn vehicle ignition OFF.
2. Disconnect the engine harness connector at the ECM.
3. Install a jumper wire between pins A and B of the FPS harness connector.
4. Measure resistance between sockets M1 and Y2 on the engine harness connectors.
  - [a] If resistance measurement is less than or equal to 5  $\Omega$ , refer to section 37.3.4.
  - [b] If resistance measurement is greater than 5  $\Omega$ , or open, the return line (#452) is open. Repair the open and refer to section 37.3.9.

### 37.3.4 Check Fuel Pressure Sensor Connectors

Perform the following steps to check the FPS connectors.

1. Inspect terminals at the FPS connectors (both the sensor and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them and refer to section 37.3.9.
  - [b] If the terminals and connectors are not damaged, replace the FPS and refer to section 37.3.9.

### 37.3.5 Check for Short


Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Disconnect the engine harness connectors at the ECM.
3. Measure resistance between sockets W1 and M1 on the engine harness connector.
  - [a] If the resistance measurement is greater than 100  $\Omega$  or open, refer to section 37.3.6.
  - [b] If the resistance measurement is less than or equal to 100  $\Omega$ , the signal line (#905) is shorted to the engine +5 volt line (#416). Repair the short and refer to section 37.3.9.

### 37.3.6 Check for Short to Battery +

Perform the following steps to check for a short to battery.

1. Remove both fuses to the ECM.
2. Disconnect the vehicle harness and 5-way power connectors at the ECM. See Figure 37-3.
3. Measure resistance between socket M1 on the engine harness connector and socket B3 of the vehicle harness connector, and between M1 and the 5-way power harness sockets A and C.
  - [a] If the resistance measurement is greater than 1,000  $\Omega$  or open, refer to section 37.3.8.
  - [b] If the resistance measurement is less than or equal to 1,000  $\Omega$ , a short exists between sockets where less than 1,000  $\Omega$  was measured. Repair short and reinsert fuses. Refer to section 37.3.9.



**Figure 37-3 ECM Vehicle Harness Connector**



### 37.3.7 Final Check

Perform the following steps to do a final check.

1. Reconnect all connectors.
2. Turn vehicle ignition ON.
3. Clear codes.
4. Start and run the engine for one minute.
5. Stop engine.
6. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If active code 94/3 is logged, reprogram the ECM. Refer to section 37.3.9.
  - [c] If any codes except code 94/3 are logged, refer to section 9.1.

### 37.3.8 Check ECM Connector

Perform the following steps to check the ECM connector.

1. Inspect terminals at the ECM connector (both the ECM and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 37.3.9.
  - [b] If terminals and connectors are not damaged, replace the FPS. Refer to section 37.3.7.

### 37.3.9 Verify Repairs

Perform the following steps to verify repairs.

1. Turn ignition switch OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, no further troubleshooting is required.
  - [b] If code 94/3 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 94/3 is logged, and other codes are logged, all system diagnostics are complete. Please review this section from the first step to find the error. Refer to section 37.3.1.




---

## **38 FLASH CODE 38 - FPS LOW**

<b>Section</b>	<b>Page</b>
38.1 DESCRIPTION OF FLASH CODE 38 .....	38- 3
38.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 38 .....	38- 3
38.3 TROUBLESHOOTING FLASH CODE 38 .....	38- 4

---



**Figure 38-1      Fuel Pressure Sensor**

### **38.1 DESCRIPTION OF FLASH CODE 38**

Flash Code 38 indicates that the engine Fuel Pressure Sensor (FPS), see Figure 38-1, input to the ECM has dropped below 5% (normally < 0.25 volts) of the sensor supply voltage.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Open sensor +5 volt supply circuit
- ☐ Sensor signal is shorted to sensor return circuit or to ground
- ☐ Sensor +5 volt supply is shorted to the sensor return circuit

### **38.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 38**

The SAE J1587 equivalent code for Flash Code 38 is p 094 4.

### 38.3 TROUBLESHOOTING FLASH CODE 38

The following procedure will troubleshoot Flash Code 38.

#### 38.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.


1. Turn vehicle ignition switch ON.
2. Plug the diagnostic data reader (DDR) into the diagnostic data link (DDL).
3. Read active codes.
  - [a] If active code 94/4 and no other codes were logged, refer to section 38.3.2.
  - [b] If active code 94/4 and any or all of the following codes were logged, 94/3, 100/3 or 4, 101/3 or 4, 110/3 or 4, 174/3 or 4, 175/3 or 4, refer to section 90.1.
  - [c] If active code 94/4 and codes other than the following codes were logged, 94/3, 100/3 or 4, 101/3 or 4, 110/3 or 4, 174/3 or 4, 175/3 or 4, refer to section 38.3.2.

#### 38.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn ignition switch OFF.
2. Disconnect FPS connector and install a jumper wire between sockets B and C of the FPS harness connector. See Figure 38-2.
3. Turn ignition ON.
4. Read logged codes.
5. If active codes 94/3 or 4 are not logged, start and run the engine until either these active codes *display or engine temperature (COOLANT TEMP & OIL on DDR) has been greater than 60°C (140°F) for more than one minute.*
  - [a] If active code 94/4 and any other codes are logged, refer to section 38.3.4.

- [b] If active code 94/3 and any other codes except code 94/4 are logged, check to ensure ECM and FPS connectors are wired properly. Refer to section 38.3.3.



**Figure 38-2 Engine Harness Connector to Fuel Pressure Sensor**

### 38.3.3 Check Fuel Pressure Sensor Connectors

Perform the following steps to check the FPS connectors.


1. Inspect terminals at the FPS connectors (both the sensor and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them and refer to section 38.3.12.
  - [b] If the terminals and connectors are not damaged, replace the FPS and refer to section 38.3.12.



### 38.3.4 Check for +5 Volts

Perform the following steps to check for +5 volts.

1. Turn vehicle ignition OFF.
2. Remove jumper wire.
3. Turn ignition ON.
4. Measure voltage on FPS harness connector, socket C to socket A. See Figure 38-3.
  - [a] If the voltage measurement is greater than 6 volts, refer to section 38.3.9.
  - [b] If the voltage measurement is less than 4 volts, refer to section 38.3.7.
  - [c] If the voltage measurement is between 4 and 6 volts, refer to section 38.3.5.



**Figure 38-3 Engine Harness Connector to Fuel Pressure Sensor**

### 38.3.5 Check for Signal Open

Perform the following steps to check for signal open.

1. Turn vehicle ignition OFF.
2. Disconnect engine harness connector at the ECM.
3. Install a jumper wire between pins A and B of the FPS harness connector.
4. Measure resistance between sockets M1 and Y2 on the engine harness connector.
  - [a] If resistance measurement is less than or equal to 5  $\Omega$  refer to section 38.3.10.
  - [b] If the resistance measurement is greater than 5  $\Omega$  or open, the signal line (#905) or return line (#452) is open. Repair the open and refer to section 38.3.12.

### 38.3.6 Check ECM Connectors


Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM harness connector (both ECM and harness side) for damage: bent, corroded, and unseated pins or sockets. Check W1, M1 and Y2 terminals at ECM.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 38.3.12.
  - [b] If terminals and connectors are not damaged, install a test ECM. Refer to section 38.3.12.

### 38.3.7 Check for Open +5 Volt Line

Perform the following steps to check for open +5 volt line.

1. Turn vehicle ignition OFF.
2. Disconnect the engine harness connectors at the ECM.
3. Install a jumper wire between sockets A and C of the FPS harness connector.  
See Figure 38-4.
4. Measure resistance between sockets W1 and Y2 on the engine harness connector.
  - [a] If resistance measurement is less than or equal to  $5\ \Omega$  refer to section 38.3.8.
  - [b] If the resistance measurement is greater than  $5\ \Omega$  or open, the engine +5 volt line (#416) is open. Repair the open and refer to section 38.3.12.



**Figure 38-4 Engine Harness Connector to Fuel Pressure Sensor**

### 38.3.8 Check for Short


Perform the following steps to check for a short.

1. Remove jumper wire.
2. Measure resistance between sockets A and C of the FPS harness connector.
  - [a] If the resistance measurement is greater than  $100\ \Omega$  or open, refer to section 38.3.11.
  - [b] If the resistance measurement is less than or equal to  $100\ \Omega$ , the return line (#452) is shorted to the engine +5 volt line (#416). Repair the short and refer to section 38.3.12.

### 38.3.9 Check for Short to Battery +

Perform the following steps to check for a short to battery.

1. Remove both fuses to the ECM.
2. Disconnect the vehicle harness and 5-way power connectors at the ECM. See Figure 38-5.
3. Measure resistance between socket W1 on the engine harness connector and socket B3 of the vehicle harness connector, and between W1 and the 5-way power harness sockets A and C.
  - [a] If the resistance measurement is greater than 1,000  $\Omega$  or open, refer to section 38.3.11.
  - [b] If the resistance measurement is less than or equal to 1,000  $\Omega$ , a short exists between sockets where less than 1,000  $\Omega$  was measured. Repair short and reinsert fuses. Refer to section 38.3.12.



**Figure 38-5 ECM Vehicle Harness Connector**

### 38.3.10 Check for Short to Ground

Perform the following steps to check for a short to ground.

1. Turn ignition switch OFF.
2. Remove jumper wires.
3. Measure resistance between sockets M1 and Y2 on the engine harness connector. Also measure resistance between socket M1 and a good ground.
  - [a] If both resistance measurements are greater than 100  $\Omega$  or open, refer to section 38.3.11.
  - [b] If either resistance measurement is less than or equal to 100  $\Omega$ , the signal line (#905) and return line (#452) are shorted together, or the signal line (#905) is shorted to battery ground. Repair the short. Refer to section 38.3.12.

### 38.3.11 Replace Fuel Pressure Sensor

Perform the following steps to replace the FPS.

1. Turn ignition switch OFF.
2. Replace FPS.
3. Reconnect all connectors.
4. Turn ignition ON.
5. Clear codes.
6. Start and run the engine for one minute.
  - [a] If check engine light comes on, refer to section 38.3.6.
  - [b] If check engine light does not come on, refer to section 38.3.12.

### 38.3.12 Verify Repairs

Perform the following steps to verify repairs.

1. Turn ignition switch OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 94/4 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 94/4 is logged, and other codes are logged, all system diagnostics are complete. Please review this section from the first step to find the error. Refer to section 38.3.1.



**39 FLASH CODE 39**

<b>Section</b>	<b>Page</b>
39.1 DESCRIPTION OF FLASH CODE 39 .....	39- 3





### 39.1 DESCRIPTION OF FLASH CODE 39

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

# 40 FLASH CODE 40

Section	Page
40.1 DESCRIPTION OF FLASH CODE 40 .....	40- 3



## **40.1 DESCRIPTION OF FLASH CODE 40**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.




---

## 41 FLASH CODE 41 - TOO MANY SRS

Section	Page
41.1 DESCRIPTION OF FLASH CODE 41 .....	41- 3
41.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 41 .....	41- 3
41.3 TROUBLESHOOTING FLASH CODE 41 .....	41- 4

---





**Figure 41-1 Synchronous Reference Sensor and Timing Reference Sensor**

## **41.1 DESCRIPTION OF FLASH CODE 41**

Flash Code 41 indicates that the ECM has detected extra Synchronous Reference Sensor pulses, or the ECM has detected missing Timing Reference Sensor pulses, see Figure 41-1.

## **41.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 41**

The SAE J1587 equivalent code for Flash Code 41 is s 021 0.


## 41.3 TROUBLESHOOTING FLASH CODE 41

The following procedure will troubleshoot Flash Code 41.

### 41.3.1 Check for Signal Open

Perform the following steps to check for signal open.

1. Turn ignition OFF.
2. Disconnect engine harness connector at the ECM. See Figure 41-2.
3. Read resistance between sockets T1 and T2 on the engine harness connector.
  - [a] If the resistance reading is less than or equal to  $200\ \Omega$ , refer to section 41.3.2.
  - [b] If the resistance reading is greater than  $200\ \Omega$  or open, refer to section 41.3.3.



**Figure 41-2 Engine Harness Connector**

### 41.3.2 Check for Short

Perform the following steps to check for a short.

1. Disconnect the TRS connector.
2. Measure resistance between sockets T1 and T2 on the engine harness connector.  
See Figure 41-3.
3. Measure resistance between socket T1 and ground, and between socket T2 and ground.
  - [a] If the resistance measurement is greater than 10,000  $\Omega$  or open, refer to section 41.3.4.
  - [b] If the resistance measurement is less than or equal to 10,000  $\Omega$ , a short exists between #110 and #109 or where less than 10,000  $\Omega$  resistance was read. Repair the short.  
Refer to section 41.3.15.




Figure 41-3 Engine Harness Connector to Timing Reference Sensor

### 41.3.3 Open Timing Reference Sensor Line Check


Perform the following steps to check the open TRS line.

1. Disconnect the TRS connector.
2. Install a jumper wire between sockets A and B of the TRS harness connector.
3. Measure resistance between sockets T1 and T2 on the engine harness connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 41.3.4.
  - [b] If the resistance measurement is greater than 5  $\Omega$ , or open, the signal line #110 or return line #109 is open. Repair the open. Refer to section 41.3.15.

### 41.3.4 Check Timing Reference Sensor Resistance

Perform the following steps to check TRS resistance.

1. Measure resistance of TRS across sensor connector pins A and B. See Figure 41-4.
  - [a] If the resistance measurement is greater than 200  $\Omega$ , refer to section 41.3.12.
  - [b] If the resistance measurement is less than 100  $\Omega$ , refer to section 41.3.12.
  - [c] If the resistance measurement is between 100 and 200  $\Omega$ , refer to section 41.3.5.



**Figure 41-4 Engine Harness Connector to Timing Reference Sensor**

### **41.3.5 Check Timing Reference Sensor / Synchronous Reference Sensor Gap**

Perform the following steps to check the TRS/SRS gap.

1. Bar the engine until the TRS is over a TRS tooth of the pulse wheel.
2. Check the gap between TRS and the tooth of the pulse wheel (0.020 to 0.040 in.). A depth micrometer can be used.
  - [a] If the gap setting is correct, refer to section 41.3.6.
  - [b] If the gap setting is not correct, adjust the TRS/SRS until the gap setting is correct. If the problem returns, the pulse wheel may be loose or bad or damaged. Refer to section 41.3.15.

### **41.3.6 Synchronous Reference Sensor Code Check**

Perform the following steps to check for SRS code.

1. Check for SRS code.
  - [a] If code 21/1 is not logged, refer to section 41.3.7.
  - [b] If code 21/1 is logged, refer to section 41.3.8.

### **41.3.7 Check ECM Connectors**


Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connectors (both the ECM and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 41.3.15.
  - [b] If terminals and connectors are not damaged, install a test ECM. Refer to section 41.3.15.

### 41.3.8 Synchronous Reference Sensor Resistance Check

Perform the following steps to check SRS resistance.

1. Measure resistance between sockets S1 and S2 on the engine harness connector.  
See Figure 41-5.
  - [a] If measured resistance is greater than  $200\ \Omega$  , or open, refer to section 41.3.10.
  - [b] If measured resistance is less than  $200\ \Omega$  , or open, refer to section 41.3.9.



**Figure 41-5 Engine Harness Connector to Synchronous Reference Sensor**

### 41.3.9 Check for Short

Perform the following steps to check for a short.

1. Disconnect the SRS connector.
2. Measure resistance between sockets S1 and S2 on the engine harness connector.
  - [a] If measured resistance is greater than 10,000  $\Omega$ , or open, refer to section 41.3.11.
  - [b] If measured resistance is less than or equal to 10,000  $\Omega$ , the signal line #111 is shorted to the return line #112. Repair the short. Refer to section 41.3.15.

### 41.3.10 Open Synchronous Reference Sensor Line Check

Perform the following steps to check for an open SRS line.

1. Disconnect the SRS connector.
2. Install a jumper wire between sockets A and B of the SRS harness connectors.
3. Measure resistance between sockets S1 and S2 on the engine harness connector.
  - [a] If measured resistance is less than or equal to 5  $\Omega$ , refer to section 41.3.11.
  - [b] If measured resistance is greater than 5  $\Omega$ , or open, the signal line #111 or return line #112 is open. Repair the open and refer to section 41.3.15.

### 41.3.11 Synchronous Reference Sensor Test

Perform the following steps to test the SRS.


1. Measure resistance of SRS across the sensor connector pins A and B.
  - [a] If measured resistance is less than or equal to 100  $\Omega$ , refer to section 41.3.13.
  - [b] If measured resistance is greater than 200  $\Omega$ , refer to section 41.3.13.
  - [c] If measured resistance is between 100 and 200  $\Omega$ , refer to section 41.3.7.



### 41.3.12 Check Timing Reference Sensor Connectors

Perform the following steps to check TRS connectors.

1. Check terminals at the TRS (both the TRS and harness side) for damage: bent, corroded, and unseated pins or sockets. See Figure 41-6.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 41.3.15.
  - [b] If terminals and connectors are not damaged, replace the TRS. Refer to section 41.3.14.



**Figure 41-6 Engine Harness Connector to Synchronous Reference Sensor**

### 41.3.13 Check Synchronous Reference Sensor Connectors

Perform the following steps to check the SRS connectors.

1. Check terminals at the SRS (both the SRS and harness side) for damage: bent, corroded, and unseated pins or sockets, or bad contacts.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 41.3.15.
  - [b] If terminals and connectors are not damaged, replace the SRS. Refer to section 41.3.14.

### **41.3.14 Verify Synchronous Reference Sensor / Timing Reference Sensor**

Perform the following steps to verify operation of the SRS/TRS.

1. Reconnect all connectors.
2. Turn vehicle ignition ON.
3. Clear codes.
4. Start and run the engine for one minute.
5. Stop engine.
6. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 21/0 and any other codes are logged, and the SRS was not replaced, refer to section 41.3.6.
  - [c] If any codes except code 21/0 are logged, refer to section 9.1.

### **41.3.15 Verify Repairs**

Perform the following steps to verify repairs.


1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn vehicle ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 21/0 and any other codes are logged, all system diagnostics are complete. Review this section to find the error. Refer to section 41.3.1 or contact Detroit Diesel Technical Service.
  - [c] If any codes except code 21/0 are logged, refer to section 9.1.



---

# 42 FLASH CODE 42 - TOO FEW SRS

Section	Page
42.1 DESCRIPTION OF FLASH CODE 42 .....	42- 3
42.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 42 .....	42- 3
42.3 TROUBLESHOOTING FLASH CODE 42 .....	42- 4



**Figure 42-1      Synchronous Reference Sensor and Timing Reference Sensor**

## **42.1 DESCRIPTION OF FLASH CODE 42**

Flash Code 42 indicates that the ECM has detected missing Synchronous Reference Sensor (SRS) pulses, or the ECM has detected extra Timing Reference Sensor (TRS) pulses, see Figure 42-1.

## **42.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 42**

The SAE J1587 equivalent code for Flash Code 42 is s 021 1.

## 42.3 TROUBLESHOOTING FLASH CODE 42

The following procedure will troubleshoot Flash Code 42.

### 42.3.1 Resistance Check

Perform the following steps to check resistance.

1. Turn vehicle ignition OFF.
  2. Disconnect engine harness connector at ECM.
  3. Measure resistance between sockets S1 and S2 on the engine harness connector.  
See Figure 42-2.
- [a] If the resistance measurement is less than or equal to  $200\ \Omega$ , refer to section 42.3.2.
- [b] If the resistance measurement is greater than  $200\ \Omega$  or open, refer to section 42.3.3.




Figure 42-2 ECM Engine Harness Connector

### 42.3.2 Check for Short

Perform the following steps to check for a short.

1. Disconnect the SRS Connector.
2. Measure resistance between sockets S1 and S2 on the engine harness connector.  
See Figure 42-3.
3. Measure resistance between socket S1 and ground, and between socket S2 and ground.
  - [a] If the resistance measurement is less than or equal to 10,000  $\Omega$ , a short exists. Repair the short. Refer to section 42.3.16.
  - [b] If the resistance measurement is greater than 10,000  $\Omega$ , or open, refer to section 42.3.4.





Figure 42-3 Engine Harness Connector to Synchronous Reference Sensor



### 42.3.3 Open Synchronous Reference Sensor Line Check

Perform the following steps to check for an open SRS line.

1. Disconnect the SRS connector.
2. Install a jumper wire between sockets A and B of the SRS harness connector.  
See Figure 42-4.
3. Measure resistance between sockets S1 and S2 on the engine harness connector.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 42.3.4.
  - [b] If the resistance measurement is greater than  $5\ \Omega$  or open, the signal line (#111) or return line (#112) is open. Repair the open. Refer to section 42.3.16.



**Figure 42-4** Engine Harness Connector to Synchronous Sensor

### **42.3.4 Synchronous Reference Sensor Test**

Perform the following steps to test the SRS.

1. Measure resistance of SRS across the sensor connector pins A and B.
  - [a] If the resistance measurement is less than or equal to 100  $\Omega$ , refer to section 42.3.12.
  - [b] If the resistance measurement is greater than 200  $\Omega$ , refer to section 42.3.12.
  - [c] If the resistance measurement is between 100 and 200  $\Omega$ , refer to section 42.3.5.

### **42.3.5 Check Synchronous Reference Sensor Gap**

Perform the following steps to check the SRS gap.

1. Bar engine until SRS is over the SRS pin.
2. Check the gap between SRS and the pin.
  - [a] If the gap setting is correct (0.020 - 0.040 in.), refer to section 42.3.6. A depth micrometer can be used.
  - [b] If the gap setting is not correct, adjust the SRS until the gap setting is correct. If the problem returns, the pulse wheel may be loose or bad. Refer to section 42.3.16.

### **42.3.6 Check for Timing Reference Sensor Code**


Perform the following steps to check for TRS code.

1. Check for TRS code.
  - [a] If code 21/0 is not logged, refer to section 42.3.7.
  - [b] If code 21/0 is logged, refer to section 42.3.8.

### 42.3.7 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connectors (both the ECM and harness side) for damage: bent, corroded, and unseated pins or sockets. See Figure 42-5.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 42.3.16.
  - [b] If terminals and connectors are not damaged, refer to section 42.3.15.




**Figure 42-5 Engine Harness Connector to Synchronous Sensor**

### 42.3.8 Timing Reference Sensor Resistance Check

Perform the following steps to check TRS resistance.

1. Remove the engine harness connector.
2. Measure resistance between sockets T1 and T2 on the engine harness connector.  
See Figure 42-6.
  - [a] If the resistance measurement is greater than 200  $\Omega$ , refer to section 42.3.10.
  - [b] If the resistance measurement is less than or equal to 200  $\Omega$ , refer to section 42.3.9.



**Figure 42-6 Engine Harness Connector to Timing Reference Sensor**

### 42.3.9 Check for Short


Perform the following steps to check for a short.

1. Disconnect the TRS connector.
2. Measure resistance between sockets T1 and T2 on the engine harness connector.
  - [a] If measured resistance is greater than 10,000  $\Omega$ , or open, refer to section 42.3.11.
  - [b] If measured resistance is less than or equal to 10,000  $\Omega$ , the signal line (#110) is shorted to the return line (#109). Repair the short. Refer to section 42.3.16.

### 42.3.10 Open Timing Reference Sensor Line Check

Perform the following steps to check for an open TRS line.

1. Disconnect the TRS connector.
2. Install a jumper wire between sockets A and B of the TRS harness connector.  
See Figure 42-7.
3. Measure resistance between sockets T1 and T2 on the engine harness connector.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 42.3.11.
  - [b] If the resistance measurement is greater than  $5\ \Omega$ , or open, the signal line (#110) or return line (#109) is open. Repair the open. Refer to section 42.3.16.



**Figure 42-7** Engine Harness Connector to Timing Reference Sensor

### 42.3.11 Timing Reference Sensor Test


Perform the following steps to test the TRS.

1. Measure resistance of TRS across the sensor connector pins A and B.
  - [a] If the resistance measurement is greater than 200  $\Omega$ , refer to section 42.3.13.
  - [b] If the resistance measurement is less than 100  $\Omega$ , refer to section 42.3.13.
  - [c] If the resistance measurement is between 100 and 200  $\Omega$ , refer to section 42.3.7.

### 42.3.12 Check Synchronous Reference Sensor Connectors

Perform the following steps to check the SRS connectors.

1. Check terminals at the SRS (both the SRS and harness side) for damage: bent, corroded, and unseated pins or sockets, or a bad contact. See Figure 42-8.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 42.3.16.
  - [b] If terminals and connectors are not damaged, replace the SRS. Refer to section 42.3.14.




**Figure 42-8 Engine Harness Connector to Synchronous Reference Sensor**

### 42.3.13 Check Timing Reference Sensor Connectors

Perform the following steps to check the TRS connectors.

1. Check terminals at the TRS (both the TRS and harness end) for damage: bent, corroded, and unseated pins or sockets or bad contacts. See Figure 42-9.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 42.3.16.
  - [b] If terminals and connectors are not damaged, replace the TRS. Refer to section 42.3.14.



**Figure 42-9** Engine Harness Connector to Timing Reference Sensor

### 42.3.14 Verify Synchronous Reference Sensor / Timing Reference Sensor

Perform the following steps to verify operation of the SRS/TRS.


1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Clear codes.
4. Start and run the engine for one minute.
5. Stop engine.
6. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If any codes except code 21/1 are logged, refer to section 9.1.
  - [c] If code 21/1 and any other codes are logged, and the TRS was not replaced, refer to section 42.3.6.
  - [d] If code 21/1 and any other codes are logged, and the TRS was replaced, refer to section 42.3.15.



### 42.3.15 Verify Cranking Voltage

Perform the following steps to verify cranking voltage.

1. Turn vehicle ignition OFF.
  2. Connect all connectors.
  3. Connect 12 volt from a fully charged battery to the 5-pin power connector.  
See Figure 42-10.
  4. Connect to ECM.
  5. Start engine.
- [a] If engine starts, check the battery. If a voltage equalizer is installed, check the operation of the equalizer. If the equalizer is not working, refer to section 42.3.16.
- [b] If the engine does not start, replace the ECM. Refer to section 42.3.16.



**Figure 42-10 5-Way ECM Engine Power Connector**

### 42.3.16 Verify Repairs

Perform the following steps to verify repairs.


1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn vehicle ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 21/1 and any other codes are logged, all system diagnostics are complete. Review this section to find the error. Refer to section 42.3.1.
  - [c] If any codes except code 21/1 are logged, refer to section 9.1.



---

# 43 FLASH CODE 43 - COOLANT LEVEL LOW

Section	Page
43.1 DESCRIPTION OF FLASH CODE 43 .....	43- 3
43.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 43 .....	43- 3
43.3 TROUBLESHOOTING FLASH CODE 43 .....	43- 4



**Figure 43-1      Coolant Level Sensor**

### **43.1 DESCRIPTION OF FLASH CODE 43**

Flash Code 43 indicates that the ECM has detected that the engine coolant level has dropped below the recommended safe operating range, see Figure 43-1.

There is a significant difference between the coolant level sensors used in Detroit Diesel Electronic Controls (DDEC) II and DDEC III applications.

- ☐ Externally, the sensors physically look the same.
- ☐ The sensor used for the DDEC II system has a black colored connector.
- ☐ The sensor used for the DDEC III system has an off-white colored connector.

A coolant level module must be used with all coolant level sensors for DDEC II applications. All DDEC III applications, except Volvo, do not require a coolant level module.

### **43.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 43**

The SAE J1587 equivalent code for Flash Code 43 is p 111 1.

## **43.3 TROUBLESHOOTING FLASH CODE 43**

The following procedure will troubleshoot Flash Code 43.

### **43.3.1 Coolant Level Low**

Perform the following steps to diagnose the coolant level low.

1. Turn ignition ON; plug in DDR.
2. Read active codes.
  - [a] If code 111-1 is logged, there is an indication of a low coolant level condition. Add coolant to ensure coolant level probe is immersed in coolant.
  - [b] If code 111-1 remains active, refer to section 43.3.2.

### **43.3.2 Replace Coolant Level Sensor**

Using the sensor tester may be of assistance. Use Tool J 37164.

#### **NOTE:**

When replacing the coolant level sensor, the CLS could be an OEM supplied part.

1. Turn ignition OFF; replace CLS.
2. Turn ignition ON.
3. Read active codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If codes are logged, refer to section 43.3.3.

### **43.3.3 Clean and Check Alternator Grounds**

Perform the following steps to check the alternator ground.

1. If the grounds are clean and good, troubleshooting is complete.
2. If the grounds are damaged, repair the ground circuit and verify repairs.  
Refer to section 43.3.4.

### **43.3.4 Verify Repairs**

Perform the following steps to verify repairs

1. Turn ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear DDR codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 111/1, and any other codes are logged, refer to section 43.3.1, and repeat the procedure, or contact Detroit Diesel Technical Service.
  - [c] If any code other than 111/1 is logged, refer to section 9.1.






---

## 44 FLASH CODE 44 - TEMP HIGH

Section	Page
44.1 DESCRIPTION OF FLASH CODE 44 .....	44- 3
44.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 44 .....	44- 3
44.3 TROUBLESHOOTING FLASH CODE 44 .....	44- 4



**Figure 44-1      Coolant Temperature Sensor (Oil Temperature Sensor similar)**

## **44.1 DESCRIPTION OF FLASH CODE 44**

Flash Code 44 indicates that the ECM has detected that the engine coolant temperature has exceeded the recommended safe operating range. See Figure 44-1, for the sensor.

It also indicates that the ECM has detected that the engine oil temperature has exceeded the recommended safe operating range. This normally occurs due to a mechanical fault.

## **44.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 44**

The SAE J1587 equivalent code for Flash Code 44 is p 110 0, coolant temperature high.

The SAE J1587 equivalent code for Flash Code 44 is p 175 0, oil temperature high.

## 44.3 TROUBLESHOOTING FLASH CODE 44

Perform the following steps to troubleshoot Flash Code 44.

### 44.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR).
3. Read active codes.
  - [a] If active codes other than 110/0 or 175/0 are logged, service them first.
  - [b] If active codes 110/0 or 175/0 are logged, and no other codes are logged, oil or coolant temperature was higher than it should have been. Inspect for damage. Plug in the reader and determine if code is coolant or oil temperature high.
  - [c] If active code 110/0 is logged, and the duration of this code is less than 20 seconds, or if it has multiple occurrences which average less than 20 seconds each, contact Detroit Diesel Technical Service.

**NOTE:**


For information concerning high temperature levels, refer to section 4.1 in the service manual.

---

## 45 FLASH CODE 45 - OIL PRESSURE LOW

Section	Page
45.1 DESCRIPTION OF FLASH CODE 45 .....	45- 3
45.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 45 .....	45- 3
45.3 TROUBLESHOOTING FLASH CODE 45 .....	45- 4

---



31244

**Figure 45-1      Oil Pressure Sensor**

## **45.1 DESCRIPTION OF FLASH CODE 45**

Flash Code 45 indicates that the ECM has detected that the engine oil pressure has dropped below the recommended safe operating range. See Figure 45-1 for the engine oil pressure sensor.

Conditions: ECM looks for a minimum pressure vs. speed. This can vary for each engine type.

## **45.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 45**

The SAE J1587 equivalent code for Flash Code 45 is p 100 1, oil pressure low.



## 45.3 TROUBLESHOOTING FLASH CODE 45

Perform the following steps to troubleshoot Flash Code 45.

### 45.3.1 Multiple Code Check

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR)
3. Read active codes.
  - [a] If codes other than 100/1 are logged, service them first.
  - [b] If code 100/1 is logged, and no other codes are logged, there was an engine running condition at which oil pressure was lower than it should have been.

#### **NOTE:**

For information concerning low oil pressure level, refer to section 3.1 in the engine service manual.

---

# 46 FLASH CODE 46 - BATTERY VOLTAGE LOW

Section	Page
46.1 DESCRIPTION OF FLASH CODE 46 .....	46- 3
46.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 46 .....	46- 3
46.3 TROUBLESHOOTING FLASH CODE 46 .....	46- 4



## 46.1 DESCRIPTION OF FLASH CODE 46

Flash Code 46 indicates that the DDEC system has detected that the main battery supply voltage to the ECM has dropped below the recommended operating range.

The DDEC system will operate on 12 or 24 volts.

- ☐ Normal operating voltage of the DDEC system is 11 to 32 volts DC, measured at the ECM.
- ☐ Operating the ECM between 6 and 11 volts may result in degraded engine operation. (Transient operation in this range during engine starting is considered normal for 12-volt systems.)
- ☐ Operating the ECM over 32 volts will cause damage.
- ☐ Reversing polarity will cause damage to the ECM if the power harness is not properly fused.

## 46.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 46

The SAE J1587 equivalent code for Flash Code 46 is p 168 1.

The power harness supplies 12 or 24 volts to the ECM. The system must be sourced directly from the battery.

### **NOTE:**

Connection to reverse polarity will damage the system if not properly fused.

## 46.3 TROUBLESHOOTING FLASH CODE 46

The following procedure will troubleshoot Flash Code 46.

### 46.3.1 Battery Check

Perform the following steps to check the battery.

1. Start and run the engine for one minute.
2. Measure voltage on battery + terminal (red lead) to battery - terminal (black lead).  
Recommended fuse applications are listed in Table 46-1. Power harness length criteria is listed in Table 46-2.
  - [a] If the engine does not start, inspect the battery and charging/starting system, and proceed if okay. Refer to section 9.1.
  - [b] If the engine does start and the voltage measurement is less than or equal to 10.0 volts, service the discharged battery and charging/starting system.
  - [c] If the engine does start and the voltage measurement is greater than 10.0 volts, refer to section 46.3.2.

Number of Cylinders	Dual Fuse or Circuit Breaker Size	Single Fuse or Circuit Breaker Size
6	2 @ 15 amp	1 @ 30 amp
8	2 @ 20 amp	1 @ 40 amp
12	4 @ 15 amp	2 @ 30 amp
16	4 @ 20 amp	2 @ 40 amp
20	4 @ 15 amp2 @ 20 amp	2 @ 30 amp1 @ 40 amp

**Table 46-1 Fuse Size Recommendations**

Length from ECM to Battery or Bus Bar (ft) *	Minimum Wire Size (Ga) *	Total Resistance of Maximum Length (m $\Omega$ ) *	Length from ECM to Battery or Bus Bar (m) †	Minimum Wire Size (Ga) †	Total Resistance of Maximum Length (m $\Omega$ ) †
0 to 28 ‡	12	24.8	0 to 6 ‡	2.5	22.8
28 to 44 ‡	10	24.57	6 to 10 ‡	4	23.55
44 to 70 ‡	8	24.58	10 to 14 ‡	6	21.98
70 to 110 ‡	6	24.7	14 to 26 ‡	10	23.66
110 to 178 ‡	4	25.0	26 to 40 ‡	16	23.2
0 to 14 §	12	24.8	0 to 3 §	2.5	22.8
14 to 22 §	10	24.57	3 to 5 §	4	23.55
22 to 35 §	8	24.58	5 to 7 §	6	21.98
35 to 55 §	6	24.7	7 to 13 §	10	23.66
55 to 89 §	4	25.0	13 to 20 §	16	23.2

\* United States

† International

‡ Dual Fuse

§ Single Fuse

**Table 46-2 Maximum Resistance vs Power Harness Length****46.3.2 Voltage Check at ECM**


Perform the following steps to check voltage at the ECM.

1. Keep engine running.
2. Select ECM INPUT VOLT on DDR.
3. Observe ECM voltage reading on DDR.
  - [a] If the voltage measurement is less than or equal to 10.0 volts, refer to section 46.3.3.
  - [b] If the voltage measurement is greater than 10.0 volts, refer to section 46.3.5.


### 46.3.3 Voltage Check at ECM Via Volt-Ohm Meter

Perform the following steps to check voltage at the ECM.

1. Turn the vehicle ignition OFF.
  2. Disconnect 5-way power harness connector at the ECM.
  3. Measure voltage from socket A and C (red lead) of 5-way power harness connector and a good battery ground (black lead). Don't use line (#151) as a ground reference. For 5-way ECM power harness connector, see Figure 46-1. For power harness schematic, see Figure 46-2.
- [a] If the voltage measurement is less than or equal to 11.5 volts, refer to section 46.3.4.
- [b] If the voltage measurement is greater than 11.5 volts, refer to section 46.3.5.



**Figure 46-1 5-Way ECM Power Connector**




**Figure 46-2      Power Harness**



### 46.3.4 Check for Bad Battery + Line

Perform the following steps to check for a bad battery + line.

1. Remove fuse(s) to the ECM.
2. Measure voltage at socket A of one fuseholder (red lead) to a good ground (black lead).  
For 5-way ECM power harness, see Figure 46-3.
3. Repeat voltage measurement at other fuseholder.
  - [a] If the voltage measurement is greater than 11.5 volts on both readings, the battery + line between the fuseholder and ECM has an open, or the ECM power connector has a *corroded connection*. Repair the problem. Refer to section 46.3.8.
  - [b] If the voltage measurement is less than or equal to 11.5 volts on either reading, the battery + line near the battery is open, or a corroded connection exists at battery + terminal. Repair the problem. Refer to section 46.3.8.



**Figure 46-3 5-Way ECM Power Harness**

### 46.3.5 Ground Check at ECM

Perform the following steps to check the ground at the ECM.

1. Disconnect the 5-way power harness connectors at the ECM. For 5-way ECM power harness, see Figure 46-3.
2. Measure voltage on socket A (red lead) to socket D (black lead) and socket C of 5-way power harness connector (red lead) to socket E, (black lead).
  - [a] If voltage measurement is greater than 11.5 volts on either reading, refer to section 46.3.6.
  - [b] If the voltage measurement is less than or equal to 11.5 volts on either reading, the ground wire (#150) is open or has a corroded connection. Repair ground wire, and refer to section 46.3.8.

### 46.3.6 Check ECM Connectors

Perform the following steps to check ECM connectors.

1. Check terminals at the ECM 5-way power harness connector (both ECM and harness side) for damage; bent, corroded, and unseated pins or sockets.
  - [a] If terminals and connector are damaged, repair them. Refer to section 46.3.8.
  - [b] If terminals and connector are not damaged, verify the power and ground are wired directly to the battery. Refer to section 46.3.7.

### 46.3.7 Code Check

Perform the following steps to check for codes.

1. Install the vehicle interface module.
2. Turn ignition ON; plug in DDR.
3. Check for codes.
  - [a] If code reoccurs, install test ECM, then refer to section 46.3.8.
  - [b] If code does not reoccur, check power harness wires for breaks, abrasions, etc. Then refer to section 46.3.8.

### 46.3.8 Verify Repairs


Perform the following steps to verify repairs.

1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes with DDR.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are displayed, troubleshooting is complete.
  - [b] If code 168/1 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 168/1 is logged, and other codes are logged, all system diagnostics are complete. To troubleshoot the error, refer to section 46.3.1.

---

## **47 FLASH CODE 47 - AIR / FUEL PRESSURE HIGH**

<b>Section</b>	<b>Page</b>
47.1 DESCRIPTION OF FLASH CODE 47 .....	47- 3
47.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 47 .....	47- 3
47.3 TROUBLESHOOTING FLASH CODE 47 .....	47- 3



**Figure 47-1      Fuel Pressure Sensor**

## 47.1 DESCRIPTION OF FLASH CODE 47

Flash Code 47 indicates that the ECM has detected that the fuel pressure, air inlet pressure, or turbo boost pressure has exceeded a programmed operating range. This normally occurs due to a mechanical fault in the air system or fuel system of the engine. See Figure 47-1, for the fuel pressure sensor.

### NOTE:

Not all engines use a fuel pressure sensor.

For gas engines, code 47 indicates that the air inlet pressure has exceeded a calibration limit programmed in the ECM.

For diesel engines, code 47 indicates that the turbo boost pressure has exceeded a calibration limit programmed in the ECM.

## 47.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 47

The SAE J1587 equivalent code for Flash Code 47 is p 094/0, fuel pressure high.

The SAE J1587 equivalent code for Flash Code 47 is p 106/0, air inlet pressure high (Gas-fueled engines).

The SAE J1587 equivalent code for Flash Code 47 is p 102/0, turbo boost pressure high (Diesel-fueled engines).

## 47.3 TROUBLESHOOTING FLASH CODE 47

This code is a mechanical fault. Check for reasons for high fuel pressure. Refer to appropriate service manual, section 5.

This (Gas-fueled engine) code is a mechanical fault. Check for reasons for high air inlet pressure. Refer to appropriate service manual, section 6.

This (Diesel-fueled engine) code is a mechanical fault. Check for reasons for high turbo boost pressure, e.g. wastegate bypassed. Refer to appropriate service manual, section 6.




---

## 48 FLASH CODE 48 - AIR / FUEL PRESSURE LOW

Section	Page
48.1 DESCRIPTION OF FLASH CODE 48 .....	48- 3
48.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 48 .....	48- 3
48.3 TROUBLESHOOTING FLASH CODE 48 .....	48- 3





**Figure 48-1      Fuel Pressure Sensor**

## 48.1 DESCRIPTION OF FLASH CODE 48

Flash Code 48 indicates that the ECM has detected that the Fuel Pressure has dropped below a programmed limit. This condition is normally associated with a restriction in the fuel supply system:

- ☐ Plugged fuel filter
- ☐ Low fuel supply

### NOTE:

Not all engines use a fuel pressure sensor, see Figure 48-1.

For gas engines, code 48 indicates that the air inlet pressure has dropped below a calibration limit.

## 48.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 48

The SAE J1587 equivalent code for Flash Code 48 is p 094/1, fuel pressure high.

The SAE J1587 equivalent code for Flash Code 48 is p 106/1, air inlet pressure low. (Gas-fueled engines)

## 48.3 TROUBLESHOOTING FLASH CODE 48

This code is a mechanical fault. Check for reasons for low fuel pressure. Refer to appropriate service manual, section 5.

This (Gas-fueled engine) code is a mechanical fault. Check for reasons for low air inlet pressure. Refer to appropriate service manual, section 6.



---

# 49 FLASH CODE 49

Section	Page
49.1 DESCRIPTION OF FLASH CODE 49 .....	49- 3



## **49.1 DESCRIPTION OF FLASH CODE 49**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

**50 FLASH CODE 50**

<b>Section</b>	<b>Page</b>
50.1 DESCRIPTION OF FLASH CODE 50 .....	50- 3





## 50.1 DESCRIPTION OF FLASH CODE 50

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

## 51 FLASH CODE 51

Section	Page
51.1 DESCRIPTION OF FLASH CODE 51 .....	51- 3



## 51.1 DESCRIPTION OF FLASH CODE 51

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

# 52 FLASH CODE 52 - ECM FAULT

Section	Page
52.1 DESCRIPTION OF FLASH CODE 52 .....	52- 3
52.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 52 .....	52- 3
52.3 TROUBLESHOOTING FLASH CODE 52 .....	52- 3





## **52.1 DESCRIPTION OF FLASH CODE 52**

Flash Code 52 indicates that the DDEC system ECMs internal Analog to Digital (A/D) Convertor device has malfunctioned. Intermittent diagnostic conditions of this type can be caused by faulty external electrical system.

## **52.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 52**

The SAE J1587 equivalent code for Flash Code 52 is s 254 12.

## **52.3 TROUBLESHOOTING FLASH CODE 52**

The following procedure will troubleshoot Flash Code 52.

### **52.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR).
3. Read active codes.
  - [a] If active codes other than 254/12 are logged, service them first.
  - [b] If active code 254/12 is logged, and no other codes are logged, hook up test ECM. If code clears, replace the ECM. If code is not cleared, contact Detroit Diesel Technical Service.

### **NOTE:**

For information concerning ECM replacement, refer to section 2.9 in the service manual.



---

# 53 FLASH CODE 53 - ECM MEMORY FAULT

Section	Page
53.1 DESCRIPTION OF FLASH CODE 53 .....	53- 3
53.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 53 .....	53- 3
53.3 TROUBLESHOOTING FLASH CODE 53 .....	53- 3



### **53.1 DESCRIPTION OF FLASH CODE 53**

Flash Code 53 indicates that the ECM was unable to read a valid copy of an engine data record (calibration, faults, or accumulators) stored in nonvolatile memory.

Flash Code 53 also indicates that the ECM was unable to update an engine data record (calibration, faults, or accumulators) stored in nonvolatile memory.

### **53.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 53**

The SAE J1587 equivalent code for Flash Code 53 is s 253 12, EEPROM write fail.

The SAE J1587 equivalent code for Flash Code 53 is s 253 2, nonvolatile checksum incorrect.

### **53.3 TROUBLESHOOTING FLASH CODE 53**

The following procedure will troubleshoot Flash Code 53.

#### **NOTE:**

Inactive code 53 should be cleared with the DDR and the unit returned to service if ECM SW is greater than or equal to 7.00.

#### **53.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR).
3. Read active codes.
  - [a] If codes other than 253/12 or 253/2 are logged, service them first.
  - [b] If codes 253/12 or 253/2 are logged, and no other codes are logged, reprogram the ECM. Refer to section 53.3.2.

### 53.3.2 Test for Codes

Perform the following steps to test for codes.

1. Start and run the engine.
2. Read active codes with DDR.
  - [a] If active code 253/2 is logged, and no other codes are logged, install a test ECM.  
Refer to section 53.3.3.

**NOTE:**

It is recommended that a "Test" ECM be tried first to determine the need to replace the ECM. For information concerning ECM replacement, refer to section 2.9 in the service manual.

- [b] If no codes are logged, troubleshooting is complete.

### 53.3.3 Verify Repairs

Perform the following steps to verify repairs.

1. Start and run the engine.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If codes are logged, contact Detroit Diesel Technical Service.

---

# 54 FLASH CODE 54 - VSS FAULT

Section	Page
54.1 DESCRIPTION OF FLASH CODE 54 .....	54- 3
54.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 54 .....	54- 3
54.3 TROUBLESHOOTING FLASH CODE 54 .....	54- 3





## 54.1 DESCRIPTION OF FLASH CODE 54

Flash Code 54 indicates that during engine operation the vehicle speed that is measured by the Vehicle Speed Sensor (VSS) is less than the expected value for the current engine speed/conditions.

This diagnostic condition is typically:

- ☐ Open sensor signal circuit
- ☐ Conditions
  - ☐ Code is logged (without anti-tamper) when the mph >1500 and PW >15° and vehicle speed < 3 mph.
  - ☐ If code is logged (with or without anti-tamper) mph will be limited.

### NOTE:

Code will not be logged for the first five hours of ECMs life (total engine hours).

## 54.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 54

The SAE J1587 equivalent code for Flash Code 54 is p 084 12.

## 54.3 TROUBLESHOOTING FLASH CODE 54

The following procedure will troubleshoot Flash Code 54.

### 54.3.1 Test Drive Vehicle

Take the vehicle for a test drive with an assistant.

1. View DDR; select vehicle speed.
  - [a] If mph reads 0 (zero), or stays steady with the vehicle in motion, refer to section 54.3.2.
  - [b] If speed appears correct, refer to section 54.3.11.

### 54.3.2 Speed Sensor Identification

Identify the speed sensor type - type one or type two.

1. The type one sensor is a magnetic pickup and may be located in one of the following locations: transmission tail shaft, wheel rim, mechanical speedometer cable. If you have a type one sensor, refer to section 54.3.3. (Verify with DDR signal type - magnetic.)
2. The type two sensor communicates with square wave input and output signals and requires the ECM to be configured correctly. Refer to section 54.3.12. (Verify with DDR signal type - switched.)

### 54.3.3 Check Vehicle Speed Sensor Circuit

Perform the following steps to check the vehicle speed sensor.

1. With ignition off, disconnect the vehicle harness connector.
2. Measure resistance of VSS circuit across vehicle harness connector pins, E2 to E3.  
See Figure 54-1.
  - [a] If the resistance measurement is less than 50  $\Omega$ , refer to section 54.3.4.
  - [b] If the resistance measurement is greater than 3,000  $\Omega$  or open, refer to section 54.3.6.
  - [c] If the resistance measurement is between 50 and 3,000  $\Omega$ , refer to section 54.3.7.




Figure 54-1 ECM Vehicle Harness Connector

### 54.3.4 Check for Short

Perform the following steps to check for short.

1. Disconnect VSS connector.
2. Measure resistance between vehicle harness connector terminals E2 and E3.  
See Figure 54-1.
  - [a] If the resistance measurement is less than or equal to 1,000  $\Omega$ , the signal wire #556 or return wire #557, are shorted together. Repair the short; refer to section 54.3.13.
  - [b] If the resistance measurement is greater than 1,000  $\Omega$  or open, refer to section 54.3.5.

### 54.3.5 Check Vehicle Speed Sensor


Perform the following steps to check the vehicle speed sensor.

1. Measure resistance of VSS across vehicle speed sensor connector pins. See Figure 54-1.
  - [a] If the resistance measurement is less than 50  $\Omega$ , refer to section 54.3.8.
  - [b] If the resistance measurement is greater than 3,000  $\Omega$  or open, refer to section 54.3.8.
  - [c] If the resistance measurement is between 50 and 3,000  $\Omega$ , refer to section 54.3.10.

### 54.3.6 Check for Open

Perform the following steps to check for open.

1. Disconnect the ECM vehicle harness connector and VSS connector.
2. Install a jumper wire between sockets A and B of the VSS harness connector.
3. Measure resistance between sockets E2 and E3 on the ECM vehicle harness connector. See Figure 54-2.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 54.3.5.
  - [b] If the resistance measurement is greater than 5  $\Omega$  or open, the VSS signal line #556 or return line #557 is open. Repair open and refer to section 54.3.13.




**Figure 54-2 ECM Vehicle Harness Connector**

### 54.3.7 Check for Short to Ground

Perform the following steps to check for short to ground.

1. Turn ignition OFF.
2. Remove jumper wire.
3. Measure resistance between sockets E2 and E3 and a good ground. See Figure 54-3.
  - [a] If the resistance measurement is greater than 1,000  $\Omega$  or open, refer to section 54.3.9.
  - [b] If the resistance measurement is less than or equal to 1,000  $\Omega$ , the signal wire #556 or return wire #557, is shorted to ground, or wired to an unauthorized device. Repair the short; refer to section 54.3.13.



**Figure 54-3 ECM Vehicle Harness Connector**

### 54.3.8 Check Vehicle Speed Sensor Connectors


Perform the following steps to check the VSS connectors.

1. Check terminals at the VSS connectors (both sensor side and harness side) for bent, corroded, and unseated pins or sockets.
  - [a] If the terminals and connectors are not damaged, replace the VSS. Refer to section 54.3.13.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 54.3.13.

### 54.3.9 Check for Short to Power

Perform the following steps to check for short to power.

1. Turn ignition ON.
2. Measure voltage at the ECM vehicle harness connector between socket E3 (#557) and a good ground. Also measure voltage between socket E2 (#556) and a good ground. See Figure 54-4.
  - [a] If both voltage measurements are less than 0.2 volts, refer to section 54.3.10.
  - [b] If either voltage measurement is greater than or equal to 0.2 volts, the VSS signal (#556) or VSS return line (#557) is shorted to the battery or some other source of voltage. Repair the short; refer to section 54.3.13.




**Figure 54-4 5-Way ECM Power Connector**

### 54.3.10 Check ECM Connectors

Perform the following steps to check ECM connectors.

1. Check the terminals at the ECM engine harness connectors for bent, corroded, and unseated pins or sockets, on both the ECM and harness sides. See Figure 54-5.
  - [a] If the terminals and connectors are not damaged, refer to section 54.3.11.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 54.3.13.



**Figure 54-5 ECM Vehicle Harness Connector**



### 54.3.11 Vehicle Speed Mechanical Checks

Perform the following vehicle speed mechanical checks.


1. Check for plugged fuel filters.
2. Check if any metal or debris is lodged between the VSS and the pulse wheel.
3. Check if the sensor is loose.
4. Ensure the VSS pulse wheel is in fixed position relative to magnetic pickup.
5. Check for proper air gap between magnetic pickup and pulse wheel.
  - [a] If all mechanical checks are okay, contact Detroit Diesel Technical Service for review if anti-tamper = yes.
  - [b] If all mechanical checks are not okay, repair the mechanical failure.  
Refer to section 54.3.13.

### 54.3.12 Check for Short to Ground

Perform the following steps to check for short to ground.

1. Turn ignition OFF.
2. Disconnect the ECM vehicle harness connector.
3. Measure resistance between sockets E2 and a good ground. See Figure 54-6.
  - [a] If the resistance measurement is greater than 10,000  $\Omega$  or open, contact the component supplier for instructions. The wiring is okay, but the device may be defective. Refer to section 54.3.13.

- [b] If the resistance measurement is less than or equal to  $100\ \Omega$ , the VSS signal line (#556) is shorted to ground, Repair the short; refer to section 54.3.13.



**Figure 54-6 ECM Vehicle Harness Connector**

### 54.3.13 Verify Repairs


Perform the following steps to verify repairs.

1. Turn the ignition OFF.
2. Reconnect all the connectors.
3. Turn the ignition ON.
4. Clear DDR codes.
5. Perform a road test with an assistant. Ensure the vehicle is loaded.
6. Stop the engine.
7. Check DDR for codes.
  - [a] If no codes are logged, no further troubleshooting is required.
  - [b] If code 84/12 is not logged, and other codes are logged, refer to section 9.1.
  - [c] If code 84/12 is logged, and any other codes are logged, all system diagnostics are complete. To troubleshoot the error, refer to section 54.3.2 and perform tasks.


---

## 55 FLASH CODE 55 - J1939 DATA LINK FAULT

Section	Page
55.1 DESCRIPTION OF FLASH CODE 55 .....	55- 3
55.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 55 .....	55- 3
55.3 TROUBLESHOOTING FLASH CODE 55 .....	55- 3



DDEC III / IV ECM  
FRONT SIDE



ENGINE HARNESS  
CONNECTIONS  
LEFT SIDE


INJECTOR HARNESS  
CONNECTORS  
(5-PIN)

ENGINE HARNESS  
CONNECTOR  
(30-PIN)

POWER HARNESS  
CONNECTOR  
(5-PIN)

COMMUNICATION  
HARNESS  
CONNECTOR  
(6-PIN)

VEHICLE INTERFACE  
HARNESS  
CONNECTOR  
(30-PIN)



VEHICLE HARNESS (OEM)  
CONNECTIONS  
RIGHT SIDE

31184

Figure 55-1 ECM

## **55.1 DESCRIPTION OF FLASH CODE 55**

Flash Code 55 indicates the ECM, see Figure 55-1, has detected a fault in the J1939 Data Link.

- ☐ Incorrect programming
- ☐ Wiring fault, J1939 data link wires

## **55.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 55**

The SAE J1587 equivalent code for Flash Code 55 is s 231/12.

## **55.3 TROUBLESHOOTING FLASH CODE 55**

The following procedure will troubleshoot Flash Code 55.

### **55.3.1 Check J1939 Data Link**

Perform the following steps to check for J1939 data link fault.

1. Is this a J1939 transmission/engine application?
  - [a] If yes, contact Detroit Diesel Technical Service.
  - [b] If no, use programming station and go to "update customer calibration" and select transmission to manual, or correct transmission. Save changes. Refer to section 55.3.2.

### **55.3.2 Verify Repairs**

Perform the following steps to verify repairs.

1. Start engine.
2. Plug in DDR.
3. Read codes.
  - [a] If active code 231/12 is not logged, troubleshooting is complete.
  - [b] If active code 231/12 is logged, contact Detroit Diesel Technical Service. Check DDR software level. Update DDR software if current level is 1.2.



---


## 56 FLASH CODE 56 - J1587 DATA LINK FAULT

Section	Page
56.1 DESCRIPTION OF FLASH CODE 56 .....	56- 3
56.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 56 .....	56- 3
56.3 TROUBLESHOOTING FLASH CODE 56 .....	56- 4






DDEC III / IV ECM  
FRONT SIDE



INJECTOR HARNESS  
CONNECTORS  
(5-PIN)

ENGINE HARNESS  
CONNECTOR  
(30-PIN)

ENGINE HARNESS  
CONNECTIONS  
LEFT SIDE



POWER HARNESS  
CONNECTOR  
(5-PIN)

COMMUNICATION  
HARNESS  
CONNECTOR  
(6-PIN)

VEHICLE INTERFACE  
HARNESS  
CONNECTOR  
(30-PIN)

VEHICLE HARNESS (OEM)  
CONNECTIONS  
RIGHT SIDE

31184

Figure 56-1 ECM

## **56.1 DESCRIPTION OF FLASH CODE 56**

Flash Code 56 indicates that the J1587 (diagnostic) data link is no longer allowing the ECM, see Figure 56-1, to transmit data.

This diagnostic condition is typically:

- ☐ Either or both of the data link circuits are open at some point in the network.
- ☐ Either or both of the data link circuits are shorted to ground at some point in the network.
- ☐ Either or both of the data link circuits are shorted to battery (+) at some point in the network.
- ☐ The pair of data link circuits are shorted together.

## **56.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 56**

The SAE J1587 equivalent code for Flash Code 56 is s 250 12.

## **56.3 TROUBLESHOOTING FLASH CODE 56**

The following procedure will troubleshoot Flash Code 56.

### **56.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR).
3. Visually check the DDR for codes.
  - [a] If codes other than 250/12 are logged, service them first.
  - [b] If code 250/12 is logged, and no other codes are logged, Refer to section 56.3.2.
  - [c] If no data is logged, refer to section 9.1.

### **56.3.2 Clear Codes**

Perform the following steps to clear codes.

1. Clear codes.
2. Start and run the engine.
3. Observe CEL/code.
  - [a] If CEL is on with code 250/12 logged, refer to section 56.3.3.
  - [b] If no CEL code is logged, refer to section 56.3.5.

### **56.3.3 Check for Devices of Original Equipment Manufacturer**

Perform the following steps to check for OEM devices.

1. Turn vehicle ignition OFF.
2. Determine if any OEM equipment utilizes the J1587 data link. (ABS, ProDriver<sup>®</sup>, satellite systems, etc.)
  - [a] If any OEM devices are installed, refer to section 56.3.4. Refer to step 1
  - [b] If no OEM devices are installed, refer to section 56.3.4. Refer to step 2[a]

### **56.3.4 Disconnect Nodes (Data Link Devices)**

Perform the following steps to disconnect the nodes.

1. Disconnect OEM installed devices, one at a time e.g. ABS, satellite systems, etc. Verify ABS switch is not in "Test" mode.
  - [a] If the disconnect does not solve the problem, continue the procedure.  
Refer to step 2[a]
  - [b] If the disconnect solved the problem, go to 4b.
2. Connect vehicle interface module, J 41005.
3. Start and run the engine.
4. Observe CEL codes.
  - [a] If CEL or codes displayed, and the CEL is on with code 250/12 logged, replace the ECM with a test ECM. Refer to section 56.3.5.
  - [b] If no CEL or codes are displayed, contact OEM for instructions on how to proceed.  
Refer to section 56.3.5.

### **56.3.5 Verify Repairs**

Perform the following steps to verify repairs.

1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Start and run the engine.
  - [a] If the CEL or codes are displayed, and if code 250/12 is logged, all system diagnostics are complete. Review this section to find the error.
  - [b] If the CEL or codes are not displayed, troubleshooting is complete.




---

## 57 FLASH CODE 57 - J1922 DATA LINK FAULT

Section	Page
57.1 DESCRIPTION OF FLASH CODE 57 .....	57- 3
57.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 57 .....	57- 3
57.3 TROUBLESHOOTING FLASH CODE 57 .....	57- 4



DDEC III / IV ECM  
FRONT SIDE



31184

Figure 57-1 ECM

## **57.1 DESCRIPTION OF FLASH CODE 57**

Flash Code 57 indicates that the J 1922 (Low Speed Powertrain) data link is no longer allowing the ECM, see Figure 57-1, to transmit data.

This diagnostic condition is typically:

- ☐ Either or both of the data link circuits are open at some point in the network.
- ☐ Either or both of the data link circuits are shorted to ground at some point in the network.
- ☐ Either or both of the data link circuits are shorted to battery (+) at some point in the network.
- ☐ The pair of data link circuits are shorted together.

## **57.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 57**

The SAE J1587 equivalent code for Flash Code 57 is s 249 12.



## 57.3 TROUBLESHOOTING FLASH CODE 57

The following procedure will troubleshoot Flash Code 57.

### 57.3.1 Code Check

Perform the following steps to check for codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR).
3. Visually check the DDR for codes.
  - [a] If code 249/12 is logged, refer to section 57.3.2.
  - [b] If no codes are logged, refer to section 9.1.
  - [c] If code 254/12 is logged, and no other codes are logged, replace the ECM. Refer to section 9.1.

### 57.3.2 Verify Codes


Perform the following steps to verify codes.

1. Clear codes with DDR.
2. Start and run the engine for one minute.
3. Check CEL for codes.
  - [a] If CEL is on with code 249/12 displayed, refer to section 57.3.3.
  - [b] If CEL is not on and no codes are displayed, refer to section 57.3.5.

### 57.3.3 Check for OEM Devices

Perform the following steps to check for OEM devices.

1. Turn vehicle ignition OFF.
2. Determine if any OEM equipment utilizes the J 1922 data link. See Figure 57-2.
  - [a] If no OEM devices are installed, refer to section 57.3.4. Refer to step 2
  - [b] If OEM devices are installed, refer to section 57.3.4. Refer to step 1



**Figure 57-2 Communication Harness**

### **57.3.4 Disconnect Nodes**

Perform the following steps to disconnect nodes.

1. Start and run engine with OEM installed devices disconnected.
  - [a] If the disconnect does not solve the problem, continue the procedure. Refer to step 2
  - [b] If the disconnect solved the problem, Refer to step 44[a].
2. Connect vehicle interface module using J 41005.
3. Start and run engine.
4. Observe CEL codes.
  - [a] If no CEL or codes are displayed, contact OEM for instructions on how to proceed. Refer to section 57.3.5. Fault is in node/wiring.
  - [b] If CEL is on with code 249/12 logged, install a test ECM. Refer to section 57.3.5.

### **57.3.5 Verify Repairs**

Perform the following steps to verify repairs.

1. Turn vehicle ignition OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes with DDR.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for codes.
  - [a] If no codes are displayed, troubleshooting is complete.
  - [b] If CEL is on with code 249/12 logged, all system diagnostics are complete. To troubleshoot the error, refer to section 57.3.1.

---

## 58 FLASH CODE 58

Section	Page
58.1 DESCRIPTION OF FLASH CODE 58 .....	58- 3
58.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 58 .....	58- 3



## **58.1 DESCRIPTION OF FLASH CODE 58**

Flash Code 58 indicates a torque overload.

This code is not covered in this manual. If changes occur, notification will be sent from DDC.

## **58.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 58**

The SAE J1587 equivalent code for Flash Code 58 is p 092/0.



---

# 59 FLASH CODE 59

Section	Page
59.1 DESCRIPTION OF FLASH CODE 59 .....	59- 3





## **59.1 DESCRIPTION OF FLASH CODE 59**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

# 60 FLASH CODE 60

Section	Page
60.1 DESCRIPTION OF FLASH CODE 60 .....	60- 3



## **60.1 DESCRIPTION OF FLASH CODE 60**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.




---

## 61 FLASH CODE 61 - INJECTOR RESPONSE LONG

Section	Page
61.1 DESCRIPTION OF FLASH CODE 61 .....	61- 3
61.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 61 .....	61- 3
61.3 TROUBLESHOOTING FLASH CODE 61 .....	61- 4

---





**Figure 61-1      Injectors**

## 61.1 DESCRIPTION OF FLASH CODE 61

Flash Code 61 indicates that the time it takes from when the DDEC III ECM requests an injector, see Figure 61-1, be turned on to when the injector solenoid valve actually closes is longer than the high limit of the expected range. Engine oil temperature must be greater than 87°F (30°C).

This diagnostic condition is typically:

- ☐ Bad injector harness and or connection (high resistance)
- ☐ Poor vehicle grounds
- ☐ Sticky solenoid valve

### NOTE:

The injector diagnostic SID (Subsystem Identifier) indicates which cylinder number has an injector with a long response time. The injector number describes the cylinder and or bank which has the injector with a long response time. The DDR will display the injector text description.

Injector response times generally increase with low battery supply voltage and decrease with high battery supply voltage. Although injector response times vary from injector to injector at a given r/min, each individual injector response time should remain relatively consistent from one firing to the next. Wide variations in response time (typically +/- 0.2 msec) for one injector at a steady engine r/min may indicate an electrical problem (faulty alternator or voltage regulator, poor or broken ground cables, etc.).

## 61.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 61

The SAE J1587 equivalent code for Flash Code 61 is s 001 0, or s 002 0, or s 003 0, or s 004 0, or s 005 0 or s 006 0 (six cylinder engine).

## 61.3 TROUBLESHOOTING FLASH CODE 61

The following procedure will troubleshoot Flash Code 61.

### 61.3.1 Test Alternator Ground

Perform the following steps to test alternator ground.

1. Disable the alternator by removing the alternator belt.
2. Start and run the engine; warm to greater than 87°F (30°C).
3. Does the code return?
  - [a] If Flash Code 61 does not return, repair or replace the alternator grounds and refer to section 61.3.5.
  - [b] If the code(s) return, refer to section 61.3.2.

### 61.3.2 Determine Cylinders With Fault

The injector location that is logging the codes is listed in Table 61-1.

	#1	#2	#3	#4	#5	#6	
	(SID 1)	(SID 2)	(SID 3)	(SID 4)	(SID 5)	(SID 6)	
S55/60	1	5	3	6	2	4	cyl #
S50	1	3	4	2	-	-	cyl #

**Table 61-1 Determine Cylinders With Fault**


1. Disconnect the 5-pin injector harness connector at the ECM for those injectors logging the codes.
2. Establish a good ECM case ground by measuring the resistance across two points on the ECM. The resistance should measure less than or equal to 1  $\Omega$ .
3. Once a good case ground is established, keep one of the measurement probes in place and move the other probe to one of the five exposed male injector terminals on the ECM.
4. Measure the resistance. Repeat this procedure at each of the five terminals.
  - [a] If any terminals have a resistance of less than 1,000  $\Omega$ , replace the ECM. Refer to section 61.3.5.
  - [b] If all terminals have a resistance of greater than 1,000  $\Omega$ , refer to section 61.3.3.

### 61.3.3 Check for Short

Perform the following steps to check for a short.

1. Locate the injector harness connector terminals associated with the codes. See Figure 61-2.
2. Measure resistance between that cavity and the cylinder block.
  - [a] If measured resistance is less than 10  $\Omega$ , the wire is shorted to the engine. Repair or replace the harness and refer to section 61.3.5.
  - [b] If measured resistance is greater than 10  $\Omega$ , go to step 3.
3. Remove the valve cover to gain access to the cylinder associated with the code.
4. Remove the connector terminals at the injector solenoid(s).
5. Measure resistance between that cavity and the appropriate return cavity (G or E).
  - [a] If measured resistance is less than 5  $\Omega$ , the wire is shorted to the return wire. Repair or replace the harness and refer to section 61.3.5.

[b] If measured resistance is greater than 5  $\Omega$ , refer to section 61.3.4.



31258

**Figure 61-2**      **Injector Harness**

### **61.3.4 Check for Open**

Perform the following steps to check for an open.

1. Insert a jumper wire between the cavity associated with the code and the return for that connector (G or E).
2. Measure resistance across the injector connectors (disconnected from injector solenoid).
  - [a] If the measured resistance is greater than 5  $\Omega$ , the injector wire is open. Repair or replace the harness and refer to section 61.3.5.
  - [b] If the measured resistance is less than 5  $\Omega$ , and the ECM software is less than 3.00, reprogram the ECM. Refer to section 61.3.5.

### **61.3.5 Verify Repairs**

Perform the following steps to verify repairs:

1. Start and run the engine. Warm to 87°F (30°C).
2. Check DDR for codes.
  - [a] If injector codes are logged, please review this section from the first step to find the problem. Refer to section 61.3.2.
  - [b] If no codes are logged, no further troubleshooting is required.



---


## 62 FLASH CODE 62 - OUTPUT FAULT

Section	Page
62.1 DESCRIPTION OF FLASH CODE 62 .....	62- 3
62.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 62 .....	62- 3
62.3 TROUBLESHOOTING FLASH CODE 62 .....	62- 4





DDEC III / IV ECM  
FRONT SIDE



ENGINE HARNESS  
CONNECTIONS  
LEFT SIDE


INJECTOR HARNESS  
CONNECTORS  
(5-PIN)

ENGINE HARNESS  
CONNECTOR  
(30-PIN)

POWER HARNESS  
CONNECTOR  
(5-PIN)

COMMUNICATION  
HARNESS  
CONNECTOR  
(6-PIN)

VEHICLE INTERFACE  
HARNESS  
CONNECTOR  
(30-PIN)



VEHICLE HARNESS (OEM)  
CONNECTIONS  
RIGHT SIDE

31184

Figure 62-1 ECM

## 62.1 DESCRIPTION OF FLASH CODE 62

Flash Code 62 indicates that the function assigned to the Auxiliary Output #1, #2, #5, #6, #7 or #8 circuit output has an open circuit or short to battery (+). A short to battery (+) is detected when the DDEC ECM, see Figure 62-1, is unsuccessful in turning "ON" the configured function.

The DDEC III ECM supplies a switched ground to the AUXILIARY OUTPUT circuit to turn ON the function assigned.

Flash Code 62 may also indicate that the function assigned to the Auxiliary Output #1, #2, #5, #6, #7 or #8 circuit output is open, shorted to ground. This diagnostic condition is detected when the Auxiliary Output # "X" function is OFF and the DDEC III ECM measures a low voltage on the circuit output.

## 62.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 62

The SAE J1587 equivalent codes for Flash Code 62 are listed in Table 62-1.

SAE J1587 Code	Output Number	Fault
s 026 3	Auxiliary output #1	Short to battery
s 026 4	Auxiliary output #1	Open circuit
s 040 3	Auxiliary output #2	Short to battery
s 040 4	Auxiliary output #2	Open circuit
s 053 3	Auxiliary output #5	Short to battery
s 053 4	Auxiliary output #5	Open circuit
s 054 3	Auxiliary output #6	Short to battery
s 054 4	Auxiliary output #6	Open circuit
s 055 3	Auxiliary output #7	Short to battery
s 055 4	Auxiliary output #7	Open circuit
s 056 3	Auxiliary output #8	Short to battery
s 056 4	Auxiliary output #8	Open circuit

**Table 62-1     Auxiliary Output Open or Short to Battery**

## **62.3 TROUBLESHOOTING FLASH CODE 62**

The following procedure will troubleshoot Flash Code 62.

### **62.3.1 Code Check**

Perform the following steps to check for codes.

1. Turn vehicle ignition ON.
2. Plug in the diagnostic data reader (DDR).
3. Record codes logged.
4. Clear codes.
5. Start and run the engine for one minute.
  - [a] If the code becomes active, refer to section 62.3.3.
  - [b] If the code does not become active, refer to section 62.3.2.

### **62.3.2 Intermittent Code Check**

Perform the following steps to check intermittent codes.

1. Perform road test.
  - [a] If the code returns, refer to section 62.3.3.
  - [b] If the code does not display again, return the vehicle to service, or refer to section 10.1.1.

### 62.3.3 Auxiliary Output Cavity Determination

Perform the following steps to determine which auxiliary output cavity is associated with the logged codes.

1. Determine which auxiliary output cavity is associated with the code or codes being logged. The SAE code descriptions of the flash codes and the DDC wire numbers are listed in Table 62-2. Continue troubleshooting. Refer to section 62.3.4.

SAE Code Description - Flash Code	DDC Wire Number	Cavity
Auxiliary Output #1 (026 3 or 026 4) 62	499	F3 (VIH)*
Auxiliary Output #2 (040 3 or 040 4) 62	555	A2 (VIH)
Auxiliary Output #5 (053 3 or 053 4) 62	563	W3 (ESH) †
Auxiliary Output #6 (054 3 or 053 4) 62	564	X3 (ESH)
Auxiliary Output #7 (055 3 or 055 4) 62	565	Y3 (ESH)
Auxiliary Output #8 (056 3 or 056 4) 62	988	A1 (VIH)

\* Vehicle Interface Harness

† Engine Sensor Harness

**Table 62-2 Auxiliary Output Cavities**

### 62.3.4 Electrical Check

Perform the following steps to check connectors, dash light or vehicle power-down relay, or item being driven.

1. Check the connectors of the output wire associated with the code logged at the vehicle harness connector or engine sensor harness connector.
2. Check the connectors of the output wire associated with the code logged at the item being driven.
  - [a] If the connectors are not good, repair or replace the terminals. Refer to section 62.3.6.
  - [b] If the connectors are good and the items being driven (e.g. relay, light) are not in good condition, repair or replace the device. (Contact OEM for test procedure.) Refer to section 62.3.6.
  - [c] If the connectors are good and the items being driven (e.g. relay, light, are in good condition, refer to section 62.3.5.

### 62.3.5 Measure Resistance

Perform the following steps to measure the resistance.

1. Turn ignition OFF.
2. Connect the engine sensor harness or vehicle interface harness (connector with output fault).
3. Disconnect the output wire associated with the code logged at the component.
4. Measure the resistance between the removed connector and the ECM case.
  - [a] If the reading is  $47,000\ \Omega$  ( $\pm 3,000\ \Omega$ ), contact Detroit Diesel Technical Service.
  - [b] If the reading is less than  $44,000\ \Omega$  or greater than  $50,000\ \Omega$ , this wire is shorted to the battery or open. Repair or replace this wire. Refer to section 62.3.6.

### 62.3.6 Verify Repairs

Perform the following steps to verify repairs.

1. Reconnect all connectors.
2. Plug DDR into the connector.
3. Clear all codes.
4. Start and run the engine.
  - [a] If the output code returns, refer to section 62.3.1.
  - [b] If the output code does not return, troubleshooting is complete.



---

## 63 FLASH CODE 63 - PWM FAULT

Section	Page
63.1 DESCRIPTION OF FLASH CODE 63 .....	63- 3
63.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 63 .....	63- 3
63.3 TROUBLESHOOTING FLASH CODE 63 .....	63- 4





### **63.1 DESCRIPTION OF FLASH CODE 63**

Flash Code 63 indicates that the pulse width modulation (PWM) output(s) used is either shorted to battery positive or open-circuited.

### **63.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 63**

The SAE J1587 equivalent code for Flash Code 63 is s 057 3, or s 057 4, or s 058 3, or s 058 4, or s 059 3, s 059 4, or s 060 3, or s 060 4.

(FMI 3 = Short to Battery; FMI 4 = Open Circuit)

## 63.3 TROUBLESHOOTING FLASH CODE 63

The following procedure will troubleshoot Flash Code 63.

### 63.3.1 Determine Assignment

Perform the following steps to determine assignment.

1. Turn ignition ON.
2. Plug in the DDR.
3. Select INs/OUTs. To what is PWM assigned? Write down assignment vs cavity and code, listed in Table 63-1.

Code	PWM	Wire Location	Wire #
S057	PWM #1	J3	#908
S058	PWM #2	Y1	#909
S059	PWM #3	W2	#910
S060	PWM #4	X2	#911

**Table 63-1 PWM Assignments**

4. Select code display.
5. Determine Failure Mode Identifier (FMI).
  - [a] If FMI 3 displays, there is a short to the battery. Refer to section 63.3.2
  - [b] If FMI 4 displays, refer to step 6
6. Verify function.
  - [a] If there is a component wired to this position, refer to section 63.3.3.
  - [b] If there is no component wired to this position, reprogram to eliminate the assigned function. (A change may be required to the DDC mainframe.) Refer to section 63.3.9.

### **63.3.2 Verify Short to Battery**

Perform the following steps to verify a short to battery:

1. Turn ignition OFF.
2. Disconnect 30-pin connector: engine connector if PWM 2, 3 or 4; vehicle connector if PWM 1.
3. Measure voltage between the cavity with the code and the good ground.
  - [a] If the voltage measurement is greater than 3 volts, the connector is shorted to the battery. Repair. Refer to section 63.3.9.
  - [b] If the voltage measurement is less than 3 volts, contact Detroit Diesel Technical Service.

### **63.3.3 Check Component Connections**

Perform the following steps to check component connections:


1. Turn the vehicle ignition switch to the OFF position.
2. Inspect the connections of the PWM wire associated with the flash code logged at both harness connector and the item being driven.
  - [a] If the connectors are damaged or broken, repair or replace the damaged terminals. Verify repairs. Refer to section 63.3.9.
  - [b] If the connectors are not damaged or broken, ensure the item is connected to the pulse width modulation wire. If the item is not connected, repair or replace the connector. Verify repairs. Refer to section 63.3.9.
  - [c] If the item is connected, measure the resistance. Refer to section 63.3.8.
  - [d] If this is an Optimized Idle vehicle, refer to section 63.3.4.

### 63.3.4 Check Installation of the Starter Harness Overlay Kit

Perform the following steps to check for proper installation of the starter harness overlay kit when a Code 63 is logged and the engine does not start; see Figure 63-1.

1. Turn off ignition (Optimized Idle Applications).
2. Remove relay from relay block.
3. Measure voltage between terminal 85 on the relay block and a good ground.
  - [a] If voltage measurement is less than 4 VDC, the power lead to the relay is open. Verify connection of wire #439 from the starter relay harness overlay to DDEC wire #439 in the cab.
  - [b] If voltage measurement is more than 4 VDC, measure voltage between terminal 86 on the relay block and a good ground. If voltage is less than 4 VDC, the resistor built into the harness is defective. Replace the harness and verify repairs. Refer to section 63.3.5.
  - [c] If voltage measurement is more than 4 VDC, measure voltage between terminal 86 on the relay block and a good ground. If voltage is more than 4 VDC, the circuit

between terminal 86 on the new relay and power side of Optimized Idle starter relay is open. Repair the open circuit and verify repairs. Refer to section 63.3.9.



28315

Figure 63-1 Optimized Idle Schematic

### 63.3.5 Verify Installation of Starter Relay Harness Overlay Service Kit

Use the following procedure to verify installation of the starter relay harness overlay service kit on Optimized Idle equipped vehicles only.

1. Turn ignition to ON position. Start engine.
2. Toggle cruise ON/OFF switch from OFF to ON. The Optimized Idle light should flash.
3. After the engine shuts down, turn the thermostat on by pressing any button.
4. Press UP or DOWN arrow until the heat or cool symbol begins to flash.
  - [a] If the engine starts, the repairs are complete. Refer to section 63.3.9.
  - [b] If the engine does not start, refer to section 63.3.6.

### 63.3.6 Engine Does Not Start in Optimized Idle Mode

Perform the following steps to start the engine.

1. Verify the hood is closed; the transmission is in neutral; the parking brake is set; and the vehicle wheels are blocked.



#### CAUTION:

**To avoid injury from an accidental startup of an engine equipped with the Optimized Idle<sup>®</sup> system, remove the starter relay from the relay holder.**

2. Remove the overlay relay from the relay block.
3. Measure voltage between terminal 85 and terminal 86 of the relay block.
  - [a] If voltage measurement is less than 4 VDC, the white wire in the overlay harness is open. Repair the open circuit between the overlay harness and the hood/cab switch. Refer to section 63.3.5.
  - [b] If voltage measurement is more than 4 VDC, the relay is inoperative. Replace the relay. Refer to section 8.6.5 of the proper engine Service Manual. Verify the repairs. Refer to section 63.3.9.
  - [c] If this is a Series 55 engine, refer to section 63.3.7.

### 63.3.7 Verify Harness

Perform the following steps to verify harness.

1. If this is a Series 55 engine, verify the engine harness is correct, especially PWM 3 and 4.
  - [a] If the harness is not correct, replace it. Refer to section 63.3.9.
  - [b] If the harness is correct, refer to section 63.3.8.

### 63.3.8 Measure Resistance Between Connector and the Electronic Control Module Case

Perform the following steps to measure resistance between the connector and the ECM case:

1. Turn the vehicle ignition to the OFF position.
2. Ensure connector is installed on the engine harness side or vehicle harness side.
3. Disconnect the PWM wire associated with the code logged at the component.
4. Measure the resistance between the removed connector and the ECM case.
  - [a] If the resistance measurement is between 46,000 and 48,000  $\Omega$ , verify the pin assignment with wiring - view with DDR. Refer to section 63.3.9.
  - [b] If the resistance measurement is not between 46,000 and 48,000  $\Omega$ , the wire is open or shorted to battery. Repair or replace the wire. Verify repairs. Refer to section 63.3.9.

### 63.3.9 Verify Repairs

Perform the following steps to verify repairs for Flash Code 63. To check Optimized Idle, refer to *Optimized Idle Manual* 6SE518.

1. Reconnect all connectors.
2. Clear all codes from the DDR.
3. Plug in the DDR.
4. Turn vehicle ignition switch to the ON position.
  - [a] If Flash Code 63 was not logged, no further troubleshooting is required.
  - [b] If Flash Code 63 was logged, please review this section from the first step to find the error. Refer to section 63.3.1.





---

## 64 FLASH CODE 64

Section	Page
64.1 DESCRIPTION OF FLASH CODE 64 .....	64- 3
64.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 64 .....	64- 3



## **64.1 DESCRIPTION OF FLASH CODE 64**

Flash Code 64 is used to identify a turbo speed fault.

This code is not covered in this manual. If changes occur, notification will be sent from DDC.

## **64.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 64**

The SAE J1587 equivalent code for Flash Code 64 is p 103/0, turbo overspeed, and p 103/8, turbo speed sensor input failure.



---

# 65 FLASH CODE 65 - THROTTLE VALVE FAULT

Section	Page
65.1 DESCRIPTION OF FLASH CODE 65 .....	65- 3
65.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 65 .....	65- 3
65.3 TROUBLESHOOTING FLASH CODE 65 .....	65- 4



## **65.1 DESCRIPTION OF FLASH CODE 65**

For diesel-fueled engines, Flash Code 65 indicates that the air filter sensor input voltage has exceeded or dropped below the expected range.

This code is not covered in this manual (for diesel engines). If changes occur, notification will be sent from DDC.

For gas-fueled engines, Flash Code 65 indicates a fault in the throttle plate.

## **65.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 65**

For diesel engines, the SAE J1587 equivalent codes for Flash Code 65 are 107/3, air filter sensor voltage high, and 107/4, air filter sensor voltage low.

For gas engines, the SAE J1587 equivalent codes for Flash Code 65 is one of the following:

- ☐ p 051/0 - Throttle plate above normal range
- ☐ p 051/1 - Throttle plate below normal range
- ☐ p 051/7 - Throttle plate not responding



## **65.3 TROUBLESHOOTING FLASH CODE 65**

The following procedure will troubleshoot Flash Code 65.

### **65.3.1 Determine System and Failure**


Determine system and failure as follows:

1. Is code 051/0 and is system model year 1997 or older with a 24-volt power supply.
  - [a] Yes to both — install jumper and refer to section 65.3.8.
  - [b] No to either — for jumper harness already installed, refer to section 65.3.2.

### 65.3.2 Check for Voltage

Perform the following steps to check for voltage.

1. Unplug throttle actuator sensor harness connector. See Figure 65-1.
2. Turn ignition ON.
3. Measure voltage between cavity A and B of the connector.
  - [a] If the battery voltage reading (12v/24v) is  $\pm 2$  volts, refer to section 65.3.3.
  - [b] If the voltage is low, refer to section 65.3.4.



**Figure 65-1 Series 50 Gas Engine Sensor Harness**

### 65.3.3 Check for Ground

Perform the following steps to check for ground:

1. Turn ignition OFF.
2. Check ground wire from Cavity B to battery negative (-).
  - [a] If the ground wire is okay, refer to section 65.3.5.
  - [b] If the ground wire is bad, repair and refer to section 65.3.8.

### 65.3.4 Check for Supply

Perform the following steps to check for supply:

1. Turn ignition OFF.
2. Unplug engine sensor harness.
3. Install a jumper between wire cavity A and F of the throttle actuator connector.
4. Measure resistance between cavity R1 and S3, then R1 and T3 at the engine sensor harness.
  - [a] If both readings are less than 1,000  $\Omega$  refer to section 65.3.5.
  - [b] If either reading is greater than 1,000  $\Omega$ , it indicates the #561 or #562 wire is open. Repair or replace the wire and refer to section 65.3.8.

### 65.3.5 Check PWM #2

Perform the following steps to check PWM #2:

1. Move jumper to cavities E and F at the throttle activator.
2. Measure resistance between cavities R1 and Y1 of the engine sensor harness.
  - [a] If the measurement is less than 1,000  $\Omega$ , refer to section 65.3.6.
  - [b] If the measurement is greater than 1,000  $\Omega$ , the wire #909 (PWM #2) is open. Repair or replace the wire and refer to section 65.3.8.

### 65.3.6 Check Connectors

Perform the following steps to check the connectors.

1. Check both connectors for damaged, bent or broken pins or terminals.
  - [a] If the connectors are not damaged, refer to section 65.3.7.
  - [b] If the connectors are damaged, repair or replace the connectors. Refer to section 65.3.8.

### 65.3.7 Check for Short

Perform the following steps to check for a short.

1. Remove jumper.
2. Measure resistance between cavity Y1 and R1 on the engine sensor harness.
3. Measure resistance between Y1 and T3 of the engine sensor harness.
  - [a] If the measured resistance is less than 1,000  $\Omega$ , the wires are shorted to each other. Repair or replace the wires and refer to section 65.3.8.
  - [b] If the measured resistance is greater than 1,000  $\Omega$ , troubleshooting is complete. Review this section or contact Detroit Diesel Technical Service to replace the actuator. Refer to section 65.3.8.

### 65.3.8 Verify Repairs

Perform the following steps to verify repairs.

1. Connect all connectors.
2. With the ignition ON, plug in the DDR and clear the codes.
3. Throttle the engine through various speeds (r/min).
4. Shut the engine off.
5. Turn ignition ON.
6. Read the logged codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 65 is logged with any other codes, troubleshooting is complete. Review this section or contact Detroit Diesel Technical Service.



---

## 66 FLASH CODE 66 - KNOCK SENSOR FAULT

Section	Page
66.1 DESCRIPTION OF FLASH CODE 66 .....	66- 3
66.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 66 .....	66- 3
66.3 TROUBLESHOOTING FLASH CODE 66 .....	66- 4



## **66.1 DESCRIPTION OF FLASH CODE 66**

Flash Code 66 indicates the oil filter sensor input to the ECM has exceeded or dropped below the allowed range.

This code is not covered in this manual (for diesel engines). If changes occur, notification will be sent from DDC.

For gasoline engines, Flash Code 66 indicates one or more faults have occurred in the engine knock level circuitry.

## **66.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 66**

For diesel engines, the SAE J1587 equivalent code for Flash Code 66 is p 099/3, oil filter sensor input voltage high or p 099/4, oil filter sensor input voltage low.

For gasoline engines, the SAE J1587 equivalent code for Flash Code 66 is one of the following: s 076 0, s 076 7, s 076 3 or s 076 4.



## **66.3 TROUBLESHOOTING FLASH CODE 66**

The following procedure will troubleshoot Flash Code 66.

### **66.3.1 Determine Failure**

The following procedure will enable you to determine the failure.

1. Code s 076 0, knock level above normal range - A Failure Mode Identifier (FMI) of 0 is used to advise the user that the knock level is too high to allow the electronics to compensate for it. Troubleshoot this as a mechanical problem.
2. Code s 076 - 7, knock level torque reduction - An FMI of 7 is used to advise the user the loss of engine power is due to the engine electronics trying to adjust the fueling to further reduce the knock level. Clear the code and retest. If the code continues to occur, contact Detroit Diesel Technical Service.
3. For code s 076-3, knock sensor input voltage high, refer to section 66.3.2.
4. For code s 076-4, knock sensor input voltage low; refer to section 66.3.3.

### **66.3.2 Check Signal to Noise Enhancement Filter Module / Knock Sensor**

Perform the following steps to check the Signal to Noise Enhancement Filter (SNEF) and knock sensor.

1. Unplug the SNEF module.
2. Turn ignition ON.
3. Plug in DDR. Read codes.
  - [a] If code s 076-4 is logged, refer to section 66.3.4.
  - [b] If code s 076-3 is logged, refer to section 66.3.5.

### **66.3.3 Check for Open**

Perform the following steps to check for an open:

1. Unplug SNEF.
2. Install a jumper wire between cavity B and E.
3. Turn ignition ON.
4. Plug in DDR. Read codes.
  - [a] If code s 076-3 is logged, refer to section 66.3.4.
  - [b] If code s 076-4 is logged, refer to section 66.3.7.

### **66.3.4 Check Connectors**


Perform the following steps to check the connectors.

1. Check connectors at ECM and SNEF module.
  - [a] If the connectors are in good condition, replace the SNEF module.  
Refer to section 66.3.9.
  - [b] If the connectors are damaged, repair and refer to section 66.3.9.

### 66.3.5 Check for Short to (+)

Perform the following steps to check for a short to positive (+).

1. Turn ignition OFF.
2. Disconnect the engine sensor harness. See Figure 66-1.



**Figure 66-1 Series 50 Gas Engine Sensor Harness**

3. Measure resistance between cavity A and E of the SNEF module connector.
  - [a] If the measured resistance is less than 1,000  $\Omega$ , the wires are shorted to each other. Repair the wires and refer to section 66.3.9.
  - [b] If the measured resistance is greater than 1,000  $\Omega$ , refer to section 66.3.6.

### 66.3.6 Check for Ground

Perform the following steps to check for a ground:

1. Measure resistance between cavity D and battery ground.
  - [a] If the measured resistance is greater than 1,000  $\Omega$ , the ground wire is open. Repair the open and refer to section 66.3.9.
  - [b] If the measured resistance is less than 1,000  $\Omega$ , replace the SNEF module and refer to section 66.3.9.

### 66.3.7 Check for Short to Ground

Perform the following steps to check for a short to ground.

1. Turn ignition OFF.
2. Remove jumper wire.
3. Disconnect the engine harness connector.
4. Measure resistance between cavity A of the SNEF connector and a good ground.
  - [a] If the measured resistance is less than 1,000  $\Omega$ , the signal wire (#976) is shorted to battery (-). Repair or replace the wire and refer to section 66.3.9.
  - [b] If the measured resistance is greater than 1,000  $\Omega$ , replace the knock sensor and refer to section 66.3.8.

### 66.3.8 Check for Signal Open

Perform the following steps to check for a signal open.

1. Insert jumper wire between E and C of the SNEF module connector.
2. Unplug the engine sensor harness connector.
3. Measure resistance between L2 (#976) and X1 (#573).
  - [a] If the measured resistance is greater than 1,000  $\Omega$ , wire #976 is open. Repair or replace the wire and refer to section 66.3.9.
  - [b] If the measured resistance is less than 1,000  $\Omega$ , refer to section 66.3.4.

### 66.3.9 Verify Repairs

Perform the following steps to verify repairs.

1. Hook up all connectors.
2. Start and run the engine.
3. Operate under load. Road test.
4. Turn engine off.
5. Turn ignition ON.
6. Plug in DDR. Read logged codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code s 076-X is logged, all system diagnostics are complete. Please review this section from the first step to find the problem. Refer to section 66.3.1, or contact Detroit Diesel Technical Service.

---

# 67 FLASH CODE 67 - MAP SENSOR FAULT

Section	Page
67.1 DESCRIPTION OF FLASH CODE 67 .....	67- 3
67.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 67 .....	67- 3
67.3 TROUBLESHOOTING FLASH CODE 67 .....	67- 3



## 67.1 DESCRIPTION OF FLASH CODE 67

For diesel engines, Flash Code 67 indicates that the coolant pressure input voltage to the ECM has exceeded or dropped below the allowed range.

This code is not covered in this manual (for diesel engines). If changes occur, notification will be sent from DDC.

For gas engines, Flash Code 67 indicates that the input voltage to the ECM from the air inlet pressure sensor has dropped below 5%, or gone above 95% of the sensor supply voltage.

## 67.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 67

For diesel engines, the SAE J1587 equivalent codes for Flash Code 67 are 109/3, coolant pressure sensor input voltage high, and 109/4, coolant pressure sensor input voltage low.

For gas engines, the SAE J1587 equivalent codes for Flash Code 67 are p 106/3, air inlet pressure sensor input voltage high, and p 106/4, air inlet pressure sensor input voltage low.

## 67.3 TROUBLESHOOTING FLASH CODE 67

The following procedure will troubleshoot Flash Code 67.

### 67.3.1 Determine Failure

Perform the following steps to determine failure.

1. Turn ignition ON.
2. Plug in DDR.
3. Read codes.
  - [a] If code 106/3 is logged, refer to section 33.3.2.
  - [b] If code 106/4 is logged, refer to section 34.3.2.

#### NOTE:

Turbo Boost Sensor (TBS) references = air inlet pressure MAP (Manifold Air Pressure) sensor for troubleshooting codes 106/3 and 106/4. The wire numbers are the same.






---

# 68 FLASH CODE 68 - IDLE VALIDATION FAULT

Section	Page
68.1 DESCRIPTION OF FLASH CODE 68 .....	68- 3
68.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 68 .....	68- 3
68.3 TROUBLESHOOTING FLASH CODE 68 .....	68- 4



**Figure 68-1 ECM**

## **68.1 DESCRIPTION OF FLASH CODE 68**

Flash Code 68 indicates that the ECM, see Figure 68-1, has detected a fault in the idle validation switch (IVS) logic.

## **68.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 68**

The SAE J1587 equivalent code for Flash Code 68 is s 230 5 (open circuit) or s 230 6 (short to ground).

### **NOTE:**

Code 230/5 (open) is set when TPS counts are less than 120 and IVS input is opened.

### **NOTE:**

Code 230/6 (short to ground) is set when TPS counts are greater than 282 and IVS input is grounded to battery (-).

## 68.3 TROUBLESHOOTING FLASH CODE 68

The following procedure will troubleshoot Flash Code 68.

### 68.3.1 Check for Idle Validation Switch Code

Perform the following steps to check for IVS active code:

1. Turn ignition ON.
2. Plug in DDR.
3. Cycle foot pedal; then read codes.
  - [a] If the IVS code is open (FMI=5), validate the throttle pedal application. Refer to section 68.3.4.
  - [b] If the IVS code is grounded (FMI=6), check the IVS switch. Refer to section 68.3.2.

### 68.3.2 Check the Idle Validation Switch

Perform the following step to check the idle validation switch:

1. Turn the vehicle ignition switch to the ON position.



#### CAUTION:

**To avoid injury before starting and running the engine, ensure the vehicle is parked on a level surface, parking brake is set, and the wheels are blocked.**

2. Start and run the engine.

#### NOTE:

Vehicle need not be moving to perform this check.

3. Plug in DDR.
4. Compare idle validation switch input status (switch light status) with the throttle position sensor counts.
  - [a] If the IVS status is ON with the TPS count being greater than 282, measure for resistance. Refer to section 68.3.3.
  - [b] If the IVS status is OFF with the TPS count being greater than 282, clear inactive codes. No further troubleshooting is required. Refer to section 68.3.7.

### **68.3.3 Check Resistance Between Idle Validation Switch Contacts**

Perform the following steps to measure resistance:

1. Turn vehicle ignition to the ON position. Refer to OEM guidelines.
2. Move TPS so counts are greater than 285.
3. Measure resistance between the ECM input (IVS) at the TPS and battery ground using a volt-ohm meter.
  - [a] If the resistance was less than 100  $\Omega$ , the idle validation input/switch is grounded or defective. Contact OEM for repair procedure. Refer to section 68.3.7.
  - [b] If the resistance was greater than 100  $\Omega$ , the fault condition no longer exists. No further troubleshooting is required. Refer to section 68.3.7.

### **68.3.4 Check for Throttle Pedal Application**

Perform the following steps to determine which type of TPS is being used:

1. Visually check to determine which throttle pedal has been installed that utilizes the IVS function.
  - [a] If the throttle pedal has an idle validation switch installed, verify TPS count. Refer to section 68.3.5.
  - [b] If the throttle pedal has no idle validation switch installed, update customer calibration using a programming station. Change the settings from idle validation to "No Function" and save changes. Verify repairs. Refer to section 68.3.7.

### 68.3.5 Determine Throttle Position Sensor Counts / Idle Validation Switch Status

Perform the following steps to determine TPS counts:

1. Turn vehicle ignition to the ON position. Refer to OEM guidelines.



#### CAUTION:

**To avoid injury before starting and running the engine, ensure the vehicle is parked on a level surface, parking brake is set, and the wheels are blocked.**

2. Plug in DDR.

#### NOTE:

Vehicle need not be moving to determine TPS counts.

3. Compare idle validation switch status (switch light status) with the throttle position sensor counts.
  - [a] If the IVS input is ON with the TPS count being less than 120, the problem no longer exists. Refer to section 68.3.7.
  - [b] If the IVS input is OFF with the TPS count being less than 120, refer to section 68.3.6.

### 68.3.6 Check Resistance Between Idle Validation Switch Contacts

Perform the following steps to determine resistance:

1. Turn vehicle ignition switch to the ON position.
2. Measure resistance between the ECM input at the TPS/IVS end of the harness and battery ground.
  - [a] If the resistance is less than 100  $\Omega$ , the IVS is defective. Replace the switch. (Contact the OEM for procedure.) Verify repairs. Refer to section 68.3.7.
  - [b] If the resistance is greater than 100  $\Omega$ , either the IVS input or #953 wire is open or the IVS is defective. Replace the switch. (Contact the OEM for procedure.) Verify repairs. Refer to section 68.3.7.

### 68.3.7 Verify Repairs

Perform the following steps to verify repairs:

1. Clear inactive codes.



**CAUTION:**

**To avoid injury before starting and running the engine, ensure the vehicle is parked on a level surface, parking brake is set, and the wheels are blocked.**

2. Start and run the engine.
3. Depress foot pedal to at least half throttle (>290 counts).
4. Release foot pedal and allow the engine to idle.
5. Visually observe the check engine light (CEL) and DDR.
  - [a] If the CEL comes on, no further troubleshooting is required.
  - [b] If code 68 is logged, refer to section 68.3.1 to troubleshoot Flash Code 68 again.





---

# 69 FLASH CODE 69

Section	Page
69.1 DESCRIPTION OF FLASH CODE 69 .....	69- 3



## **69.1 DESCRIPTION OF FLASH CODE 69**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

# 70 FLASH CODE 70

Section	Page
70.1 DESCRIPTION OF FLASH CODE 70 .....	70- 3



## 70.1 DESCRIPTION OF FLASH CODE 70

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.






---

## 71 FLASH CODE 71 - INJECTOR RESPONSE SHORT

Section	Page
71.1 DESCRIPTION OF FLASH CODE 71 .....	71- 3
71.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 71 .....	71- 3
71.3 TROUBLESHOOTING FLASH CODE 71 .....	71- 4

---



**Figure 71-1      Injectors**

## 71.1 DESCRIPTION OF FLASH CODE 71

Flash Code 71 indicates that the time it takes from when the DDEC ECM requests an injector be turned on, to when the injector solenoid valve actually closes, is shorter than the lower limit of the expected range.

This diagnostic condition is typically:

- ☐ Aerated fuel system
- ☐ High system battery (+) supply voltage
- ☐ Mechanical injector failure
- ☐ Failed solenoid

### NOTE:

The injector diagnostic SID (Subsystem Identifier) indicates which cylinder number has an injector with a short response time. The injector number describes the cylinder and bank that has the injector with a short response time. The DDR will display the injector text description.

Injector response times generally increase with low battery supply voltage and decrease with high battery supply voltage. Although injector response times vary from injector to injector at a given r/min, each individual injector response time should remain relatively consistent from one firing to the next. Wide variations in response time (typically  $\pm 0.2$  ms) for one injector at a steady engine r/min may indicate an electrical problem (faulty alternator or regulator, poor or broken ground cables, etc.). See Figure 71-1 for injector diagram.

## 71.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 71

The SAE J1587 equivalent code for Flash Code 71 is s 001 1, or s 002 1, or s 003 1, or s 004 1, or s 005 1, or s 006 1.

## 71.3 TROUBLESHOOTING FLASH CODE 71

The following procedure will troubleshoot Flash Code 71.

### 71.3.1 Determine Cylinders With Fault

The injector location that is logging the codes is listed in Table 71-1.


	#1	#2	#3	#4	#5	#6	
	(SID 1)	(SID 2)	(SID 3)	(SID 4)	(SID 5)	(SID 6)	
S55/60	1	5	3	6	2	4	cyl #
S50	1	3	4	2	-	-	cyl #

**Table 71-1 Determine Cylinders With Fault**

1. Disconnect the 5-pin injector harness connector at the ECM for those injectors logging the codes.
2. Establish a good ECM case ground by measuring the resistance across two points on the ECM. The resistance should measure less than or equal to 1  $\Omega$ .
3. Once a good case ground is established, keep one of the measurement probes in place and move the other probe to one of the five exposed male injector terminals on the ECM.
4. Measure the resistance. Repeat this procedure at each of the five terminals.
  - [a] If any terminals have a resistance of less than 1000  $\Omega$ , replace the ECM. Refer to section 71.3.5.
  - [b] If all terminals have a resistance of greater than 1000  $\Omega$ , refer to section 71.3.5.

### 71.3.2 Check for Short

Perform the following steps to check for a short. See Figure 71-2.



**Figure 71-2 Injector Harness**

1. Locate the injector harness connector terminals associated with the codes.

2. Measure resistance between that cavity and the cylinder block.
3. Also, measure resistance between that cavity and the appropriate return cavity (G or E).
  - [a] If measured resistance is less than 5  $\Omega$ , the wire is shorted. Repair or replace the harness and refer to section 71.3.5.
  - [b] If measured resistance is greater than 5  $\Omega$ , refer to section 71.3.3.

### 71.3.3 Check for Open

Perform the following steps to check for an open.

1. Insert a jumper wire between the cavity associated with the code and the return for that connector (G or E).
2. Remove the valve cover to gain access to the cylinder associated with the code.
3. Remove the connector terminals at the injector solenoid.
4. Measure resistance between the terminal plugs.
  - [a] If the measured resistance is greater than 5  $\Omega$ , the injector wire is open. Repair or replace the harness and refer to section 71.3.5.
  - [b] If the measured resistance is less than 5  $\Omega$ , and the ECM software is less than 3.00, reprogram the ECM. Refer to section 71.3.5.
  - [c] If the measured resistance is less than 5  $\Omega$ , and the ECM software is 3.00 or higher, remove the alternator belt to disable the actuator and refer to section 71.3.4.

### 71.3.4 Assemble

Perform the following steps to assemble the components.

1. Connect the connectors.
2. Install the valve cover.
3. Start and run the engine.
4. Stop engine.
5. Does the code return?
  - [a] If the code does not return, repair or replace the alternator grounds and refer to section 71.3.5.
  - [b] If the codes return, replace the injector and solenoid. Refer to section 71.3.5.

### **71.3.5 Verify Repairs**

Perform the following steps to verify repairs:

1. Start and run the engine.
2. Stop engine.
3. Check DDR for codes.
  - [a] If no codes are logged, no further troubleshooting is required.
  - [b] If injector codes are logged, all system diagnostics are complete. Please review this section from the first step to find the error. Refer to section 71.3.1.






---

## 72 FLASH CODE 72 - VEHICLE OVERSPEED

Section	Page
72.1 DESCRIPTION OF FLASH CODE 72 .....	72- 3
72.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 72 .....	72- 3
72.3 TROUBLESHOOTING FLASH CODE 72 .....	72- 4



31184

**Figure 72-1 ECM**

## **72.1 DESCRIPTION OF FLASH CODE 72**

Flash Code 72 indicates that the vehicle speed signal to the ECM (with fueling to the engine) has exceeded the vehicle speed limit that is defined in the ECM calibration. See Figure 72-1.

Flash Code 72 also may indicate that the vehicle speed signal to the ECM (without fueling to the engine) has exceeded a secondary vehicle speed limit that is defined in the ECM calibration.

## **72.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 72**

The SAE J1587 equivalent code for Flash Code 72 is p 084 0 or p 084 11.

## 72.3 TROUBLESHOOTING FLASH CODE 72

The following procedure will troubleshoot Flash Code 72.

### 72.3.1 Overspeed

Perform the following steps to troubleshoot overspeed.

1. These codes indicate the vehicle speed has exceeded the limits programmed into the ECM. Verify cruise control and VSS information.
  - [a] Code 84/0 - Overspeed with fuel limit has been exceeded.
  - [b] Code 84/11 - Overspeed without fuel limit has been exceeded.
2. Limits are a reasonable distance above the road speed limit.
  - [a] If the limits are a reasonable distance, go to step 3
  - [b] If the limits are not a reasonable distance above the road speed limit, change the limits and perform the test. Refer to section 72.3.2.

#### NOTE:

For information regarding overspeed limits, refer to section 7.1.29.

3. *Fuel Economy Incentive feature configured recently.*
  - [a] If configured recently, review the limits. W/FEI limits may need to be increased.
  - [b] If not configured recently, the conditions are normal. The vehicle has exceeded speed limits set.

### 72.3.2 Test

Perform the following steps to troubleshoot overspeed.

1. Start and run the engine.
2. Perform a road test.
  - [a] If the overspeed condition has disappeared, troubleshooting is complete.
  - [b] If the overspeed condition still exists, review this section from the beginning to find the error. Refer to section 72.3.1.


---

# 73 FLASH CODE 73 — ESS FAULT

Section	Page
73.1 DESCRIPTION OF FLASH CODE 73 .....	73- 3
73.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 73 .....	73- 3
73.3 TROUBLESHOOTING FLASH CODE 73 .....	73- 4



DDEC III / IV ECM  
FRONT SIDE



ENGINE HARNESS  
CONNECTIONS  
LEFT SIDE


INJECTOR HARNESS  
CONNECTORS  
(5-PIN)

ENGINE HARNESS  
CONNECTOR  
(30-PIN)

POWER HARNESS  
CONNECTOR  
(5-PIN)

COMMUNICATION  
HARNESS  
CONNECTOR  
(6-PIN)

VEHICLE INTERFACE  
HARNESS  
CONNECTOR  
(30-PIN)



VEHICLE HARNESS (OEM)  
CONNECTIONS  
RIGHT SIDE

31184

Figure 73-1 ECM

### 73.1 DESCRIPTION OF FLASH CODE 73

Flash Code 73 is used for many faults.

- ☐ When used with the Engine Synchronous Shift (ESS) system on diesel fuel engines, this code indicates a fault was detected by the ECM, see Figure 73-1, of the input from the shift knob or Neutral Switch.
- ☐ When used in a gas-fueled engine, the code indicates a gas valve position fault.

### 73.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 73

The SAE J1587 equivalent code for Flash Code 73, diesel engines, are listed in Table 73-1.

Flash	SAE Codes	Description
73	s 227-2	Shift knob data erratic, intermittent or incorrect
73	s 227-3	Shift knob voltage above normal or shorted high
73	s 227-4	Shift knob voltage below normal or shorted low
73	s 226-11	Neutral / in-gear switch fault
73	s 151-14	Stuck in gear detected

**Table 73-1 Flash Code 73 Equivalent Codes for Diesel Engines**

The SAE J1587 equivalent code for Flash Code 73, gas engines, are listed in Table 73-2

Flash	SID	FMI	Gas Valve Position
73	A## SID:77	FMI:0	Above normal range
73	A## SID:77	FMI:1	Below normal range
73	A## SID:77	FMI:3	Input voltage high
73	A## SID:77	FMI:4	Input voltage low

**Table 73-2 Flash Code 73 Equivalent Codes for Gas Engines**



## 73.3 TROUBLESHOOTING FLASH CODE 73

The following procedure will troubleshoot Flash Code 73. For troubleshooting diesel engines, refer to section 73.3.1. For troubleshooting gas engines, refer to section 73.3.2.

### 73.3.1 Determine the SAE Code

Perform the following steps to determine the SAE code.


1. Plug in DDR.
2. Turn ignition ON.
3. Record logged codes.
  - [a] If codes 226-11 or 151-14 are logged, refer to section 73.3.2.
  - [b] If code 227 is logged, and codes 226-11 or 151-14 are not logged, refer to section 73.3.5.

### 73.3.2 Check Switch Light Status

Perform the following steps to check the switch light status. See Figure 73-2.

1. Turn ignition ON.
2. Plug in DDR.
3. Select SWITCH LIGHT STATUS.
4. Move the transmission shift lever to neutral; then place in gear.
  - [a] If the switch light status changes when the transmission is in gear vs neutral (in neutral Status=ON), and if DDR BREAK TORQUE, SYSTEM SW and SHIFT INTENT status change (ON/OFF) when switch positions are changed, the problem no longer exists. Perform a road test and return to service. This may still be an intermittent issue.

- [b] If the switch light status does not change when the transmission is in gear vs in neutral, and if DDR BREAK TORQUE, SYSTEM SW and SHIFT INTENT status do not change (ON/OFF) when switch positions are changed, refer to section 73.3.3.**



### Figure 73-2

### 73.3.3 In-Gear and In-Neutral Wiring Test

Perform the following steps to test the in-gear and in-neutral wiring.

1. Locate the in-gear and in-neutral switch at the transmission.
2. Unplug the 4-pin connector.
3. Install the jumper wire between cavity A and B.
4. Turn ignition ON.
5. Plug in the DDR. Determine the in-gear and in-neutral pin assignments.
6. Turn ignition OFF.
7. Unplug the vehicle 30-pin connector.
8. Measure the resistance between the in-neutral pin and a good ground.
  - [a] If the measured resistance is less than or equal to 5  $\Omega$ . Refer to section 73.3.4.
  - [b] If the measured resistance is greater than 5  $\Omega$ . the input wire is open. Repair the open and refer to section 73.3.11.

### 73.3.4 Check Neutral Switch

Perform the following steps to check the neutral switch.

1. Move the jumper wire at the 4-pin connector and place it between the D and C cavities.
2. Measure the resistance between the in-gear pin and a good ground.
  - [a] If the measured resistance is less than or equal to 5  $\Omega$ , replace the switch. (This is a Rockwell component.) Refer to section 73.3.11.
  - [b] If the measured resistance is greater than 5  $\Omega$ , repair the open. Refer to section 73.3.11.

### 73.3.5 Check for Open

Perform the following steps to test for an open.

1. Unplug the 2-pin connector at the shift knob assembly.
2. Unplug the vehicle harness 30-pin connector.
3. Install a jumper wire between cavities A and B at the 2-pin connector.
4. Measure the resistance between cavity A3 and D3 at the 30-pin connector.
  - [a] If the measured resistance is less than or equal to 5  $\Omega$ , refer to section 73.3.6.
  - [b] If the measured resistance is greater than 5  $\Omega$ , one or both of the input wires are open. Repair the open. Refer to section 73.3.11.

### **73.3.6 Check for Short**

Perform the following steps to test for a short.

1. Remove jumper wire.
2. Measure resistance between cavity A3 and D3.
  - [a] If the measured resistance is less than 10,000  $\Omega$ , the wires are shorted to each other. Repair and refer to section 73.3.11.
  - [b] If the measured resistance is greater than 10,000  $\Omega$ , refer to section 73.3.7.

### **73.3.7 SAE Codes 227–2, 227–3, 227–4, Shift Knob Test**

Plug the 2-pin connector back in, and proceed as follows.

1. Set shift knob system switch to ON.
2. Set shift intent switch to Position 2. Break Torque-Up.
3. Unplug the vehicle interface harness connector.
4. Measure the resistance between cavity A3 and D3 of the vehicle harness connector.
  - [a] If the measured resistance is between 42,000 and 45,000  $\Omega$ , refer to section 73.3.8
  - [b] If the measured resistance is not between 42,000 and 45,000  $\Omega$ , replace the shift knob assembly. (This is a Rockwell component.) Refer to section 73.3.11.

### **73.3.8 Shift Knob Check, Continued**

Perform the following steps to test the shift knob.

1. Set shift knob system switch to ON.
2. Set shift intent switch to Position 4, Break Torque-Down.
3. Measure the resistance between cavity A3 and D3 or the vehicle harness connector.
  - [a] If the measured resistance is between 9,000 and 11,000  $\Omega$ , refer to section 73.3.9.
  - [b] Refer to section 73.3.11.

### 73.3.9 Shift Knob Check, Continued

Perform the following steps to test the shift knob.

1. Set shift knob system switch to OFF.
2. Set shift intent switch to Position 1 (Upshift).
3. Measure the resistance between cavity A3 and D3 of the vehicle harness connector.
  - [a] If the measured resistance is between 124,000 and 128,000  $\Omega$ , refer to section 73.3.10.
  - [b] If the measured resistance is not between 124,000 and 128,000  $\Omega$ , replace the shift knob assembly (Rockwell component). Refer to section 73.3.11.

### 73.3.10 Shift Knob Check, Continued

Perform the following steps to test the shift knob.

1. Set shift knob system switch to OFF, DOWN INTENT.
2. Set shift intent switch to Position 2 (DOWN).
3. Measure the resistance between cavity A3 and D3 of the vehicle harness connector.
  - [a] If the measured resistance is between 91,000 and 95,000  $\Omega$ , replace the ECM. Refer to section 73.3.11.
  - [b] If the measured resistance is not between 91,000 and 95,000  $\Omega$ , replace the shift knob assembly (Rockwell component). Refer to section 73.3.11.

### 73.3.11 Test Operation

Perform the following steps to test the operation.

1. Reconnect any connections disconnected during troubleshooting.
2. Perform road test and check all operations of the ESS system.
  - [a] If the ESS system operates correctly, troubleshooting is complete.
  - [b] If the ESS system does not operate correctly, contact Rockwell or Detroit Diesel Technical Service.

### 73.3.12 Gas Engine Troubleshooting

The troubleshooting procedure is to be determined. It is currently not used.

---

## 74 FLASH CODE 74 — OI SAFETY LOOP

Section	Page
74.1 DESCRIPTION OF FLASH CODE 74 .....	74- 3
74.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 74 .....	74- 3
74.3 TROUBLESHOOTING FLASH CODE 74 .....	74- 4



## **74.1 DESCRIPTION OF FLASH CODE 74**

Flash Code 74 indicates that the park brake digital input is shorted to ground between the vehicle interface harness connector and one of the switches (park brake switch, neutral switch, hood switch or optional OEM interlock).

- ☐ If this code is inactive, it may indicate that the vehicle moved during optimized idle operation or that two consecutive engine start attempts were not successful.
- ☐ Flash Code 74 may also indicate that the relay coil is open or is shorted (causing the unsuccessful engine start).


## **74.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 74**

The SAE J1587 equivalent code for Flash Code 74 is p 070.4.



## 74.3 TROUBLESHOOTING FLASH CODE 74

The following procedure will troubleshoot Flash Code 74. For system overview, see Figure 74-1.



28315

**Figure 74-1 Optimized Idle Schematic**

### 74.3.1 Check Diagnostic Data Reader for Codes

Perform the following steps to check the DDR for codes:

1. Turn the vehicle ignition switch ON.
2. Plug the DDR into the diagnostic data link (DDL).
3. Check the DDR for active and inactive optimized idle codes.

**NOTE:**

Service any other logged codes first.

4. Visually examine the DDR for code 74.
  - [a] If code 74 was logged, check for short to ground. Refer to section 74.3.2.
  - [b] If code 74 was not logged, verify fault has been resolved. Refer to section 74.3.6.

### 74.3.2 Check for Short to Ground

Perform the following steps to check for short to ground:

1. Open the vehicle hood. Refer to OEM guidelines.
2. Turn the vehicle ignition switch to the ON position.
3. Plug the DDR into the DDL.

**NOTE:**

The DDR may already be installed.

4. Select the switch/light status (park brake/ISD).
5. Verify the switch/light status (park brake/ISD).
  - [a] If the park brake status is not ON, refer to section 74.3.3.
  - [b] If the park brake status is ON, the input wire is shorted to ground between the hood switch and the ECM. Repair or replace the wire. Verify fault has been resolved. Refer to section 74.3.6.

### 74.3.3 Check for Short to Ground, Continued

Perform the following steps to check for short to ground:

1. Close the vehicle hood. Refer to OEM guidelines.
2. Put the transmission in gear. Refer to OEM guidelines.
3. Verify the switch/light status (park brake).
  - [a] If the park brake status is not ON, continue checking for a short to ground. Refer to section 74.3.4.
  - [b] If the park brake status is ON, the input wire is shorted to ground between the hood switch and the neutral switch. Repair or replace the wire. Verify fault has been resolved. Refer to section 74.3.6.

### 74.3.4 Check for Short to Ground, Continued

Perform the following steps to continue checking for a short to ground:

1. Put the transmission in neutral. Refer to OEM guidelines.
2. Ensure the parking brake is not set. Refer to OEM guidelines.
3. Verify the switch/light status (park brake/ISD).
  - [a] If the park brake/ISD status is not ON, check for vehicle speed. Refer to section 74.3.5.
  - [b] If the park brake/ISD status is ON, the input wire is shorted to ground between the park brake switch and the neutral switch. Repair or replace the wire. Refer to section 54.3. Verify fault has been resolved. Refer to section 74.3.6.

### 74.3.5 Check Vehicle Speed

Perform the following steps to check vehicle speed:

**CAUTION:**

**To avoid injury, before starting and running the engine, ensure that the vehicle is parked on a level surface, parking brake is set, and the wheels are blocked.**

1. Start engine with vehicle in park. Refer to OEM guidelines.
2. Plug the DDR into the DDL.
3. View ECM data list (vehicle speed in mile/h or km/h).
4. Increase engine r/min.
5. Verify vehicle speed.
  - [a] If vehicle speed did not vary, verify fault has been resolved. Refer to section 74.3.6.
  - [b] If vehicle speed did vary or was ever greater than 0 r/min, perform flash code 54 troubleshooting. Refer to section 54.3. Upon completion of repair, verify fault has been resolved. Refer to section 74.3.6.

### 74.3.6 Verify Repairs

Perform the following steps to verify repairs for flash code 74.

1. Turn vehicle ignition to the OFF position.
2. Reconnect all connectors.
3. Close vehicle hood. Refer to OEM guidelines.
4. Set the park brake. Refer to OEM guidelines.
5. Put the transmission in neutral position. Refer to OEM guidelines.

**CAUTION:**

**To avoid injury, before starting and running the engine, ensure that the vehicle is parked on a level surface, parking brake is set, and the wheels are blocked.**

6. Start the engine.
7. Turn the cruise master switch to the ON position.

**NOTE:**

If the switch was set to the ON position before the vehicle was started, turn the switch to the OFF position and then to the ON position.

8. Wait for the engine to shut down.

**NOTE:**

After the idle timer expires, the engine will either shut down or continue to run to charge the battery or keep the oil temperature between 16°C (60°F) and 40°C (104°F).

9. Turn the thermostat on (if installed).
10. Adjust the set point and heating and cooling mode until the thermostat requires the engine to start.

**NOTE:**

If the thermostat is not installed, wait for the lube oil temperature to fall below 16°C (60°F).

**NOTE:**


The alarm will sound and the engine will start. Vehicle power (blower fans) will turn on approximately 30 seconds after the engine starts, due to the thermostat.

11. Verify that optimized idle operates properly.
  - [a] If optimized idle is not operating properly, refer to section 74.3.1 to troubleshoot code 74.
  - [b] If optimized idle is operating correctly, troubleshooting is complete.


---

## 75 FLASH CODE 75 - BATTERY VOLT HIGH

Section	Page
75.1 DESCRIPTION OF FLASH CODE 75 .....	75- 3
75.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 75 .....	75- 3
75.3 TROUBLESHOOTING FLASH CODE 75 .....	75- 3



DDEC III / IV ECM  
FRONT SIDE



ENGINE HARNESS  
CONNECTIONS  
LEFT SIDE


INJECTOR HARNESS  
CONNECTORS  
(5-PIN)

ENGINE HARNESS  
CONNECTOR  
(30-PIN)

POWER HARNESS  
CONNECTOR  
(5-PIN)

COMMUNICATION  
HARNESS  
CONNECTOR  
(6-PIN)

VEHICLE INTERFACE  
HARNESS  
CONNECTOR  
(30-PIN)



VEHICLE HARNESS (OEM)  
CONNECTIONS  
RIGHT SIDE

31184

**Figure 75-1 ECM**

## **75.1 DESCRIPTION OF FLASH CODE 75**

Flash Code 75 indicates that the DDEC® ECM, see Figure 75-1, has detected that the main battery supply voltage to the ECM has exceeded the recommended operating range.

## **75.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 75**

The SAE J1587 equivalent code for Flash Code 75 is p 168 0.

## **75.3 TROUBLESHOOTING FLASH CODE 75**

The following procedure will troubleshoot Flash Code 75.

### **75.3.1 High Voltage**

Perform the following steps to troubleshoot high voltage.

1. Turn ignition ON.
2. Plug in the diagnostic data reader (DDR).
3. Read logged codes.
  - [a] If any codes other than 168/0 are received, service the other codes first.
  - [b] If code 168/0 and no other codes are logged, the voltage to the ECM is too high. Check batteries and/or vehicle charging system.





---

## 76 FLASH CODE 76 - ENGINE OVERSPEED / BRAKE

Section	Page
76.1 DESCRIPTION OF FLASH CODE 76 .....	76- 3
76.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 76 .....	76- 3
76.3 TROUBLESHOOTING FLASH CODE 76 .....	76- 3



## **76.1 DESCRIPTION OF FLASH CODE 76**

Flash Code 76 indicates the engine speed exceeded a calibration limit, and the engine brake output was active at the time the condition occurred.

## **76.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 76**

The SAE J1587 equivalent code for Flash Code 76 is p 121/0, Engine Overspeed with Engine Brake.

## **76.3 TROUBLESHOOTING FLASH CODE 76**

Perform the following steps to troubleshoot Flash Code 76.

### **76.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn vehicle ignition switch ON.
2. Plug in the diagnostic data reader (DDR).
3. Visually check the DDR for codes.
  - [a] If codes other than 121/0 are logged, service them first.
  - [b] If code 121/0 is logged, and no other codes are logged, there was an engine running condition at which the engine r/min exceeded a calibration limit during engine brake operation.

#### **NOTE:**


Determine the reason the engine r/min went too high.




---

## 77 FLASH CODE 77 - FUEL TEMP HIGH

Section	Page
77.1 DESCRIPTION OF FLASH CODE 77 .....	77- 3
77.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 77 .....	77- 3
77.3 TROUBLESHOOTING FLASH CODE 77 .....	77- 3



DDEC III / IV ECM  
FRONT SIDE



ENGINE HARNESS  
CONNECTIONS  
LEFT SIDE


INJECTOR HARNESS  
CONNECTORS  
(5-PIN)

ENGINE HARNESS  
CONNECTOR  
(30-PIN)

POWER HARNESS  
CONNECTOR  
(5-PIN)

COMMUNICATION  
HARNESS  
CONNECTOR  
(6-PIN)

VEHICLE INTERFACE  
HARNESS  
CONNECTOR  
(30-PIN)



VEHICLE HARNESS (OEM)  
CONNECTIONS  
RIGHT SIDE

31184

Figure 77-1 ECM

## **77.1 DESCRIPTION OF FLASH CODE 77**

Flash Code 77 indicates that the fuel temperature has exceeded a calibration limit set by DDC in the ECM, see Figure 77-1.

At this time, this code is logged without illuminating a CEL.

## **77.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 77**

The SAE J1587 equivalent code for Flash Code 77 is p 174 0.

## **77.3 TROUBLESHOOTING FLASH CODE 77**

There is no established procedure to troubleshoot Flash Code 77.

- ☐ The code is used to determine if high fuel temperature may be a cause of reduced power levels.
- ☐ High fuel temperature will reduce available horsepower.
- ☐ Refer to the recommendations of the vehicle manufacturer regarding the possible need for additional fuel cooling.





---

# 78 FLASH CODE 78

Section	Page
78.1 DESCRIPTION OF FLASH CODE 78 .....	78- 3



## **78.1 DESCRIPTION OF FLASH CODE 78**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

# 79 FLASH CODE 79

Section	Page
79.1 DESCRIPTION OF FLASH CODE 79 .....	79- 3



## 79.1 DESCRIPTION OF FLASH CODE 79

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.





**80 FLASH CODE 80**

<b>Section</b>	<b>Page</b>
80.1 DESCRIPTION OF FLASH CODE 80 .....	80- 3



## **80.1 DESCRIPTION OF FLASH CODE 80**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

## 81 FLASH CODE 81

Section	Page
81.1 DESCRIPTION OF FLASH CODE 81 .....	81- 3
81.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 81 .....	81- 3



## **81.1 DESCRIPTION OF FLASH CODE 81**

Flash Code 81 is used to identify oil level, crankcase pressure, dual fuel BOI, or exhaust temperature voltage high.

This code is not covered in this manual. If changes occur, notification will be sent from DDC.

## **81.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 81**

The SAE J1587 equivalent code for Flash Code 81 is p 098 3, oil level sensor input voltage high; p 101 3, crankcase pressure sensor input voltage high, or s 020 3, dual fuel BOI input voltage high.





---

## 82 FLASH CODE 82

Section	Page
82.1 DESCRIPTION OF FLASH CODE 82 .....	82- 3
82.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 82 .....	82- 3



## **82.1 DESCRIPTION OF FLASH CODE 82**

Flash Code 82 is used to identify oil level, crankcase pressure, dual fuel BOI, or exhaust temperature voltage low.

This code is not covered in this manual. If changes occur, notification will be sent from DDC.

## **82.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 82**

The SAE J1587 equivalent code for Flash Code 82 is p 098 4, oil level sensor input voltage low; p 101 4, crankcase pressure sensor input voltage low, or s 020 4, dual fuel BOI input voltage low.



---

# 83 FLASH CODE 83

Section	Page
83.1 DESCRIPTION OF FLASH CODE 83 .....	83- 3
83.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 83 .....	83- 3



### **83.1 DESCRIPTION OF FLASH CODE 83**

Flash Code 83 is used to identify oil level, crankcase pressure, exhaust temperature, or external pump pressure high.

This code is not covered in this manual. If changes occur, notification will be sent from DDC.

### **83.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 83**

The SAE J1587 equivalent code for Flash Code 83 is p 098 0, oil level high; p 101 0, crankcase pressure high; p 173 0, exhaust temperature high; and p 173 3, 4, exhaust temperature sensor input.





---

## 84 FLASH CODE 84

Section	Page
84.1 DESCRIPTION OF FLASH CODE 84 .....	84- 3
84.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 84 .....	84- 3



## **84.1 DESCRIPTION OF FLASH CODE 84**

Flash Code 84 is used to identify oil level or crankcase pressure low.

This code is not covered in this manual. If changes occur, notification will be sent from DDC.

## **84.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 84**

The SAE J1587 equivalent code for Flash Code 84 is p 098/1, oil level low and p 101/1, crankcase pressure low.



---

## 85 FLASH CODE 85 - ENGINE OVERSPEED

Section	Page
85.1 DESCRIPTION OF FLASH CODE 85 .....	85- 3
85.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 85 .....	85- 3
85.3 TROUBLESHOOTING FLASH CODE 85 .....	85- 3



## **85.1 DESCRIPTION OF FLASH CODE 85**

Flash Code 85 indicates that an engine overspeed condition exists.

## **85.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 85**

The SAE J1587 equivalent code for Flash Code 85 is p 190 0, engine overspeed.

## **85.3 TROUBLESHOOTING FLASH CODE 85**

The following procedure will troubleshoot Flash Code 85.

### **85.3.1 Code Information**

Perform the following steps to gather information. This code is logged whenever the engine has been operating over 2500 r/min for at least two seconds.

1. Turn ignition ON.
2. Plug diagnostic data reader (DDR) into the diagnostic data link (DDL). For vehicle harness connector.
3. Select inactive codes.
4. Part of the display will read as follows:
  - [a] First Occurrence
  - [b] Last Occurrence
  - [c] Total Number
  - [d] Total Time
5. If necessary, refer to section 6.2






---

## 86 FLASH CODE 86 - PGS SENSOR HIGH

Section	Page
86.1 DESCRIPTION OF FLASH CODE 86 .....	86- 3
86.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 86 .....	86- 3
86.3 TROUBLESHOOTING FLASH CODE 86 .....	86- 4

---



**Figure 86-1      Pressure Transducer**

## **86.1 DESCRIPTION OF FLASH CODE 86**

Flash Code 86 indicates that the pump pressure circuit failed high (below). For pressure transducer and connector, see Figure 86-1,

## **86.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 86**

The SAE J1587 equivalent code for Flash Code 86 is p 073 3.

## **86.3 TROUBLESHOOTING FLASH CODE 86**

The following procedure will troubleshoot Flash Code 86.

### **86.3.1 Multiple Code Check**

Perform the following steps to check for multiple codes.

1. Turn ignition ON.
2. Plug in DDR.
3. Read active codes.
  - [a] If active code 73/3 was logged, and no other codes were logged, refer to section 86.3.2.
  - [b] If active code 73/4 and any other codes were logged, refer to section 86.3.3.
  - [c] If any codes other than 73/3 were logged, refer to section 91.1.

### **86.3.2 Sensor Check**


Perform the following steps to check the sensor.

1. Turn ignition OFF.
2. Disconnect the Pressure Governor System (PGS) sensor connector.
3. Turn ignition ON.
4. Start engine and operate the PGS in the PRESSURE mode.
5. Read active codes.
  - [a] If active code 73/3 and any other codes were logged, refer to section 86.3.5.
  - [b] If active code 73/4 and any other codes except 73/3 were logged, refer to section 86.3.3.

### 86.3.3 Return Circuit Check

Perform the following steps to check the return circuit.

1. Turn vehicle ignition OFF.
2. Disconnect the vehicle harness connector at the ECM. See Figure 86-2.
3. Install a jumper wire between pins A and B of the PGS sensor harness connector.
4. Measure resistance between sockets D3 and C3 on the vehicle harness connectors.
  - [a] If the resistance measurement is less than or equal to  $5\ \Omega$ , refer to section 86.3.4.
  - [b] If the resistance measurement is greater than  $5\ \Omega$ , or open, the return line (circuit #952) is open. Repair the open and refer to section 86.3.9.



**Figure 86-2 ECM Vehicle Harness Connector**

### 86.3.4 Check Pressure Governor System Connectors

Perform the following steps to check the PGS connectors.

1. Inspect terminals at the PGS sensor connector (both the sensor and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If the terminals and connectors are damaged, repair them and refer to section 86.3.9.
  - [b] If the terminals and connectors are not damaged, replace the PGS sensor and refer to section 86.3.9.

### 86.3.5 Check for Short to +5 Volts

Perform the following steps to check for a short to the +5 volts.

1. Turn ignition OFF.
2. Disconnect the vehicle harness connectors at the ECM.
3. Measure resistance between sockets A3 and D3 on the engine harness connector.
  - [a] If the resistance measurement is greater than 100  $\Omega$  or open, refer to section 86.3.6.
  - [b] If the resistance measurement is less than or equal to 100  $\Omega$ , the signal line (#749) is shorted to the engine +5 volt line (#916). Repair the short and refer to section 86.3.9.

### 86.3.6 Check for Short to Battery +

Perform the following steps to check for a short to battery.

1. Remove both fuses to the ECM.
2. Disconnect the vehicle harness and 5-way power connectors at the ECM.
3. Measure resistance between socket D3 on the engine harness connector and battery (+).
4. Measure resistance between socket D3 of the engine harness connector, and the 5-way power harness sockets A and C.
  - [a] If the resistance measurement for all readings is greater than 100  $\Omega$  or open, refer to section 86.3.7.
  - [b] If the resistance measurement is less than or equal to 100  $\Omega$ , a short exists between the signal line (circuit #749) and battery (+). Repair short and reinsert fuses. Refer to section 86.3.9.

### **86.3.7 Check ECM Connectors**

Perform the following steps to check the ECM connectors.

1. Inspect terminals at the ECM connectors (both ECM and harness side) for damage: bent, corroded, and unseated pins or sockets.
  - [a] If terminals and connectors are damaged, repair them. Refer to section 86.3.9.
  - [b] If terminals and connectors are not damaged, install a test ECM.  
Refer to section 86.3.8.

### **86.3.8 Final Check**

Perform the following steps to do a final check.

1. Reconnect all connectors.
2. Turn vehicle ignition ON.
3. Clear codes.
4. Start and run the engine for one minute.
5. Stop engine.
6. Check DDR for active codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If active code 73/3 is logged, install a test ECM. Refer to section 86.3.9.
  - [c] If any codes except code 73/3 are logged, refer to section 9.1, to service other codes.



### 86.3.9 Verify Repairs


Perform the following steps to verify repairs.

1. Turn ignition switch OFF.
2. Reconnect all connectors.
3. Turn ignition ON.
4. Clear codes.
5. Start and run the engine for one minute.
6. Stop engine.
7. Check DDR for inactive codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code 73/3 is not logged, and other codes are logged, refer to section 9.1, to service other codes.
  - [c] If code 73/3 is logged, and other codes are logged, all system diagnostics are complete. Review this section from the first step to find the problem. Refer to section 86.3.1.

---

## **87 FLASH CODE 87 - PGS SENSOR LOW**

<b>Section</b>	<b>Page</b>
87.1 DESCRIPTION OF FLASH CODE 87 .....	87- 3
87.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 87 .....	87- 3
87.3 TROUBLESHOOTING FLASH CODE 87 .....	87- 3



**Figure 87-1      Pressure Transducer**

## **87.1 DESCRIPTION OF FLASH CODE 87**

Flash Code 87 indicates pump pressure sensor input voltage low.

The signal volts dropped below 5% (normally = <0.25 volts) of the sensor supply. For pressure transducer and connector, see Figure 87-1.

## **87.2 SAE J1587 EQUIVALENT CODE FOR FLASH CODE 87**

The SAE J1587 equivalent code for Flash Code 87 is p 073/4.

## **87.3 TROUBLESHOOTING FLASH CODE 87**

The following procedure will troubleshoot Flash Code 87.

### **87.3.1 Multiple Code Check**

Perform the following steps to check for codes.

1. Turn vehicle ignition ON.
2. Plug in DDR. Read the codes.
  - [a] If codes p 73/4, 100/3 or 4, 102/3 or 4, 110/3 or 4, 174/3 or 4 or 175/3 or 4 are logged, refer to section 91.1.
  - [b] If code 073/4 is logged and no other codes are logged, refer to section 87.3.2.
  - [c] If code 073/4 is logged, and none of the following codes are logged: 100/3 or 4, 102/3 or 4, 110/3 or 4, 174/3 or 4 or 175/3 or 4, refer to section 87.3.2.

### 87.3.2 Sensor Check

Perform the following steps to check the sensor.

1. Turn ignition OFF.
2. Disconnect the pump pressure sensor connector and install a jumper between sockets B and C of the pump pressure sensor transducer connector.
3. Turn ignition ON.
4. Start engine and operate the Pressure Governor System (PGS) in the PRESSURE mode.
5. Read active codes.
  - [a] If code p 73/3 and any other code except p 73/4 display, check to ensure the ECM and PGS sensor connectors are wired properly. If wired properly, refer to section 87.3.3.
  - [b] If code p 73/4 and any other codes display, refer to section 87.3.4.

### 87.3.3 Check Pressure Governor System Sensor Connectors

Perform the following steps to check the pressure governor system (PGS) sensor connectors.

1. Turn ignition OFF.
2. Inspect terminals at the pump pressure sensor connectors (sensor and harness side) for damaged, bent, corroded, and unseated pins or sockets.
  - [a] If the terminals and connectors are not damaged, replace the PGS sensor. Refer to section 87.3.7.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 87.3.7.

### 87.3.4 Check for Short to Return

Perform the following steps to check for a short.

1. Turn ignition OFF.
2. Remove jumper wire.
3. Remove vehicle interface harness connector (30-pin).
4. Turn ignition ON.
5. Measure resistance between C3 (#952) and D3 (#749).
  - [a] If the measured resistance is less than 1,000  $\Omega$ , the wires are shorted to each other. Replace the harness.
  - [b] If the measured resistance is greater than 1,000  $\Omega$ , refer to section 87.3.5.

### 87.3.5 Check for Short to Battery (-)

Perform the following steps to check for a short to the battery (-).

1. Measure resistance between D3 (#749) and battery ground.
  - [a] If the measured resistance is less than 1,000  $\Omega$ , the #749 wire is shorted to the battery. Replace the harness and refer to section 87.3.7.
  - [b] If the measured resistance is greater than 1,000  $\Omega$ , refer to section 87.3.6.

### 87.3.6 Check for 5 Volt Open

Perform the following steps to check for a 5 volt open.

1. Plug in the 30-pin connector for the vehicle sensor harness.
2. Turn ignition ON.
3. Measure voltage between cavity B (#952) and A (#916) of the transducer connector.
  - [a] If the measurement is less than 4.5 volts, wire #916 is open. Repair the open or replace the harness. Refer to section 87.3.7.
  - [b] If the measurement is between 4.5 and 5.5 volts, the signal wire (#749) is open. Repair the wire and refer to section 87.3.7.

### 87.3.7 Verify Repairs

Perform the following steps to verify repairs.

1. Plug in all connectors.
2. Start and run the engine.
3. Plug in DDR and read the codes.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If code p 073/4 is logged, review this section to find the error. Then, contact Detroit Diesel Technical Services.



---

## 88 FLASH CODE 88

Section	Page
88.1 DESCRIPTION OF FLASH CODE 88 .....	88- 3





## **88.1 DESCRIPTION OF FLASH CODE 88**

Flash Code 88 is used to identify coolant pressure low.

This code currently is not covered in this manual. If changes occur, notification will be sent from DDC.



---

## 89 FLASH CODE 89

Section	Page
89.1 DESCRIPTION OF FLASH CODE 89 .....	89- 3



## **89.1 DESCRIPTION OF FLASH CODE 89**

This manual was designed to have the section number equal to the Flash Code for troubleshooting. This section is intentionally left blank.

No DDEC code is currently assigned to this number. If changes occur, notification will be sent from DDC.



---

# 90 ENGINE SENSOR HARNESS

Section	Page
90.1 DESCRIPTION OF ENGINE SENSOR HARNESS .....	90- 3
90.2 TROUBLESHOOTING ENGINE SENSOR HARNESS .....	90- 3





## 90.1 DESCRIPTION OF ENGINE SENSOR HARNESS

Referral to this section indicates a fault within the Engine Sensor Harness affecting signals of various sensors used by the DDEC system.

## 90.2 TROUBLESHOOTING ENGINE SENSOR HARNESS

The following procedure will troubleshoot the engine sensor harness.

### 90.2.1 Check for Low Battery Voltage

Perform the following steps to check for low battery voltage.

1. Plug in the diagnostic data reader (DDR).
  - [a] If Flash Code 168/1 is logged, refer to section 46.3.
  - [b] If code 168/1 is not logged, refer to section 90.2.2.

### 90.2.2 Check for +5 Volts

Perform the following steps to check for +5 volts.

1. Turn vehicle ignition switch OFF.
2. Disconnect the Oil Pressure Sensor (OPS) and Turbo Boost Sensor (TBS) connectors.
3. If applicable, disconnect the Fuel Pressure Sensor (FPS).
4. Turn vehicle ignition switch ON.
5. At each sensor harness connector, measure voltage between socket C (red lead) and socket A (black lead).
  - [a] If the voltage measurement is between 4.7 and 5.2 volts, the voltage reading is correct. Check voltage at the next connector. If all connector voltage readings are correct, refer to section 90.2.3.
  - [b] If the voltage measurement is less than 4.7 volts at any or all connectors, refer to section 90.2.4.
  - [c] If the voltage measurement is greater than 5.2 volts at all connectors, refer to section 90.2.6.

### 90.2.3 Check ECM Connectors

Perform the following steps to check the ECM connectors.

1. Check terminals at the ECM engine harness connector (both the ECM and harness side) for damaged, bent, corroded and unseated pins or sockets.
  - [a] If the terminals and connectors are not damaged, check all sensors, especially OPS, TBS, and TPS (on vehicle system), this indicates that there is no problem on the engine sensor harness. Refer to section 91.1.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 90.2.7.

### 90.2.4 Check for +5 volts or Return Open

Perform the following steps to check for +5 volts or return open.

1. Turn vehicle ignition switch OFF.
2. Disconnect the engine harness connector at the ECM.
3. Install a jumper wire between sockets A and C of any sensor connector that reads less than 4.7 volts. Refer to section 90.2.2.
4. Measure resistance between sockets W1 and Y2 of the engine harness connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 90.2.5.
  - [b] If the resistance measurement is greater than 5  $\Omega$  or open, either the engine +5 volt line (#416), or the return line (#452) is open. Repair the open and refer to section 90.2.7.

### 90.2.5 Check for Short to Ground

Perform the following steps to check for short to ground.

1. Turn vehicle ignition switch OFF.
2. Remove jumper wire.
3. Measure resistance between sockets A and C of the sensor connector.
4. Measure resistance between socket C of the sensor connector and a good ground.
  - [a] If the resistance measurement for both readings is greater than 1,000  $\Omega$ , or open, refer to section 90.2.3.
  - [b] If either resistance measurement is less than or equal to 1,000  $\Omega$ , the engine +5 volt line (#416) is shorted to either the sensor return line (#452) or to chassis ground. Repair the short and refer to section 90.2.7.

## 90.2.6 Check for Short to Battery

Perform the following steps to check for a short to battery.

1. Turn vehicle ignition switch OFF.
2. Remove both fuses to the ECM.
3. Disconnect all five connectors at the ECM.
4. Measure resistance between socket W1 on the engine harness connector and B3 on the vehicle harness connector.
5. Measure resistance between socket W1 on the engine harness connector and the battery (+).
  - [a] If the resistance measurement for both readings is greater than 1,000  $\Omega$ , or open, refer to section 90.2.3.
  - [b] If either resistance measurement is less than or equal to 1,000  $\Omega$ , a short exists between sockets where reading was taken. Repair the short and refer to section 90.2.7.

## 90.2.7 Verify Repairs

Perform the following steps to verify repairs.

1. Turn vehicle ignition switch OFF.
2. Reconnect all connectors.
3. Reconnect fuses (or circuit breakers) if previously disconnected.
4. Turn ignition ON.
5. Clear codes.
6. If Check Engine Light (CEL) does not stay on, start engine and run for one minute
7. Stop engine.
8. Read inactive codes with the DDR.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If codes that brought you to this section are still logged, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 90.2.1.
  - [c] If codes except those which brought you to this section are logged, refer to section 9.1.



---

## 91 VEHICLE HARNESS

Section	Page
91.1 DESCRIPTION OF VEHICLE HARNESS +5 VOLT SUPPLY .....	91- 3
91.2 TROUBLESHOOTING VEHICLE HARNESS +5 VOLT SUPPLY .....	91- 3



## **91.1 DESCRIPTION OF VEHICLE HARNESS +5 VOLT SUPPLY**

Referral to this section indicates a fault within the vehicle interface harness.

### **NOTE:**

It is suggested that the vehicle interface module be installed for test. If the fault(s) clear, you may wish to contact the vehicle manufacturer for instructions on troubleshooting. Otherwise, continue with this section.

## **91.2 TROUBLESHOOTING VEHICLE HARNESS +5 VOLT SUPPLY**

The following procedure will troubleshoot vehicle harness.

### **91.2.1 Check for Low Battery Voltage**

Perform the following steps to check for low battery voltage.

1. Plug in the diagnostic data reader (DDR).
  - [a] If code 168/1 is logged, refer to section 46.3.1.
  - [b] If code 168/1 is not logged, refer to section 91.2.2.

### **91.2.2 Check for +5 Volts**

Perform the following steps to check for +5 volts at the Throttle Position Sensor (TPS).

1. Turn vehicle ignition switch OFF.
2. Disconnect the TPS (disconnect the VSG and PGS, if applicable).
3. Turn vehicle ignition switch ON.
4. Measure voltage on the TPS and VSG harness connector, pin C (#916) (red lead) to pin A (#952) (black lead), and pin A to pin B at the PGS connector, if applicable.
  - [a] If the voltage measurement is between 4.7 and 5.2 volts, the voltage reading is correct. Check voltage at the next connector. If all connector voltage readings are correct, refer to section 91.2.5.
  - [b] If the voltage measurement is less than 4.7 volts, refer to section 91.2.3.
  - [c] If the voltage measurement is greater than 5.2 volts at all connectors, refer to section 91.2.8.



### 91.2.3 Check for +5 volts or Return Open

Perform the following steps to check for +5 volts or return open.

1. Turn vehicle ignition switch OFF.
2. Disconnect the vehicle harness connector at the ECM.
3. Install a jumper wire between pins A and C of the TPS harness connector.
4. Measure resistance between sockets A3 and C3 of the vehicle harness connector.
  - [a] If the resistance measurement is less than or equal to 5  $\Omega$ , refer to section 91.2.4.
  - [b] If the resistance measurement is greater than 5  $\Omega$  or open, either the vehicle +5 volt line (#916) or the sensor return line (#952) is open. Refer to section 91.2.9.

### 91.2.4 Check for +5 Short to Ground

Perform the following steps to check for +5 short to ground.

1. Remove jumper wire.
2. Measure resistance between pins A and C of the TPS harness connector.
3. Measure resistance between pin C of the TPS harness connector and a good ground (battery-).
  - [a] If the resistance measurement for both readings is greater than 1,000  $\Omega$ , or open, refer to section 91.2.7.
  - [b] If either resistance measurement is less than or equal to 1,000  $\Omega$ , wire (#916) is shorted to wire (#952), or battery ground. Repair the short and refer to section 91.2.9.

### 91.2.5 Vehicle Harness 5V Check TPS

Perform the following steps to check TPS.

1. Turn vehicle ignition switch OFF.
2. Reconnect the TPS connector.
3. Turn vehicle ignition switch ON.
4. Select Throttle Sensor percentage on the DDR.
5. Observe throttle percentage at both no throttle and full throttle (engine not running).
  - [a] If the percentage is between 0 and 100%, refer to section 91.2.7.
  - [b] If not getting a reading between 0 and 100%, refer to section 91.2.6.

### **91.2.6 Vehicle Harness 5V Check Throttle Position Sensor Connectors**

Perform the following steps to check TPS connectors.

1. Turn vehicle ignition switch OFF.
2. Disconnect the TPS.
3. Inspect terminals at the TPS connectors (sensor side and harness side) for damage; bent, corroded and unseated pins or sockets.
  - [a] If the terminals and connectors are not damaged, replace TPS. Refer to section 91.2.9.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 91.2.9.

### **91.2.7 Check ECM Connectors**

Perform the following steps to check the ECM connectors.

1. Turn vehicle ignition switch OFF.
2. Disconnect the vehicle harness connector at the ECM (if not already disconnected).
3. Check terminals at the ECM vehicle harness connector (both the ECM and harness side) for damage; bent, corroded and unseated pins or sockets (especially terminals #952, #916, #417 and #510). Install new terminal if in doubt.
  - [a] If the terminals and connectors are not damaged, refer to section 90.2.2.
  - [b] If the terminals and connectors are damaged, repair them. Refer to section 91.2.9.

### 91.2.8 Check for Short to Battery (+)

Perform the following steps to check for a short to battery (+).

1. Turn vehicle ignition switch OFF.
2. Remove both fuses or circuit breakers to the ECM.
3. Disconnect the vehicle harness and the 5-pin power harness connectors at the ECM.
4. Measure resistance between sockets A3 and B3 on the vehicle harness connector.
5. Measure resistance between socket A3 on the vehicle harness connector and the battery (+).
  - [a] If the resistance measurement for all readings is greater than 1,000  $\Omega$ , or open, refer to section 91.2.7.
  - [b] If the resistance measurement is less than 1,000  $\Omega$ , a short exists between the vehicle +5 volt line (#916) and the lines where less than 1,000 was read (either circuit #240, #241 or #439). Repair the short and refer to section 91.2.9.

### 91.2.9 Verify Repairs

Perform the following steps to verify repairs.

1. Turn vehicle ignition switch OFF.
2. Reconnect all connectors.
3. Reconnect fuses (or circuit breakers) if previously disconnected.
4. Turn ignition ON.
5. Clear codes.
6. If Check Engine Light (CEL) does not stay on, start engine and run for one minute.
7. Stop engine.
8. Read inactive codes with the DDR.
  - [a] If no codes are logged, troubleshooting is complete.
  - [b] If codes that brought you to this section are still logged, all system diagnostics are complete. Review this section from the first step to find the error. Refer to section 91.2.1.
  - [c] If codes except those which brought you to this section are logged, refer to section 9.1.

---

## 92 ENGINE WIRING SCHEMATICS


Section	Page
92.1 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 50 ENGINES WITH JAKE BRAKE .....	92- 3
92.2 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 60 ENGINES ..	92- 4
92.3 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 6V92 ENGINES .....	92- 6
92.4 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 8V92 AND 8V149 ENGINES .....	92- 7
92.5 INTERNAL ENGINE BRAKE FOR ECM/WORLD TRANSMISSION INTERFACE .....	92- 8
92.6 INTERNAL ENGINE BRAKE FOR DDEC SYSTEM ECM .....	92-11
92.7 ENGINE HARNESS .....	92-13

---



# **92.1 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 50 ENGINES WITH JAKE BRAKE**

The following wire schematics support the injector harness; see Figure 92-1.




31259

**Figure 92-1**      **Injector Harness - Series 50 Engines With Jake Brake**


## 92.2 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 60 ENGINES

The following wire schematics support the injector harness; see Figure 92-2.



For "Go To A", see Figure 92-3.

**Figure 92-2**      **Injector Harness (Sheet 1-2) (Series 60 Shown)**




**Figure 92-3**      **Injector Harness (Sheet 2-2)**



## 92.3 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 6V92 ENGINES


The following wire schematics support the injector harness; see Figure 92-4.



**Figure 92-4**      **Injector Harness - Series 6V92 Engines**

## 92.4 INJECTOR HARNESS WIRING SCHEMATIC - SERIES 8V92 AND 8V149 ENGINES


The following wire schematics support the injector harness; see Figure 92-5.



**Figure 92-5**      **Injector Harness - Series 8V92 and 8V149 Engines**


## **92.5 INTERNAL ENGINE BRAKE FOR ECM/WORLD TRANSMISSION INTERFACE**

The following wire schematics support the internal engine brake for ECM/World transmission interface; see Figure 92-6.



For "Go To A", see Figure 92-7.


**Figure 92-6 Internal Engine Brake ECM/World Transmission Interface (Sheet 1-2)**



**Figure 92-7 Internal Engine Brake ECM/World Transmission Interface (Sheet 2-2)**

## 92.6 INTERNAL ENGINE BRAKE FOR DDEC SYSTEM ECM

The following wire schematics support the internal engine brake; see Figure 92-8.



For "Go To A", see Figure 92-9.

**Figure 92-8 Internal Engine Brake (Sheet 1-2)**




Figure 92-9 Internal Engine Brake (Sheet 2-2)

## 92.7 ENGINE HARNESS

The following wire schematics support the engine harness; see Figure 92-10.

<u>LABEL</u>	<u>WIRE NO</u>	<u>CAVITY</u>	<u>COLOR</u>
TRS (-)	109	T-1	PPL
TRS (+)	110	T-2	DK GRN
SRS (+)	111	S-2	LT BLU
SRS (-)	112	S-1	WHT
OIL TEMPERATURE	120	R-2	TAN
AIR TEMPERATURE	132	N-2	YEL/RED
COOLANT TEMP	133	P-3	PNK
SENSOR SUPPLY (5VDC)	416	W-1	GRA
TURBO BOOST	432	P-1	ORN
SENSOR RETURN (ENGINE)	452	Y-2	BLACK
FUEL TEMP	472	R-3	ORN
OIL PRESSURE	530	P-2	BRN
ENGINE BRAKE MED	561	S-3	LT BLU
ENGINE BRAKE LO	562	T-3	LT GRN
DIGITAL OUTPUT W-3	563	W-3	YEL
DIGITAL OUTPUT X-3	564	X-3	TAN/BLK
DIGITAL OUTPUT Y-3	565	Y-3	RED
TIMED INPUT	573	X-1	BRN
BARO PRESSURE	904	L-1	PPL/WHT
FUEL PRESSURE	905	M-1	YEL
ANALOG INPUT #3	906	N-1	ORN
ANALOG INPUT #6	907	R-1	DK GRN
PWM OUT #2	909	Y-1	LT GRN/YEL
PWM OUT #3	910	W-2	ORN
PWM OUT #4	911	X-2	PNK
J1939 (+)	925	L-3	DK BLU
J1939 (-)	926	M-3	DK BLU/WHT
J1939 SHIELD	927	N-3	WHT/BLU
ANALOG INPUT #5	958	M-2	BLU
ANALOG INPUT #4	976	L-2	DK GRN


GO TO  
A

24614

For "Go To A", see Figure 92-11.


**Figure 92-10 Engine Harness (Sheet 1-7)**






For "Go To B", see Figure 92-12.

**Figure 92-11 Engine Harness (Sheet 2-7)**




For "Go To C", see Figure 92-13.

**Figure 92-12 Engine Harness (Sheet 3-7)**




For "Go To D", see Figure 92-14.

**Figure 92-13      Engine Harness (Sheet 4-7)**



For "Go To E", see Figure 92-15.

**Figure 92-14 Engine Harness (Sheet 5-7)**



For "Go To F", see Figure 92-16.

**Figure 92-15      Engine Harness (Sheet 6-7)**




Figure 92-16 Engine Harness (Sheet 7-7)



---

## 93 VEHICLE WIRING SCHEMATICS

Section	Page
93.1 VEHICLE INTERFACE HARNESS .....	93- 3
93.2 PRESSURE GOVERNOR SYSTEM - VEHICLE INTERFACE HARNESS CONNECTOR .....	93-12
93.3 ELECTRONIC FIRE COMMANDER HARNESS .....	93-13
93.4 POWER HARNESS - SINGLE ECM, SINGLE FUSE .....	93-14
93.5 POWER HARNESS - SINGLE ECM, DUAL FUSES .....	93-15
93.6 DDEC DIGITAL OUTPUT .....	93-16
93.7 COMMUNICATION HARNESS .....	93-17

---





## 93.1 VEHICLE INTERFACE HARNESS

The following wire schematics support the vehicle interface harness; see Figure 93-1.

<b><u>LABEL</u></b>	<b><u>WIRE NO</u></b>	<b><u>CAVITY</u></b>	<b><u>COLOR</u></b>
COOLANT LEVEL	115	H-3	ORN
LIMITING SPEED GOVERNOR	417	D-2	DK BLUE
CHECK ENGINE LIGHT	419	B-1	PPL/WHT
IGNITION	439	B-3	PNK
DIGITAL INPUT E-1	451	E-1	LT GRN
DIGITAL OUTPUT F-3	499	F-3	LT BLU
TACHOMETER DRIVE	505	K-1	GRA
STOP ENGINE LIGHT	509	B-2	PPL
VARIABLE SPEED GOVERNOR	510	D-1	BRN
DIGITAL INPUT H-1	523	H-1	GRA/RED
DIGITAL INPUT H-2	524	H-2	GRA
DIGITAL INPUT G-1	528	G-1	BRN/RED
DIGITAL INPUT J-2	531	J-2	ORN
DIGITAL INPUT J-1	541	J-1	YEL/RED
DIGITAL INPUT F-1	542	F-1	YEL
DIGITAL INPUT G-2	543	G-2	ORN/BLK
DIGITAL INPUT F-2	544	F-2	BRN/WHT
DIGITAL INPUT G-3	545	G-3	LT BLUE/YEL
DIGITAL OUTPUT A-2	555	A-2	TAN
VEHICLE SPEED (+)	556	E-2	LT BLUE/BLK
VEHICLE SPEED (-)	557	E-3	LT BLUE/ORN
DIGITAL INPUT K-2	583	K-2	LT BLUE/BLK
ANALOG INPUT #7	749	D-3	YEL
DATA LINK (+)	900	C-2	DK GREEN/YEL
DATA LINK (-)	901	C-1	DK GREEN
PWM #1 OUTPUT	908	J-3	WHT
SENSOR SUPPLY (5VDC)	916	A-3	RED/BLK
SENSOR RETURN	952	C-3	BLK
DIGITAL INPUT K-3	979	K-3	WHT
DIGITAL OUTPUT A-1	988	A-1	GRA
<b><u>IGNITION CONNECTOR</u></b>			
+12 V FROM BATTERY	440	A	ORN
BATTERY GROUND	953	B	BLK/WHT




24605

For "Go To A", see Figure 93-2.


**Figure 93-1 Vehicle Interface Harness (Sheet 1-9)**

A

## VEHICLE INTERFACE HARNESS CONNECTOR



ALL UNUSED  
CAVITIES  
REQUIRE PLUGS  
(DDC P/N 12034413)




30 WAY CONNECTOR  
DDC P/N 12034398  
TERMINAL  
DDC P/N 12103881

GO TO  
B

24806


For "Go To B", see Figure 93-3.

**Figure 93-2 Vehicle Interface Harness (Sheet 2-9)**




For "Go To C", see Figure 93-4.

**Figure 93-3 Vehicle Interface Harness (Sheet 3-9)**




For "Go To D", see Figure 93-5.

**Figure 93-4 Vehicle Interface Harness (Sheet 4-9)**




For "Go To E", see Figure 93-6.

**Figure 93-5 Vehicle Interface Harness (Sheet 5-9)**



For "Go To F", see Figure 93-7.


**Figure 93-6 Vehicle Interface Harness (Sheet 6-9)**



For "Go To G", see Figure 93-8.


**Figure 93-7      Vehicle Interface Harness (Sheet 7-9)**





For "Go To H", see Figure 93-9.

**Figure 93-8 Vehicle Interface Harness (Sheet 8-9)**



**Figure 93-9 Vehicle Interface Harness (Sheet 9-9)**

## 93.2 PRESSURE GOVERNOR SYSTEM - VEHICLE INTERFACE HARNESS CONNECTOR

The following wire schematics support the Pressure Governor System (PGS) vehicle interface harness connector; see Figure 93-10.




Figure 93-10

Pressure Governor System Vehicle Interface Harness Connector

### 93.3 ELECTRONIC FIRE COMMANDER HARNESS

The following wire schematics support the electronic fire commander harness; see Figure 93-11.





Figure 93-11

Electronic Fire Commander Harness

## 93.4 POWER HARNESS - SINGLE ECM, SINGLE FUSE


The following wire schematics support the vehicle interface harness; see Figure 93-12.



**Figure 93-12 Power Harness - Single ECM, Single Fuse**

## 93.5 POWER HARNESS - SINGLE ECM, DUAL FUSES


The following wire schematics support the vehicle interface harness; see Figure 93-13.



**Figure 93-13 Power Harness - Single ECM, Dual Fuses**

## 93.6 DDEC DIGITAL OUTPUT


The following wire schematics support the DDEC digital outputs; see Figure 93-14.



**Figure 93-14** DDEC Digital Outputs

## 93.7 COMMUNICATION HARNESS

The following wire schematics support the communication harness; see Figure 93-15.



**Figure 93-15 Communication Harness**






---

## 94 DDEC PRO-LINK OPERATION

Section	Page
94.1 DDEC PRO-LINK OPERATION .....	94- 3



**Figure 94-1 Pro-Link**

## 94.1 DDEC PRO-LINK OPERATION

The following procedure will suggest several ways to use the Pro-Link® on the DDEC system, see Figure 94-1,

### 94.1.1 Diagnostic Codes

Start with the Menu Selection screen.

1. To call up active codes:
  - [a] Select ENGINE and ENTER three times.
2. To call up inactive codes:
  - [a] Select ENGINE and ENTER twice.
  - [b] Select INACTIVE CODES and ENTER.
3. To clear codes:
  - [a] Select ENGINE and push ENTER twice.
  - [b] Go down and select CLEAR CODES and ENTER.
  - [c] Left to YES, and ENTER.
  - [d] Wait and then push FUNC three times.
  - [e] Go to lines 1 and 2 of the Engine Data List, Active and Inactive Codes, and verify that both lines display NO.

### 94.1.2 Cylinder Cutout Sequence

Start with the Menu Selection screen.

1. Select ENGINE and ENTER.
2. Go down and select FUEL INJECTOR INFO and ENTER.
3. Go to CYLINDER CUTOFF and ENTER.
4. Select NEW TEST and ENTER, or REVIEW LAST TEST and ENTER.
5. Select IDLE and ENTER or 1000 RPM and ENTER.
6. Select AUTO and ENTER, or MANUAL and ENTER three times.
7. Test is now in progress.

**NOTE:**

Test results stay stored in the Pro-Link memory as long as the DDR remains powered up.

### 94.1.3 Injector Calibration Update

Start with the Menu Selection screen.

1. Select ENGINE and ENTER.
2. Go down to FUEL INJECTOR INFO and ENTER.
3. Go down to CAL UPDATE and ENTER.
4. Select VIEW and ENTER or select UPDATE and ENTER.
5. Enter password: 0000 or xxxx and ENTER twice.
6. Enter new CAL # and ENTER. Use UP/DN arrow keys to select line.
7. When finished, select FUNC, select YES, ENTER and wait.
8. ENTER to continue.

### 94.1.4 Reprogram Calibration

Start with the Menu Selection screen.

1. Select ENGINE and ENTER.
2. Down to CALIBRATION CHANGE and ENTER.
3. Select REPROGRAM CAL and ENTER.
4. Enter password: 0000 or xxxx and ENTER (xxxx=1 to 9 and A to Z).
5. Select menu to be changed with UP/DN arrow keys and ENTER twice.
6. Use RT/LT arrow keys to change a word or put in a new # and ENTER.
7. When finished, select FUNC.
8. SELECT ANOTHER MENU: left to YES and ENTER, or NO and ENTER.
9. Left to YES and ENTER.
10. Wait and then ENTER to continue.

### 94.1.5 Snapshot Sequence

Start with the Menu Selection screen.

1. Select PRO-LINK and ENTER.
2. Go up to SNAPSHOT and ENTER.
3. Go down to DATA UPDATE RATE and ENTER.
4. Type in NEW RATE and ENTER (.0 to 9.9 seconds); (90 frames will be recorded).
5. Up to TRIGGER SETUP and ENTER.
6. Select TRIGGER SOURCE and ENTER:

- [a] Any Numeric Key
  - [b] Any code
  - [c] Specific PID
  - [d] Specific SID
7. Adjust TRIGGER POINT: NO, or select YES and ENTER; change trigger point with RT/LT arrow keys. ENTER.
  8. WAITING FOR TRIGGER. When ready to take SNAPSHOT, apply the trigger. ANY NUMERIC KEY overrides all other triggers.
  9. PROCESSING TRIGGER; Filling remaining frames (90 frames max). When all frames are filled, the first three lines of the TRIGGER FRAME, T, will display.
    - [a] To do SNAPSHOT after setup is done, do items 1, 2, and 8 only, or go to QUICK TRIGGER and ENTER.
    - [b] SNAPSHOT DATA stays stored in Pro-Link memory as long as the DDR remains powered up.

#### **94.1.6 Print Function**

Print custom data list of snapshot. The printer is attached to the DDR.

1. Select PROLINK. ENTER.
2. Select RS-232 SERIAL PORT. ENTER.
3. Select PRINTER OUTPUT. ENTER.
4. Arrow up or down to SNAPSHOT DATA. ENTER.
5. Right to CUSTOM. ENTER twice.
6. Select six items from data list using arrow up or down. ENTER after each selection.  
- FUNC.
7. Type 001; ENTER; 090; ENTER.